

[Manuals.plus](#) /

› [Kingdura](#) /

› Kingdura 10FT Outdoor Patio Umbrella Instruction Manual

Kingdura 10ft Patio Umbrella

Kingdura 10FT Outdoor Patio Umbrella Instruction Manual

Model: 10ft Patio Umbrella

1. INTRODUCTION

Thank you for choosing the Kingdura 10FT Outdoor Patio Umbrella. This manual provides essential information for the safe assembly, operation, and maintenance of your new patio umbrella. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: Kingdura 10FT Outdoor Patio Umbrella providing shade in an outdoor setting.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- **Secure Base:** Always use a weighted umbrella base (not included) to prevent the umbrella from tipping over. Ensure the base is heavy enough for a 10-foot umbrella.
- **Wind Conditions:** Close the umbrella during strong winds, heavy rain, or other severe weather conditions to prevent damage to the umbrella and potential hazards.
- **Clearance:** Ensure adequate clearance around the umbrella when opening and closing to avoid contact with objects or people.
- **Children and Pets:** Keep children and pets away from the umbrella during operation.
- **Flammable Materials:** Do not place the umbrella near open flames or heat sources.
- **Inspection:** Regularly inspect all parts for wear, tear, or damage. Do not use if any components are compromised.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Umbrella Canopy with Fiberglass Ribs (1)
- Upper Pole Section with Crank Mechanism (1)
- Lower Pole Section (1)
- Instruction Manual (1)

Note: A weighted umbrella base is **not included** and must be purchased separately. The pole diameter is 1.5 inches (37.9mm).

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Kingdura patio umbrella:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Connect Pole Sections:** Insert the upper pole section (with the crank mechanism) into the lower pole section. Ensure the connection is secure.
3. **Insert into Base:** Place the assembled pole into a suitable weighted umbrella base (not included). Tighten any securing knobs on the base to hold the pole firmly in place.
4. **Open Canopy:** Slowly turn the crank handle clockwise to open the umbrella canopy until it is fully extended. Do not force the crank if resistance is met.



Image 4.1: Visual representation of the umbrella in closed and open states.

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing the Umbrella

- **To Open:** Turn the crank handle clockwise until the canopy is fully open and taut.
- **To Close:** Turn the crank handle counter-clockwise until the canopy is fully closed and secured.

5.2 Using the Tilt Mechanism

The umbrella features a push-button tilt mechanism for adjustable shade angles.

- **To Tilt:** Locate the push button on the pole. Press and hold the button while gently tilting the canopy to your desired angle (0-30°).
- **To Return to Upright:** Press and hold the button again while returning the canopy to its vertical position.




Image 5.1: Details of the umbrella's operational features including the crank and tilt mechanisms.

6. MAINTENANCE

Proper maintenance will extend the life of your patio umbrella.

- **Cleaning:** Wipe the canopy and pole with a dry cloth to remove dust and debris. For stubborn stains, use a mild soap solution and a soft brush, then rinse thoroughly and allow to air dry completely before closing or storing.
- **Storage:** When not in use for extended periods, or during off-season, close the umbrella and secure it with a tie strap. Store in a dry, protected area to prevent damage from elements.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight. Inspect the fiberglass ribs and polyester fabric for any signs of wear or damage.

Versatile Outdoor Fabric

Reliable cover for all your outdoor activities.



Anti-UV



High Quality



Water-Repellent



Air-Flow

Image 6.1: Detail of the durable 180g solution-dyed polyester fabric.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Umbrella will not open/close smoothly.	Mechanism obstructed or dirty; pole not fully inserted.	Check for obstructions. Clean crank mechanism. Ensure pole sections are securely connected and fully seated in the base.
Umbrella wobbles or tips over.	Insufficiently weighted base; loose pole in base.	Ensure you are using a heavy enough weighted base. Tighten all securing knobs on the base.
Tilt mechanism is stuck.	Button not fully depressed; debris in mechanism.	Ensure the push button is fully depressed. Check for and remove any debris around the button.

8. SPECIFICATIONS

Size: 10 FT Diameter

Pole Diameter: 1.5 inches (37.9mm)

Canopy Material: 180g Solution Dyed Polyester

Frame Material: Iron Pole, 8 Fiberglass Ribs

UV Protection: UV 50+

Opening Mechanism: Crank Lift

Tilt Mechanism: Manual Push Button Tilt (0-30°)

Color: Beige

Approximate Weight: 13.7 pounds



Image 8.1: Key dimensions of the 10FT patio umbrella.



FIBERGLASS UMBRELLA OFFERS BETTER WIND RESISTANCE

Featuring robust fiberglass ribs, this umbrella is less prone to breakage compared to traditional iron umbrellas.

Image 8.2: Fiberglass ribs designed for enhanced wind resistance.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Kingdura 10FT Outdoor Patio Umbrella, please contact Kingdura customer service. Refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question