

WLIVE B0FGD3NT33

WLIVE 9-Drawer Dresser and Modern TV Stand User Manual

Model: B0FGD3NT33

INTRODUCTION

Thank you for choosing the WLIVE 9-Drawer Dresser and Modern TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before assembly and retain them for future reference.



An overview of the WLIVE 9-Drawer Dresser and the Modern TV Stand, showcasing both units together.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Periodically check and re-tighten fasteners as needed.
- Do not overload drawers or shelves. Refer to the specifications section for weight limits.
- For the dresser, it is highly recommended to use the included anti-tip kit to secure the unit to a wall, preventing accidental tipping.
- Keep small parts and packaging materials away from children and pets to avoid choking hazards.
- Do not stand or climb on the furniture.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Metal Frame Components (for Dresser and TV Stand)
- Fabric Drawers (9 units for Dresser)
- Wooden Top Board (for Dresser)
- TV Stand Top Panel and Side Panels
- TV Stand Cabinet Doors and Shelves
- Adjustable Feet
- Handles (for drawers and cabinet doors)
- Assembly Hardware (screws, bolts, Allen wrench, etc.)
- Anti-Tip Kit (for Dresser)

SETUP AND ASSEMBLY

Assembly typically requires two adults. Follow the steps carefully.

Dresser Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface. Identify each component using the parts list.
2. **Assemble the Frame:** Connect the metal frame components according to the diagrams provided in the separate assembly guide (not included in this manual). Ensure all screws are finger-tightened initially.
3. **Attach Adjustable Feet:** Screw the adjustable plastic feet into the bottom of the dresser frame. Adjust them to ensure stability on uneven floors.
4. **Install Wooden Top:** Place the wooden top board onto the assembled metal frame and secure it with the provided screws.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom panel to create a rigid structure. Attach the handles to the front of each drawer.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective compartments in the dresser frame.
7. **Secure with Anti-Tip Kit:** Attach the anti-tip bracket to the top rear of the dresser and secure it to a wall stud using the provided hardware. This step is crucial for safety.



A clear front view of the 9-drawer dresser, highlighting the fabric drawers and metal frame.

TV Stand Assembly

1. **Unpack and Identify:** Lay out all TV stand components and hardware.
2. **Assemble Base Frame:** Connect the metal legs and support bars to form the base structure of the TV stand. Tighten all connections securely.
3. **Attach Panels:** Secure the bottom, side, and middle support panels to the metal frame using the provided hardware.
4. **Install Cabinet Doors:** Attach the cabinet doors to the designated sections using the hinges. Ensure they open and close smoothly.
5. **Place Top Panel:** Position the top panel onto the assembled frame and secure it.
6. **Insert Shelves:** Place any adjustable or fixed shelves into the open compartments.



An illustration of the TV stand's features, including the metal handles for cabinet doors and the stable metal leg structure.

OPERATING INSTRUCTIONS

Dresser Usage

- **Drawer Operation:** Gently pull the handles to open drawers and push to close. Avoid forcing drawers.
- **Weight Distribution:** Distribute items evenly within drawers to prevent strain on the fabric and frame.
- **Top Surface:** The wooden top can be used for lamps, clocks, or decorative items. Do not place excessively heavy objects on top.



The 9-drawer dresser placed in a bedroom, illustrating its use as a storage solution.

TV Stand Usage

- **TV Placement:** Place your television centrally on the top surface. Ensure the TV base fits within the stand's dimensions.
- **Cable Management:** Utilize the open compartments and cabinet spaces for media devices and to help manage cables.
- **Cabinet Storage:** Use the enclosed cabinets for storing media, accessories, or other items.



The modern TV stand with a television, showing its capacity to hold a large screen TV and media devices.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** For fabric drawers, spot clean with a mild detergent and allow to air dry. Do not machine wash.
- **Regular Checks:** Periodically inspect all connections and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to materials.

TROUBLESHOOTING

- **Wobbly Unit:** Check that all screws are tightened. Adjust the leveling feet on the bottom of the unit to stabilize it on uneven floors.
- **Drawers Not Sliding Smoothly:** Ensure drawers are correctly inserted and not overloaded. Check for any obstructions.
- **Missing Parts:** If any parts are missing upon unboxing, do not proceed with assembly. Contact WLIVE customer support for assistance.

SPECIFICATIONS

WLIVE 9-Drawer Dresser

- **Overall Dimensions:** Approximately 39.6" (L) x 11.8" (W) x 40.2" (H)
- **Large Drawer Dimensions:** Approximately 18.2" (L) x 11.8" (W) x 8.5" (H)

- **Small Drawer Dimensions:** Approximately 12.0" (L) x 11.8" (W) x 8.5" (H)
- **Material:** Steel frame, wooden top, fabric drawers



Detailed measurements of the 9-drawer dresser, including overall height, width, depth, and individual drawer sizes.

WLIVE Modern TV Stand

- **Overall Dimensions:** Approximately 57.9" (L) x 14.6" (W) x 17.7" (H)
- **Maximum TV Size:** Up to 65 inches
- **Total Board Capacity:** 110 lbs
- **Material:** Wood top, metal frame, metal legs



Detailed measurements of the TV stand, including overall dimensions and the maximum weight capacity of 110 lbs.

WARRANTY AND SUPPORT

WLIVE products are designed for quality and durability. For specific warranty information or if you require assistance with assembly, missing parts, or any other issues, please contact WLIVE customer support through your purchase platform or the official WLIVE website. Please have your model number (B0FGD3NT33) and purchase date available when contacting support.