

[manuals.plus](#) /› [Bemi](#) /› [Bemi Cognita Tab 6+ E-Reader User Manual](#)

Bemi Cognita Tab 6+

Bemi Cognita Tab 6+ E-Reader User Manual

Model: Cognita Tab 6+

1. INTRODUCTION

This user manual provides detailed instructions for the Bemi Cognita Tab 6+ E-Reader. Please read this manual carefully before using your device to ensure proper operation and to maximize your reading experience. Keep this manual for future reference.

1.1 Package Contents

- Bemi Cognita Tab 6+ E-Reader
- USB Charging Cable

Ensure all items are present and in good condition upon unboxing.

2. DEVICE OVERVIEW

Familiarize yourself with the physical components of your Bemi Cognita Tab 6+ E-Reader.



Figure 2.1: Front view of the Bemi Cognita Tab 6+ E-Reader. The device features a 6-inch E-Ink display with the Bemi logo and model name visible. The screen is designed to mimic paper for a comfortable reading experience.



Figure 2.2: Front and back view of the Bemi Cognita Tab 6+ E-Reader. This image highlights the device's thin design and the textured back cover, which provides a secure grip.




Figure 2.3: Side view of the Bemi Cognita Tab 6+ E-Reader, illustrating the location of the power button and a small LED indicator. This button is used for turning the device on/off and waking it from sleep.

2.1 Key Components:

- **6-inch E-Ink Touchscreen:** Glare-free display for comfortable reading.
- **Power Button:** Located on the side for turning the device on/off and sleep/wake.
- **USB-C Port:** For charging and data transfer.
- **MicroSD Card Slot:** Expandable storage up to 256GB.
- **Side Control Buttons:** For page turning and navigation.
- **SMARTlight:** Adjustable front light for reading in various conditions.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your Bemi Cognita Tab 6+ E-Reader. Connect the provided USB cable to the device's USB-C port and the other end to a compatible USB power adapter (not included) or a computer's USB port.

- A full charge typically takes approximately 2-3 hours.
- The charging indicator light will show the charging status.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button (refer to Figure 2.3) for a few seconds until the screen activates.
- **To Power Off:** Press and hold the Power button until a power-off menu appears, then select "Power Off".
- **To Sleep/Wake:** Briefly press the Power button to put the device into sleep mode or wake it up.

3.3 Wi-Fi Connection

Connecting to Wi-Fi allows you to download books, transfer files, and access online services.

1. From the home screen, tap the **Settings** icon.
2. Select **Wi-Fi**.
3. Toggle the Wi-Fi switch to **On**.
4. The device will scan for available networks. Select your desired network from the list.
5. Enter the password if prompted, then tap **Connect**.

3.4 Initial Configuration

Upon first power-on, you may be guided through initial setup steps, including language selection and time zone settings. Follow the on-screen prompts.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Interface

The Bemi Cognita Tab 6+ features a touch-sensitive E-Ink screen and physical side buttons for navigation.

- **Touch Gestures:** Tap to select, swipe to scroll, pinch to zoom (where supported).
- **Side Buttons:** Use the physical buttons on the side to turn pages forward or backward during reading.
- **G-Sensor:** The device automatically rotates the screen orientation based on how you hold it, accommodating both right and left-handed users.




Figure 4.1: User holding the Bemi Cognita Tab 6+ E-Reader while reading. The image shows the clear text display on the E-Ink screen, highlighting the device's readability.

4.2 Reading Books

To open and read a book:

1. From the home screen, tap on the **Library** or **Books** icon.
2. Browse your collection or use the search function to find a book.
3. Tap on the book cover to open it.
4. Use the touch screen or side buttons to turn pages.

4.3 Adjusting SMARTlight

The SMARTlight feature allows you to adjust both the brightness and color temperature of the screen's front light.

1. During reading, tap the center of the screen to bring up the reading menu.
2. Look for the **Light** or **SMARTlight** icon.
3. Adjust the sliders for brightness (intensity) and color temperature (warm to cool) to your preference.

4.4 Transferring Files

You can transfer e-books and other supported files to your device via Wi-Fi or USB cable.

- **Via Wi-Fi:** If your device supports cloud services or direct Wi-Fi transfer, follow the specific application instructions.
- **Via USB Cable:**
 - a. Connect your E-Reader to a computer using the provided USB cable.
 - b. The device will appear as a removable storage drive on your computer.
 - c. Drag and drop your desired files (e.g., EPUB, PDF, MOBI) into the appropriate folders on the E-Reader (e.g., "Books" folder).
 - d. Safely eject the device from your computer before disconnecting the cable.

4.5 Using MicroSD Card

To expand storage, insert a microSD card (up to 256GB) into the designated slot.

- Gently insert the microSD card with the gold contacts facing down until it clicks into place.
- To remove, gently push the card inward until it springs out.
- Files on the microSD card will be accessible through the device's file manager or library.

5. MAINTENANCE

5.1 Cleaning the Device

- Use a soft, lint-free cloth to gently wipe the screen and body of the device.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- Charge the device regularly, even if not used, to prevent deep discharge.

5.3 Storage

When not in use, store your E-Reader in a protective case to prevent scratches and damage to the screen.

6. TROUBLESHOOTING

If you encounter issues with your Bemi Cognita Tab 6+, refer to the following common solutions:

Problem	Solution
Device does not turn on.	Ensure the battery is charged. Connect the device to a power source for at least 30 minutes. If it still doesn't turn on, try a hard reset by holding the power button for 10-15 seconds.

Problem	Solution
Screen is frozen or unresponsive.	Perform a soft reset by holding the power button for 5-7 seconds until the device restarts. If the issue persists, try a hard reset.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Verify the Wi-Fi password. Restart your E-Reader and your Wi-Fi router. Ensure you are within range of the Wi-Fi signal.
Books are not appearing in the library.	Ensure the files are in a supported format (e.g., EPUB, PDF). If transferred via USB, ensure they are in the correct folder. Try refreshing the library or restarting the device.
Battery drains quickly.	Reduce screen brightness. Turn off Wi-Fi and Bluetooth when not in use. Close background applications. Ensure the device is not constantly searching for networks.

7. SPECIFICATIONS

Feature	Detail
Model Name	Bemi Cognita Tab 6+
Screen Size	6 Inches (E-Ink Carta, 1024x758, 212 ppi)
Internal Memory	32 GB
Expandable Storage	MicroSD card slot, up to 256 GB
Connectivity	Wi-Fi, Bluetooth
Operating System	Android 8.1
Human Interface Input	Touchscreen, Side Control Buttons
Special Features	Adjustable SMARTlight, G-Sensor for auto-rotation, Glare-Free & Eye-Friendly E-Ink Display
Dimensions (Approx.)	7 mm thickness
Included Components	USB Cable

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Bemi Cognita Tab 6+ E-Reader comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Bemi website for detailed terms and conditions regarding warranty coverage and duration.

Optional protection plans may be available for extended coverage. Please check with your retailer for details.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Bemi customer support:

- **Website:** www.bemi-electronics.com
- **Email:** Refer to the Bemi website for contact email.
- **Phone:** Refer to the Bemi website for contact phone numbers.

When contacting support, please have your device model (Cognita Tab 6+) and purchase information ready.

© 2025 Bemi. All rights reserved.