



Manuals.plus /

› Busaurus /

› Busaurus 62" Oversized Chaise Lounge Chair Indoor User Manual

Busaurus B0FGDRB76S

Busaurus 62" Oversized Chaise Lounge Chair Indoor User Manual

Model: B0FGDRB76S

INTRODUCTION

This manual provides essential information for the safe and proper use of your Busaurus 62" Oversized Chaise Lounge Chair. Please read these instructions thoroughly before setup and operation to ensure optimal performance and longevity of your product.

SAFETY INFORMATION

- Ensure the product is placed on a flat, stable, and level surface to prevent tipping.
- Do not exceed the maximum weight capacity of **450 lbs** to avoid damage or injury.
- Keep the chaise lounge away from open flames, heaters, and direct heat sources.
- Avoid contact with sharp objects that could puncture or tear the fabric.
- Supervise children and pets when they are near or on the furniture.

PACKAGE CONTENTS

Your Busaurus Chaise Lounge Chair package includes the following items:

- 1 x Oversized Chaise Lounge Chair (compressed)
- 3 x Throw Pillows
- 2 x Integrated Cup Holders (pre-installed)

SETUP INSTRUCTIONS

Your Busaurus Chaise Lounge Chair is designed for convenience and requires no traditional assembly. It arrives compressed in a single box.

1. Carefully remove the entire compressed sofa from its shipping box.
2. Place the compressed sofa in your desired room and location.
3. Allow the sofa to expand naturally for a minimum of **96 hours**. During this time, the high-density foam will fully decompress and reach its intended size and comfort level.



Image: Illustration of the unboxing process, showing the compressed sofa being removed from the box, cut open, and then expanding over 96 hours.

OPERATING INSTRUCTIONS

Your chaise lounge is designed for versatile use, easily adapting to various needs and preferences.

Converting the Chaise Lounge

The chaise lounge can be effortlessly transformed into different configurations:

- **Chaise Lounge:** Use as a comfortable lounge chair with an extended footrest for relaxation.
- **Sofa with Footrest:** Adjust the ottoman section to create a traditional sofa setup with a separate, movable footrest.
- **Sleeper Bed:** Fully extend all sections to form a flat, spacious sleeping surface for guests or extended lounging.



Image: The chaise lounge shown in two states: as a compact chair with an ottoman, and fully extended as a sleeper bed.



Image: A graphic depicting the three primary configurations of the chaise lounge: a standard chaise, a sofa with a separate footrest, and a fully extended sofa bed.

Using Integrated Features

- **Cup Holders:** Two convenient cup holders are integrated into the armrests. Use them to securely hold beverages while you relax.
- **Throw Pillows:** The three included throw pillows provide additional comfort and lumbar support. Arrange them as desired for personalized relaxation.



Image: A close-up view of the chaise lounge armrest, highlighting the integrated cup holder, with a person comfortably seated.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and extend the lifespan of your chaise lounge:

- **Cleaning:** For general cleaning, wipe the fabric with a clean, dry cloth. For spills, blot immediately with a clean, damp cloth. Avoid rubbing, which can spread the stain. Do not use harsh chemical cleaners, as they may damage the fabric.
- **Pillows:** The throw pillows are removable. Refer to their individual care labels for specific cleaning instructions if present.
- **Fabric:** The corduroy fabric is durable. Regular light vacuuming with an upholstery attachment can help remove dust and debris.
- **Non-slip Pads:** The bottom of the chaise lounge is equipped with non-slip pads. Periodically check and clean these pads to ensure they are free of debris and maintain stability.



Image: A composite image illustrating key practical design features: a removable pillow, an integrated cup holder with a glass, and a detailed view of the non-slip pad on the furniture's base.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Chaise lounge not fully expanded	Insufficient expansion time	Allow the product to expand for the recommended 96 hours. Ensure it is in a well-ventilated room.
Instability or wobbling	Uneven floor surface; debris under non-slip pads	Place the chaise lounge on a flat, level surface. Check and clean the non-slip pads on the bottom.
Fabric appears discolored or faded	Prolonged exposure to direct sunlight; improper cleaning agents	Avoid prolonged direct sunlight exposure. Follow recommended cleaning instructions using only appropriate methods.
Difficulty converting between modes	Obstruction; improper alignment of sections	Ensure no objects are obstructing the conversion mechanism. Gently adjust sections for proper alignment during transformation.

SPECIFICATIONS

Feature	Detail
Brand	Busaurus
Model	B0FGDRB76S
Color	Dark Grey
Product Dimensions (Chaise)	62"D x 52.4"W x 25"H
Product Dimensions (Sleeper Bed)	85.4"D x 52.4"W x 25"H
Seat Height	16.6 Inches
Armrest Width	10.2 Inches
Weight Capacity	450 lbs (Maximum)
Material	Corduroy Fabric, High-Density Foam Fill
Included Components	3 Throw Pillows, 2 Cup Holders
Assembly	No Assembly Required (96-hour expansion)
Care Instructions	Wipe Clean with Dry Cloth



Image: A comprehensive diagram illustrating the dimensions of the chaise lounge in its various configurations, including width, depth, height, and armrest measurements. It also highlights the 450 lbs maximum weight capacity and notes "No Assembly Required".

Required" and "All in one box".

WARRANTY AND SUPPORT

For warranty information or customer support, please contact Busaurus directly through their official channels or the retailer where the product was purchased. It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.

IMPORTANT NOTES

- **Color Variations:** Slight color variations may occur due to differences in screen calibration and display settings. For the most accurate representation of true colors, viewing the product in natural light is recommended.
- **Expansion Time:** The specified 96-hour expansion period is crucial for the product to achieve its intended shape, firmness, and comfort. Do not attempt to use the chaise lounge fully before this period has elapsed.



Image: An illustration demonstrating how the product's color might appear differently on various digital screens (smartphone, tablet, desktop monitor) due to display settings and calibration.