

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [WEWE](#) /
- › [WEWE Kitchen Faucet W100-06-08MB Instruction Manual](#)

WEWE W100-06-08MB

WEWE Kitchen Faucet W100-06-08MB Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your new WEWE Kitchen Faucet, Model W100-06-08MB. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of your faucet. Keep this manual for future reference.

SETUP AND INSTALLATION

1. Package Contents


Verify that all components are present before beginning installation. The package should include the faucet body, handle, sprayer, and instruction manual.

2. Product Dimensions and Compatibility


Ensure your sink and countertop are compatible with the faucet's specifications.



Hole Size Compatible



1 Hole



Cold Supply Hose 31.50"



Hot Supply Hose 29.50"



Image Description: This diagram illustrates the key dimensions of the WEWE Kitchen Faucet, including its overall height of 15.7 inches, spout reach of 8.5 inches, and spout height of 8.5 inches. It also indicates 180-degree hot and cold water control. Compatibility details show a required hole size between 1.38 and 1.5 inches, and the lengths of the cold (31.50 inches) and hot (29.50 inches) supply hoses, both with 3/8 inch connectors.

- **Installation Method:** Single Hole, Deck Mount
- **Compatible Hole Size:** 1.38 - 1.5 inches
- **Supply Hose Lengths:** Cold 31.50 inches (3/8"), Hot 29.50 inches (3/8")

3. Installation Steps

The faucet is designed for straightforward installation. Follow these general steps:

1. Turn off the main water supply.
2. Remove your old faucet (if applicable).
3. Clean the mounting surface on your sink or countertop.
4. Insert the new faucet into the mounting hole.
5. Secure the faucet from underneath the sink using the provided mounting hardware.
6. Connect the hot and cold water supply lines to your angle stops. Ensure connections are tight to prevent leaks.
7. Connect the sprayer hose to the main faucet body.
8. Turn on the main water supply and check for leaks.



ULTRA-SIMPLE INSTALLATION

Installs in **minutes**, no tools
required.

Image Description: This image displays the underside of the faucet installation, highlighting the connection of the water supply lines and the securing nut that fastens the faucet to the countertop. The design aims for a simple installation process.

The faucet features a drip-free ceramic cartridge, designed for reliable, leak-free performance.



Image Description: A cutaway view of the faucet's base reveals the internal drip-free ceramic cartridge, which is crucial for preventing leaks and ensuring smooth operation of the water flow and temperature control.

OPERATING INSTRUCTIONS

1. Water Flow and Temperature Control

The single handle controls both water flow and temperature. Lift the handle to increase water flow. Move the handle left for hot water and right for cold water. The handle offers 180-degree rotation for precise temperature adjustment.

2. Sprayer Functionality

The faucet features a pull-down sprayer with a 20-inch retractable hose and 360-degree swivel capability, allowing for flexible use around the sink.



Image Description: This image illustrates the faucet's pull-down sprayer in use, extended from the main body. It highlights the 20-inch retractable hose and the 360-degree swivel feature, which allows the sprayer to reach all areas of the sink for convenience.

3. Spray Modes

The sprayer head offers three distinct spray modes, selectable via buttons on the sprayer:

- **Stream Mode:** Provides a steady, aerated flow for filling pots and general washing.
- **Spray Mode:** Delivers a powerful spray for rinsing dishes and cleaning the sink.
- **Pause Mode:** Temporarily stops water flow without turning off the main handle, useful for moving the sprayer between tasks.



Image Description: This image displays the faucet's sprayer head, clearly indicating the three available water modes: Stream, Spray, and Pause. Each mode is represented by an icon, demonstrating the versatility of the sprayer for various kitchen tasks.



Stream



Spray



Pause



Image Description: This composite image visually demonstrates the three spray modes. The top panel shows the 'Stream' mode filling a glass, the middle panel illustrates the 'Spray' mode rinsing a pan, and the bottom panel depicts the 'Pause' mode, where water flow is temporarily halted while holding the sprayer.

MAINTENANCE

1. Cleaning Instructions

To maintain the finish and performance of your WEWE Kitchen Faucet, follow these cleaning guidelines:

- Clean the faucet regularly with a soft cloth and mild soap.

- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish and stainless steel material.
- The faucet is designed to be washable and resistant to dirt and fingerprints, making it easy to wipe down.
- For hard water spots, use a solution of equal parts white vinegar and water, applied with a soft cloth, then rinse thoroughly and dry.



Image Description: This image emphasizes the faucet's construction from 304 Stainless Steel. It features icons representing its anti-dirt, anti-fingerprint, and easy-to-clean characteristics, indicating its durability and low-maintenance design.

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Reduced Water Flow	Clogged aerator or supply lines.	Remove and clean the aerator. Check supply lines for kinks or obstructions.
Leaks from Faucet Base	Loose mounting nut or damaged O-rings.	Tighten the mounting nut underneath the sink. Inspect and replace O-rings if damaged.
Sprayer Does Not Retract Fully	Obstruction under the sink preventing hose movement.	Ensure the hose and counterweight under the sink have enough clear space to move freely. Remove any cleaning supplies or other items obstructing the hose path.
Inconsistent Water Temperature	Issues with water heater or supply line pressure.	Check your water heater settings. Ensure both hot and cold supply valves are fully open.

SPECIFICATIONS

Feature	Detail
Brand	WEWE
Model Number	W100-06-08MB
Manufacturer	Aonecer
Product Dimensions	5.08 x 21.59 x 39.88 cm
Item Weight	1.59 kg
Colour	Matte Black
Finish	Matt
Material	Stainless Steel
Installation Method	Single Hole
Mounting Type	Deck Mount
Item Package Quantity	1
Number of Pieces	1
Flow Rate	1.8 Gallons Per Minute
Number of Holes	3 (Note: Designed for single hole installation, but compatible with 3-hole sinks using an optional deck plate, not included with this model)
Number of Handles	1
Handle Material	Stainless Steel
Special Features	Washable, Anti-dirt, Anti-fingerprint, Easy to clean

Feature	Detail
Included Components	Handle, Instruction Manual, Sprayer
Batteries Included?	No
Batteries Required?	No

WARRANTY INFORMATION

Specific warranty details for the WEWE Kitchen Faucet Model W100-06-08MB are not provided within this manual. For warranty claims or information, please refer to the product packaging or contact WEWE customer support directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to troubleshoot an issue not covered in this manual, please contact WEWE customer support. Contact information can typically be found on the product packaging, the manufacturer's official website, or through your point of purchase.