

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PDDAXLQUE](#) /

› [PDDAXLQUE DX-LR03 433/475MHz RF LoRa Module User Manual](#)

PDDAXLQUE LR03-433/475Mhz

PDDAXLQUE DX-LR03 433/475MHz RF LoRa Module User Manual

Model: LR03-433/475Mhz

1. INTRODUCTION

This manual provides comprehensive instructions for the PDDAXLQUE DX-LR03 433/475MHz RF LoRa Module. It covers product features, setup procedures, operating instructions, and technical specifications to ensure proper use and optimal performance of the module. The DX-LR03 is designed for ultra-long distance LoRa communication, offering robust and reliable data transmission.


2. PRODUCT OVERVIEW

2.1 Key Features

- **Ultra-Long Distance Communication:** Achieves transmission distances up to 10KM in open visibility.
- **Frequency Band:** Supports 433/475MHz communication.
- **High Transmission Power:** Features a PA amplifier with up to 30dBm transmission power.
- **ASR6601 SOC Chip:** Integrated ASR6601 System-on-Chip for efficient operation.
- **UART Serial Port:** Facilitates transparent data transmission via UART serial communication.
- **AT Command Set:** Configurable through a comprehensive set of AT commands for various parameters.
- **Wide Baud Rate Support:** Supports baud rates from 1200 to 128000 bps (Default: 9600bps/8/n/1).
- **Certifications:** CE, FCC, and ROSH certified for safety and reliability.
- **Robust Design:** Equipped with an RF shielding cover, offering strong anti-interference, anti-static, and EMC electromagnetic compatibility.
- **External Antenna Support:** Designed for use with external antennas.

Support Working Mode

(A) Fixed-point transmission



(A) Broadcast transmission




Figure 1: DX-LR03 Module Key Features and Dimensions. This image highlights the ASR6601 SOC chip, UART serial communication, frequency support, output power, receiver sensitivity, operating voltage, module size, and certifications. It also shows the module dimensions and antenna length.

2.2 Main Parameters



LR03 433/475MHz+ Glue stick antenna



Main parameters	Parameter value
Chip type	ASR6601 SOC chip
Hardware interface	LPUART
Operating frequency	LR03 Module:433~475MHz
Firing power	0~+27dBm
Reference distance (km)	Open visibility up to 10km
Receiver sensitivity	-138dBm
Operating voltage	4V-5.5 V(Typical: 5V)
Module Size	43mm*28mm*3.2mm
Antenna Interface	External Antenna

Figure 2: Main Parameters of the DX-LR03 Module. This table details the chip type (ASR6601 SOC), hardware interface (LPUART), operating frequency (433-475MHz), firing power (0~+27dBm), reference distance (up to 10km), receiver sensitivity (-138dBm), operating voltage (4V-5.5V), module size (43mm*28mm*3.2mm), and antenna interface (External Antenna).

3. SETUP AND INSTALLATION

3.1 Module Components






Figure 3: DX-LR03 LoRa Module with an attached antenna. This image shows the compact module with its pin headers and the external antenna connected via an SMA connector.

3.2 Pinout and Connections

The DX-LR03 module features a standard pinout for easy integration. Ensure correct voltage supply and serial communication connections.




Figure 4: DX-LR03 Module Pinout and Interface Details. This image illustrates the traceability ID, indicator light, VCC (3.3-5.5V), GND, AUX (Module RF status indicator pin), M1, M0, RXD, TXD, and the antenna interface. It also shows the module's serial number and certifications.

3.3 Connecting with a USB to TTL Adapter

For initial setup and testing, a USB to TTL adapter can be used to interface the module with a computer. Connect the module's TXD to the adapter's RXD, and the module's RXD to the adapter's TXD. Ensure common ground (GND) and proper power supply (VCC).



LR03 Key Features

- ASR6601 SOC Chip+PA Amplifier
- Uart Serial Communication, Abundant AT commands
- LR03-433T30D: Support 433~475MHz
LR03-900T30D: Support 850~931MHz
- Output power: 0~+27dBm
- Maximum Receiver Sensitivity: -138dBm
- Line-of-sight distance up to 10km
- Operating voltage: 4~5.5V(Typical: 5V)
- Module Size: 43(L) x 28(W) x 3.2(H)mm
- CE, FCC,ROHS certification

Figure 5: USB to TTL Adapter and Wiring Diagram. This image shows a USB to TTL module adapter board and a wiring diagram illustrating how to connect the DX-LR03 module to it for serial communication, indicating connections for VCC, GND, TXD, RXD, M1, M0, and AUX.

4. OPERATING INSTRUCTIONS

4.1 Serial Communication

The DX-LR03 module uses UART serial communication for transparent data transmission. The default baud rate is 9600bps with 8 data bits, no parity, and 1 stop bit (9600/8/N/1). Other supported baud rates include 1200, 2400, 19200, 38400, 57600, 115200, and 128000 bps.

4.2 AT Command Settings

The module's operating parameters can be configured using AT commands. These commands allow setting and querying various aspects such as operating mode, frequency, MAC address, bandwidth, spreading factor, coding rate, and transmission power. Refer to the detailed AT command set documentation for a complete list of commands and their usage.

Easy to Use Complete Data Package

DX-SMART Official Website:

The screenshot shows the 'Product Information' page on the DX-SMART website. On the left, there is a navigation menu with categories like Bluetooth Ibeacon, GNSS Module, Bluetooth module, WiFimodule, LORA module (highlighted), Serial converter, Development tools, and Positioning module. The main content area displays 'Product Information Package' with a list of items: '10KM Communication distance' (highlighted), 'DX-LR03-900MHz', 'DX-LR03-433Mhz', 'LLCC68', 'SX1262', and 'Lora module & MCU case'. To the right, there is a 'Product Information Package' section with two items: 'DX-LR03-900 Data package' and 'DX-LR03-900 documentation Go'. An orange arrow points from the 'DX-LR03-900 Data package' item to a 'Document Download' button.

Product Information

Bluetooth Ibeacon >	5KM Communication distance >
GNSS Module >	10KM Communication distance >
Bluetooth module >	DX-LR03-900MHz
WiFimodule >	DX-LR03-433Mhz
LORA module >	LLCC68 >
Serial converter >	SX1262 >
Development tools >	Lora module & MCU case >
Positioning module >	

Product Information Package

Product Information Package

- DX-LR03-900 Data package
- DX-LR03-900 documentation Go

Document Download

Service Support Video Tutorial Technical Documentation Test tools Hardware Information

- Click the Product Guide and Documentation links below to access user guides, complete product information, and product tutorials

Figure 6: Overview of AT Commands. This image shows a partial AT command table with examples like AT (test), +++ (enter/exit AT command mode), AT+BAUD (set/query baud rate), AT+MAC (set/query device address), AT+MODE (set/query operating mode), AT+SLEEP (set/query power consumption mode), AT+CHANNEL (set/query working channels), and AT+POWE (set/query transmit power).


4.3 Communication Modes

The DX-LR03 module supports different communication modes, including fixed-point transmission and broadcast transmission.

- **Fixed-point transmission:** Data is sent to a specific module identified by its MAC address and channel.
- **Broadcast transmission:** Data is sent to all modules within range on a specified channel, without requiring a specific MAC address.

AT Commands are Easy to Use

- ✓ Command Instructions
- ✓ Setup Instructions
- ✓ Query Instructions



#AT command table	
AT	Test (Response OK)
+ + +	Enter/exit AT command mode
AT+BAUD	Set/query baud rate
AT+MAC	Set/query device address
AT+MODE	Set/query operating mode
AT+SLEEP	Set/query power consumption mode
AT+CHANNEL	Set/query working channels
AT+POWE	Set/query transmit power
...	

Figure 7: Fixed-point and Broadcast Transmission Modes. This diagram illustrates how data is transmitted in both fixed-point (requiring matching MAC and Channel) and broadcast (requiring only matching Channel) modes, showing successful and unsuccessful data reception scenarios.

5. TROUBLESHOOTING

- **No Communication:** Verify power supply, serial port connections (TX/RX cross-over), and baud rate settings. Ensure both modules are configured to the same frequency and communication parameters.
- **Limited Range:** Check antenna connection and placement. Ensure there are no significant obstructions between modules. Verify transmission power settings.
- **Module Not Responding to AT Commands:** Ensure the module is in AT command mode (usually by sending '+++'). Check serial port settings.
- **Interference Issues:** Ensure the module is properly shielded and away from strong electromagnetic interference sources.

6. TECHNICAL SPECIFICATIONS

Parameter	Value
-----------	-------

Parameter	Value
Model Number	LR03-433/475Mhz
Brand	PDDAXLQUE
Chip Type	ASR6601 SOC
Operating Frequency	433/475MHz
Transmission Power	0 ~ +30dBm (with PA amplifier)
Receiver Sensitivity	-138dBm
Communication Distance	Up to 10KM (line-of-sight)
Data Interface	UART Serial Port
Baud Rates	1200, 2400, 9600 (default), 19200, 38400, 57600, 115200, 128000 bps
Operating Voltage	4V - 5.5V (Typical: 5V)
Module Dimensions	43mm (L) x 28mm (W) x 3.2mm (H)
Antenna Interface	External Antenna
Certifications	CE, FCC, ROHS
Manufacturer	DX-SMART

7. SUPPORT AND DOCUMENTATION

PDDAXLQUE provides comprehensive technical support and documentation for the DX-LR03 module. This includes detailed technical documentation, AT command sets, module footprints, reference design schematics, and development/test tools. For further assistance or to access additional resources, please refer to the official product documentation. For technical inquiries or support, please contact the manufacturer through the provided channels in the product documentation or the seller's support information.