

PKBD ZCC213

PKBD ZCC213 Cordless Hair Clippers & Beard Trimmer User Manual

Model: ZCC213 | Brand: PKBD

INTRODUCTION

Thank you for choosing the PKBD ZCC213 Cordless Hair Clippers and Beard Trimmer. This professional grooming set is designed for precise and comfortable hair and beard trimming. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

SAFETY INFORMATION

To reduce the risk of injury, electric shock, fire, or damage to the product, always follow these basic safety precautions:

- Avoid contact with eyes and skin.
- Do not immerse the clipper body in water. The shaver head is detachable and washable, but the main body is not waterproof.
- Keep away from heat sources and open flames.
- Unplug the device when not in use or before cleaning.
- Do not use on infants or children without adult supervision.
- Always follow recommended cleaning and maintenance procedures outlined in this manual.
- Do not operate the device if it has a damaged cord or plug, or if it is not working properly.

PACKAGE CONTENTS

Your PKBD ZCC213 grooming set includes the following items:

- 1 x Cordless Hair Clipper (Main Unit)
- 1 x T-Blade Hair Trimmer
- 6 x Guide Combs (3mm, 6mm, 9mm, 12mm, 16mm, 19mm)
- 1 x USB Charging Cable

- 1 x Cleaning Brush
- 1 x Lubricant Oil Bottle
- User Manual

PRODUCT FEATURES

- **Precision Ceramic Blades:** Sharp, wear-resistant R-angle designed ceramic blades prevent scratches and pulling.
- **Adjustable Taper Lever:** The main clipper features a 5-position adjustable blade head (0.9mm to 2.1mm) for precise length control.
- **Multiple Guide Combs:** Six combs (3mm, 6mm, 9mm, 12mm, 16mm, 19mm) for various hair lengths and styles.
- **Powerful Motor:** High-performance 7000 RPM motor for efficient cutting across all hair types.
- **Quiet Operation:** Operates below 60 decibels for a comfortable grooming experience.
- **Long-Lasting Battery:** Built-in 1800mAh lithium battery (main clipper) provides up to 120 minutes of continuous use on a 3-hour charge. The T-blade trimmer has a 600mAh battery, offering 120 minutes run time on a 90-minute charge.
- **LED Display:** Clear LED display shows remaining battery life and charging status.
- **Safety Protections:** Features overcharge and over-discharge protection to prolong battery life.
- **Cordless & USB Rechargeable:** Offers flexibility and convenience for use anywhere.

SETUP

1. **Initial Charge:** Before first use, fully charge both the main hair clipper and the T-blade trimmer. Connect the USB charging cable to the device and a suitable USB power adapter (not included). The LED display will indicate charging status. A full charge for the main clipper takes approximately 3 hours, and for the T-blade trimmer, about 90 minutes.
2. **Attach Guide Comb:** Select the desired guide comb (3mm, 6mm, 9mm, 12mm, 16mm, or 19mm) and slide it onto the clipper blade until it clicks into place. Ensure it is securely attached.
3. **Adjust Taper Lever (Main Clipper):** For the main clipper, use the adjustable taper lever on the side to fine-tune the cutting length between 0.9mm and 2.1mm.

5-Position

Adjustable Taper Lever
From 0.9mm To 2.1mm



0.9mm



1.2mm



1.5mm



1.8mm



2.1mm



6-Guide Combs



3mm



6mm



9mm



12mm



16mm



19mm



Image: The main hair clipper showing the 5-position adjustable taper lever (0.9mm to 2.1mm) and the six included guide combs (3mm, 6mm, 9mm, 12mm, 16mm, 19mm).



Image: Two hair clippers (main and T-blade trimmer) displaying LED battery levels and charging via USB. Details on battery capacity (1800mAh for main, 600mAh for T-blade), running time (120 min for both), and charging time (180 min for main, 90 min for T-blade) are shown.

OPERATING INSTRUCTIONS

Follow these steps for effective and safe grooming:

- 1. Preparation:** Ensure your hair or beard is clean and dry. Place an apron or towel around your neck and shoulders to catch trimmed hair.
- 2. Power On:** Press the power button to turn on the clipper/trimmer. The LED display will illuminate, showing the battery level.
- 3. Hair Trimming (Main Clipper):**
 - For general hair cutting, use the main clipper with the appropriate guide comb.
 - Start with a longer comb length and gradually reduce it if a shorter cut is desired.
 - Move the clipper against the direction of hair growth for an even cut.
 - Use the adjustable taper lever for blending and precise length transitions.
- 4. Beard Trimming & Detailing (T-Blade Trimmer):**

- The T-blade trimmer is ideal for shaping beards, creating clean lines, trimming sideburns, and intricate hair patterns.
- Use without a comb for close trimming and detailing.
- Hold the trimmer at a slight angle and gently guide it along the desired area.

5. **Post-Trimming:** Once finished, turn off the device. Remove the guide comb and clean the blades.

Simple and Convenient Hair Cutting Steps

Complete Set, No Need to Purchase Additional Accessories







Image: A four-step visual guide demonstrating hair cutting: 1) Put on an apron, 2) Use the large clipper to trim thick hair, 3) Use the small clipper (T-blade) to trim hair around ears/sideburns/beard/carve patterns, 4) Record beautiful moments (implies successful grooming).






Image: Four panels illustrating different applications: Hair Trimming, Beard Shaving, Trimming Sideburns, and Hair Pattern Engraving, showcasing the versatility of the clippers and trimmer.

Professional Hair Clipper and Trimmer Set



Sharp Cutting



No Pulling Hair



7000RPM



Low Noise<60DB




Image: A close-up of the hair clipper in use, emphasizing its features: Sharp Cutting, No Pulling Hair, 7000RPM motor, and Low Noise (<60DB).

MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your clippers:

1. **Cleaning the Blades:** After each use, turn off the clipper/trimmer. Detach the shaver head by gently pushing it forward. Use the included cleaning brush to remove any trapped hair from the blades and the inside of the clipper head.
2. **Washing the Shaver Head:** The detached shaver head is washable. Rinse it under running water. Ensure it is completely dry before reattaching.
3. **Cleaning the Clipper Body:** The main clipper body is **not waterproof**. Use a dry cloth to wipe down the body. Do not rinse or immerse the body in water.
4. **Oiling the Blades:** Periodically, apply a small drop of the included lubricant oil to the blades. Turn on the clipper for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.
5. **Storage:** Store the clippers and all accessories in a dry, cool place, away from direct sunlight and moisture.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or no charge.	Charge the clipper fully using the USB cable. Check the LED display for battery status.
Clipper pulls hair or cuts unevenly.	Blades are dull, dirty, or not oiled. Hair is too thick or wet.	Clean and oil the blades. Ensure hair is dry. Try a slower cutting speed. If blades are dull, consider replacement (contact support).
Reduced battery life.	Battery not fully charged or aging.	Ensure a full charge cycle. Avoid over-discharging frequently. Battery life naturally diminishes over time.
Excessive noise or vibration.	Blades are not properly aligned or need oiling.	Clean and oil the blades. Ensure the shaver head is securely reattached.

SPECIFICATIONS

Feature	Detail
Brand	PKBD
Model Number	ZCC213
Power Source	Battery Powered (USB Rechargeable)
Blade Material	Ceramic
Motor Speed	7000 RPM
Noise Level	Below 60 dB
Main Clipper Battery Capacity	1800 mAh Lithium Battery
Main Clipper Run Time	Up to 120 minutes
Main Clipper Charging Time	Approximately 3 hours
T-Blade Trimmer Battery Capacity	600 mAh Lithium Battery
T-Blade Trimmer Run Time	Up to 120 minutes
T-Blade Trimmer Charging Time	Approximately 90 minutes
Adjustable Taper Lever	0.9mm - 2.1mm (5 positions)
Guide Comb Lengths	3mm, 6mm, 9mm, 12mm, 16mm, 19mm
Target Audience	Men
Product Dimensions	21.4 x 12.3 x 8.3 cm; 300 grams (Shipping dimensions)

WARRANTY AND SUPPORT

This product is designed for durability and performance. For any warranty claims, technical support, or inquiries not covered in this manual, please contact the retailer or manufacturer's customer service. Please retain your proof of purchase for warranty purposes.

OFFICIAL PRODUCT VIDEOS

No official seller videos were provided for this product.
