**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Bellemave FST00229-T-AN1**

# Bellemave Twin Loft Bed with Desk (Model FST00229-T-AN1) Instruction Manual

Your guide to safe assembly, use, and maintenance.

## 1. Important Safety Information

Please read and understand all instructions before assembling and using this product. Failure to follow these warnings could result in serious injury.

- Always use the ladder to climb up and down the loft bed. Do not jump or climb over the guardrails.
- Adult supervision is recommended when children are using the loft bed.
- Be cautious of pinch points when assembling the bed.
- Ensure all connections are tight before use. Periodically check and tighten all fasteners.
- The loft bed is designed for a twin-size mattress. Do not use a mattress thicker than recommended by safety standards to ensure guardrail effectiveness.
- Do not attach or suspend items from any part of the loft bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, or jump ropes.

## 2. Assembly Instructions

The Bellemave Twin Loft Bed with Desk is designed for convenient assembly. It is delivered in one package and includes a detailed installation manual and all necessary hardware.

### 2.1 Before You Begin

- Unpack all components and verify against the parts list provided in the separate assembly manual.
- Ensure you have adequate space for assembly.
- Keep children and pets away from the assembly area.
- Two adults are recommended for assembly.

### 2.2 Assembly Steps

Refer to the dedicated assembly manual included in your package for step-by-step instructions, diagrams, and a

complete parts list. Follow the instructions carefully to ensure proper and safe construction.





**Figure 1:** Dimensions of the Bellemave Twin Loft Bed with Desk. Overall dimensions are approximately 78.6"L x 43.4"W x 66.5"H.



**Figure 2:** Front view of the assembled Bellemave Twin Loft Bed with Desk, showcasing the bed frame and integrated desk.

## 3. Operating Instructions

### 3.1 Using the Loft Bed

- Access the bed using the integrated ladder. Always face the ladder when climbing up or down.
- Ensure the mattress fits snugly within the bed frame to prevent gaps.
- The high guard rails are designed for safety. Do not remove or modify them.

### 3.2 Using the Integrated Desk

The spacious area underneath the loft bed includes a desk, providing a dedicated space for study, reading, or other activities. The desk is designed to support standard study materials and light electronics.



**Figure 3:** Detail view of the integrated desk and ladder, highlighting the functional design.



**Figure 4:** The Bellemave Twin Loft Bed with Desk integrated into a room, demonstrating its use as both a sleeping and study area.

## 4. Care and Maintenance

### 4.1 Cleaning

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the wood finish.
- For spills, wipe immediately with a dry cloth.

### 4.2 Structural Integrity

- Periodically check all bolts, screws, and fasteners to ensure they are tight. Re-tighten as necessary to maintain stability and safety.
- Inspect the wooden frame for any signs of damage, cracks, or splinters. Address any issues promptly to prevent further damage or injury.



**Figure 5:** Detail of the bed slats, showing the support structure for the mattress. Ensure these are securely in place.

## 5. Troubleshooting

### 5.1 Bed Feels Wobbly

- **Check all fasteners:** Ensure all bolts and screws are fully tightened. Loose connections are the most common cause of wobbling.
- **Verify assembly:** Double-check that all parts are assembled according to the instruction manual. Incorrectly installed components can affect stability.
- **Level surface:** Ensure the bed is placed on a flat, level surface. Uneven flooring can cause instability.
- **Wall attachment (optional):** For added stability, consider securing the bed frame to a wall using appropriate brackets and hardware (not included). Consult a professional if unsure.

### 5.2 Missing or Damaged Parts

- If you find any parts missing or damaged upon opening the package, do not proceed with assembly.
- Contact Bellemave customer support immediately with your product model number (FST00229-T-AN1) and a description of the issue.

## 6. Product Specifications

| | |
|---|---|
| **Brand** | Bellemave |
| **Model Number** | FST00229-T-AN1 |
| **Size** | Twin |
| **Product Dimensions (L x W x H)** | 78.6" x 43.4" x 66.5" |
| **Color** | Natural With a Desk |
| **Material** | Wood (Premium Rubber Wood) |
| **Finish Type** | Lacquered |
| **Special Feature** | Integrated Desk |
| **Included Components** | Bed Frame, Desk, Guardrails, Slats, Ladder |
| **Compatible Mattress Size** | Twin |
| **Assembly Required** | Yes |
| **Item Weight** | 48 pounds |

## 7. Customer Support

For any questions regarding assembly, missing parts, or product issues, please contact Bellemave customer support. Have your product model number (FST00229-T-AN1) ready for faster assistance.

You can typically find contact information on the Bellemave official website or through your purchase platform.

© 2025 Bellemave. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0FGJCQMT6**

More documents and user manuals: **https://manuals.plus/**