

[manuals.plus](#) /

› [Music Sound](#) /

› [Music Sound DRIFT Wireless In-Ear Earbuds User Manual \(Model BTMSTWSDRIFTB\)](#)

## Music Sound BTMSTWSDRIFTB

# Music Sound DRIFT Wireless In-Ear Earbuds User Manual

Model: BTMSTWSDRIFTB

## 1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Music Sound DRIFT Wireless In-Ear Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.

## 2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Music Sound DRIFT Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Guide
- Multiple sizes of ear tips (S, M, L)

# PACK CONTENT




Image: Contents of the Music Sound DRIFT Earbuds package, including the earbuds, charging case, USB-C cable, user guide, and various ear tip sizes.

## 3. PRODUCT OVERVIEW

The Music Sound DRIFT earbuds feature an in-ear design for a secure fit and immersive audio. The compact charging case provides extended battery life and easy portability.



Image: The Music Sound DRIFT wireless earbuds resting in their open blue charging case, showcasing the sleek design and LED indicators on the case.

## Key Features:

- **In-Ear Design:** Ensures a comfortable and stable fit for extended listening.

- **Compact Charging Case:** Easy to carry, providing additional charges on the go.
- **Bluetooth Connectivity:** Wireless audio experience with auto-pairing functionality.
- **Touch Controls:** Manage music playback, calls, and voice assistant directly from the earbuds.
- **Extended Playtime:** Up to 22 hours of total battery life with the charging case.




Image: Diagram illustrating the touch control areas on the earbuds for functions like calls, volume, and track navigation, along with the LED battery level indicator.

## 4. SETUP

### 4.1 Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included).
3. The LED indicators on the case will illuminate to show charging status. A full charge typically takes approximately 2 hours.
4. Once fully charged, disconnect the charging cable.

## 4.2 Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "Music Sound DRIFT" in the list of available Bluetooth devices.
5. Select "Music Sound DRIFT" to connect. Once connected, the earbud indicator lights will stop flashing.
6. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power On/Off

- **Power On:** Open the charging case, or long-press the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch control area on both earbuds for 5 seconds.

### 5.2 Touch Controls

The Music Sound DRIFT earbuds feature intuitive touch controls. Refer to the diagram below for common functions:

Function	Action
Play/Pause Music	Single tap on either earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Activate Voice Assistant	Triple tap on either earbud

### 5.3 Charging the Earbuds and Case

The earbuds provide up to 5 hours of playback on a single charge, and the charging case extends the total playtime to 22 hours.

# ALL DAY PLAY-TIME!

22

HOURS

with  
charging  
case



5

HOURS

single charge

Image: Graphic illustrating the total playtime of 22 hours with the charging case and 5 hours on a single earbud charge.

- **Charging Earbuds:** Place them into the charging case. They will charge automatically.
- **Charging Case:** Connect the USB-C cable to the case and a power source. The LED indicators on the case show the charging status.

## 6. MAINTENANCE

### 6.1 Cleaning

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure the charging contacts on both the earbuds and the case are clean and dry.

### 6.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store the product in a cool, dry place, away from extreme temperatures and direct sunlight.

## 7. TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Music Sound DRIFT" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, then open it again. Ensure both earbuds are charged.
No sound	Check device volume. Ensure earbuds are properly connected. Try re-pairing.
Charging case not charging	Check USB-C cable connection and power adapter. Try a different cable or power source.





## 8. SPECIFICATIONS

Feature	Detail
Model Name	BTMSTWSDRIFTB
Brand	Music Sound
Connectivity Technology	Wireless (Bluetooth 5)
Form Factor	In-Ear
Control Method	Touch
Total Playtime (with case)	Up to 22 Hours
Earbud Playtime (single charge)	Up to 5 Hours
Charging Interface	USB-C
Material	Plastic
Weight	140 g (product)
Color	Blue

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official Music Sound website. Keep your proof of purchase for warranty claims.

### Related Documents - BTMSTWSDRIFTB

	<p><a href="#"><b>DRIFT FLOW WIRELESS EARPHONES - Music Sound</b></a></p> <p>Explore the Music Sound DRIFT FLOW WIRELESS EARPHONES, featuring an immersive in-ear design, up to 22 hours of playtime, auto-pairing, and a compact, colorful case. Available in multiple colors with product codes and EANs.</p>
	<p><a href="#"><b>Music Sound FANTASY Wireless Headphones - Bluetooth On-Ear Headset</b></a></p> <p>Discover the Music Sound FANTASY wireless on-ear headphones. Featuring Bluetooth connectivity, 22H playtime, comfortable padded headband, swivel earcups, and built-in microphone. Available in multiple colors.</p>
	<p><a href="#"><b>Music Sound MAXI 2 Bluetooth Headphones User Guide and Specifications</b></a></p> <p>Comprehensive guide to the Music Sound MAXI 2 Bluetooth headphones, covering setup, features, technical specifications, safety information, and compliance.</p>
	<p><a href="#"><b>Music Sound Basic Bluetooth Headphones User Manual</b></a></p> <p>This manual provides instructions for using the Music Sound Basic Bluetooth headphones, including setup, operation, and technical specifications. It covers pairing, charging, and safety information.</p>
	<p><a href="#"><b>Music Sound GROOVE True Wireless Earbuds - User Manual &amp; Specifications</b></a></p> <p>Comprehensive guide to Music Sound GROOVE True Wireless Stereo earbuds, covering features, touch controls, technical specifications, safety guidelines, warranty, and disposal information.</p>
	<p><a href="#"><b>Music Sound Breeze Bluetooth Earbuds User Manual</b></a></p> <p>This manual provides instructions and technical specifications for the Music Sound Breeze Bluetooth earbuds, including setup, usage, safety information, and disposal guidelines.</p>