

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SACOSDING](#) /
- › [SACOSDING Quartz Watch LG89155-Steel Strip Black User Manual](#)

SACOSDING LG89155-Steel Strip Black

SACOSDING Quartz Watch LG89155-Steel Strip Black User Manual

Model: **LG89155-Steel Strip Black** | Brand: **SACOSDING**

INTRODUCTION

This manual provides essential instructions for the SACOSDING LG89155-Steel Strip Black Quartz Watch. Please read carefully to ensure proper setup, operation, and maintenance of your timepiece. This watch features a precise quartz movement, a durable stainless steel strap, and 3ATM water resistance.



Figure 1: SACOSDING LG89155-Steel Strip Black Quartz Watch

SETUP

Setting Time and Date

1. To adjust the **date**, gently pull the crown out to the **first position**. Rotate the crown clockwise or counter-clockwise until the desired date is displayed in the date window.
2. To adjust the **time** (hour and minute hands), gently pull the crown out to the **second position**. Rotate the crown to move the hands to the correct time.
3. Once the time and date are set, push the crown back in fully to its original position to start the watch and ensure water resistance.

FUNCTION DESCRIPTION



Figure 2: Crown Positions for Time and Date Adjustment

Adjusting the Watch Band

The stainless steel strap can be adjusted to fit your wrist by adding or removing links. A link adjustment tool is typically provided with your watch. Follow the instructions below or refer to the accompanying video for guidance.

1. Identify the pins on the side of the watch band links that need to be removed.
2. Place the band in the link adjustment tool, aligning the tool's pin with the watch band pin.
3. Gently turn the tool's handle to push the pin out.
4. Remove the desired number of links.
5. Reassemble the band by inserting the pins back into the links, ensuring they are securely in place.



Figure 3: Watch Band Adjustment Diagram

Your browser does not support the video tag.

Video 1: Overview of the Classic Steel Band Luminous Waterproof Men's Formal Watch, including its features and band. This video is provided by the seller.

OPERATING INSTRUCTIONS

Luminous Features

The watch dial and hands are equipped with luminous material for visibility in low-light conditions. To activate this feature, expose the watch to a strong light source (such as natural sunlight or artificial light) for approximately 30 seconds. The luminous elements will then glow in the dark.



Figure 4: Luminous Dial in Dark Conditions

Water Resistance

This watch is rated 3ATM water resistant. This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water (e.g., hand washing). It is **not suitable** for bathing, swimming, diving, or any activities involving prolonged water exposure or high-pressure water. Always ensure the crown is fully pushed in when the watch is exposed to water.

3ATM WATER RESISTANT



Figure 5: Watch Demonstrating Water Resistance

MAINTENANCE

- **Cleaning:** Regularly wipe the watch case and strap with a soft, dry, lint-free cloth to remove dust, sweat, and fingerprints. For the stainless steel strap, a slightly damp cloth can be used, followed by a dry cloth.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, strap, or internal components.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect the movement and seals.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as these can interfere with the quartz movement's accuracy.
- **Crown Position:** Always ensure the crown is fully pushed in after adjusting the time or date to maintain the watch's water resistance.

TROUBLESHOOTING

- **Watch Not Running:**

- Ensure the crown is fully pushed in.
 - If the watch is new, check for and remove any plastic battery stopper under the crown.
 - The battery may need replacement. Consult a professional watch repair service.
- **Date Not Changing Correctly:**
 - Ensure the time is set correctly, passing midnight to trigger the date change.
 - Manually adjust the date by pulling the crown to the first position and rotating it until the correct date is displayed.
- **Weak Luminous Glow:**
 - The luminous material requires exposure to light to charge. Expose the watch to a strong light source (natural or artificial) for at least 30 seconds.

SPECIFICATIONS

Model Number	LG89155-Steel Strip Black
Brand	SACOSDING
Movement	Quartz
Case Diameter	42mm
Case Thickness	12mm
Strap Material	Stainless Steel
Strap Width	24mm
Water Resistance	3ATM (Splash/Rain Resistant)
Clasp Type	Foldover Clasp With Push Button
Battery	1 Nonstandard Battery (included)
Item Weight	9.28 ounces

PRODUCT PARAMETERS



Figure 6: Product Parameters and Dimensions

WARRANTY

This product is covered by a standard manufacturer's warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the warranty card or documentation included in your product packaging. Alternatively, you may visit the official SACOSDING website for more information.

SUPPORT

Should you require further assistance, have questions about your watch, or need to report an issue, please contact SACOSDING customer service. Contact information can typically be found on the product packaging, the warranty card, or the official SACOSDING brand website. Please have your model number (LG89155-Steel Strip Black) and purchase details ready when contacting support.