

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WANBO](#) /

› [WANBO Mozart 1 Pro 4K Smart Projector User Manual](#)

WANBO Mozart 1 Pro

WANBO Mozart 1 Pro 4K Smart Projector User Manual

Model: Mozart 1 Pro

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your WANBO Mozart 1 Pro 4K Smart Projector. Please read this manual thoroughly before using the product and retain it for future reference. The Mozart 1 Pro features Google TV, 1200 ANSI lumens brightness, HDR10 support, 4K input capability, and advanced image correction technologies.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the projector and ensure user safety:

- **Power Supply:** Use only the provided power adapter. Ensure the voltage matches your local power supply.
- **Ventilation:** Do not block ventilation openings. Maintain adequate space around the projector for proper airflow to prevent overheating.
- **Eye Safety:** Do not look directly into the projector lens when the lamp is on. The bright light can cause eye damage.
- **Water and Moisture:** Keep the projector away from water, rain, and excessive humidity. Do not operate with wet hands.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Avoid liquid or aerosol cleaners.
- **Placement:** Place the projector on a stable, level surface. Avoid placing it in direct sunlight or near heat sources.
- **Servicing:** Do not attempt to repair the projector yourself. Refer all servicing to qualified personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Mozart 1 Projector
- Remote Control
- User Manual (this document)
- Power Cord
- Power Adapter

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your projector.



Figure 4.1: Front view of the WANBO Mozart 1 Pro projector with its remote control. The projector features a large lens, front grille, and a sensor. The remote control has navigation buttons, volume controls, and dedicated app buttons.

AI-Powered

Done in the blink of an eye



Auto Focus



Auto Keystone Correction



Auto Screen Fit



Intelligent Obstacle Avoidance

Figure 4.2: Diagram illustrating the internal 20W frequency speakers and 660cc sound chamber, designed for immersive audio performance.

Mozart 1 Pro 2025

Google TV x NETFLIX

▶ YouTube Hey Google

prime video

Google Play



Widevine DRM L1



Figure 4.3: Detailed view of the PixelPro 5.0 full closed optical engine, highlighting its components including the lens system and cooling fans, which contribute to increased light transmission and improved clarity.

5. SETUP

5.1 Initial Connection

- Power Connection:** Connect the power adapter to the projector's DC input port, then plug the power cord into an electrical outlet.
- Power On:** Press the power button on the projector or the remote control to turn on the device.

5.2 Google TV Setup

Upon first power-on, you will be guided through the Google TV setup process:

- Language Selection:** Choose your preferred language.
- Network Connection:** Connect to your Wi-Fi network (2.4G or 5G).
- Google Account Login:** Sign in with your Google account to access Google TV features, apps, and personalized recommendations.

- **App Installation:** Follow on-screen prompts to install essential streaming applications.




Figure 5.1: The Google TV interface displaying various streaming applications such as Disney+, Netflix, Hulu, HBO, Prime Video, and YouTube, indicating access to a wide range of content.

5.3 Placement and Image Adjustment

Position the projector to achieve the desired screen size and clarity.

- **Distance:** Adjust the projector's distance from the projection surface to change the image size.
- **Auto Focus:** The projector features automatic focus adjustment. If the image appears blurry, the system will typically correct it automatically.
- **Auto Keystone Correction:** The projector automatically corrects trapezoidal distortion when placed at an angle.
- **Auto Screen Fit:** The projector can automatically adjust the image to fit the screen boundaries.
- **Intelligent Obstacle Avoidance:** The projector can detect and avoid obstacles on the projection surface.

Immerse Yourself in Sound

20W

Frequency Speakers

External
Sound wave

660CC

Sound chamber



Figure 5.2: Visual representation of the AI-powered image adjustment features: Auto Focus, Auto Keystone Correction, Auto Screen Fit, and Intelligent Obstacle Avoidance, ensuring a clear and properly aligned image.

6. OPERATING INSTRUCTIONS

6.1 Remote Control Functions

The remote control allows full navigation and control of the projector's features.

- **Power Button:** Turns the projector on/off.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and selects options.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Returns to the Google TV home screen.
- **Volume Buttons (+/-):** Adjusts the audio volume.
- **Google Assistant Button:** Activates voice control.
- **Dedicated App Buttons:** Quick access to popular streaming services (e.g., Netflix, YouTube).

6.2 Google TV Navigation

From the Google TV home screen, you can:

- Browse and launch installed applications.
- Access personalized content recommendations.
- Search for movies, shows, and apps using the search function or Google Assistant.
- Manage device settings (network, display, sound, system).

6.3 Connectivity

The projector offers various connectivity options:

- **Wi-Fi (2.4G/5G):** For internet access and streaming. Configure in the network settings.
- **Bluetooth:** Connect external Bluetooth speakers, headphones, or other compatible devices. Pair devices via the Bluetooth settings menu.
- **HDMI 2.0:** Connect external devices such as gaming consoles, Blu-ray players, or laptops.
- **USB:** Play media files from a USB drive or power a streaming stick.
- **3.5mm Audio Jack:** Connect wired headphones or external speakers.
- **Chromecast Built-in:** Cast content directly from your phone, tablet, or computer to the projector.

PixelPro 5.0

Full closed optical machine

60% 

Increased light transmission

35% 

Improved clarity

30000H+

Light source life



Figure 6.1: The projector's connectivity options, including HDMI, USB, DC input, and headphone jack, shown with examples of connected devices like a laptop and a gaming console.

6.4 Voice Control with Google Assistant

Use the Google Assistant button on your remote to control the projector and search for content using voice commands.

- Press the Google Assistant button on the remote.
- Speak clearly into the remote's microphone.
- Examples: "Open Netflix," "Play [movie title]," "Increase volume," "What's the weather?"




Figure 6.2: An illustration of users interacting with the projector via Google Assistant voice commands, demonstrating hands-free control for opening applications like Netflix.

6.5 Atmosphere Wall Mode

Explore the Atmosphere Wall Mode feature to project creative ambient visuals, transforming your space with dynamic backgrounds and scenes. Access this mode through the Google TV interface.

7. MAINTENANCE

7.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses. Gently wipe the lens surface to remove dust or smudges. Avoid abrasive materials or harsh chemicals.

7.2 Cleaning the Exterior

Wipe the projector's exterior with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use solvents or abrasive cleaners.

7.3 Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Consider using the original packaging for protection.

8. TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
No Power	Power cord not connected; Power outlet faulty; Projector off.	Ensure power cord is securely connected. Test outlet with another device. Press power button on projector or remote.
No Image	Input source incorrect; Lens cap on; Projector in standby.	Select correct input source (HDMI, Google TV). Remove lens cap. Wake projector from standby.
Poor Image Quality (Blurry/Distorted)	Out of focus; Keystone not adjusted; Lens dirty.	Allow auto-focus to adjust. Ensure auto-keystone is enabled or manually adjust. Clean the projector lens.
No Sound	Volume too low; Muted; External audio device not connected.	Increase volume. Unmute. Check external audio connections (Bluetooth, 3.5mm).
Remote Control Not Working	Batteries low/dead; Obstruction; Remote not paired.	Replace batteries. Remove obstructions between remote and projector. Re-pair remote if necessary (refer to Google TV settings).
Wi-Fi/Bluetooth Connectivity Issues	Network signal weak; Incorrect password; Device out of range.	Move projector closer to router. Re-enter Wi-Fi password. Ensure Bluetooth device is in pairing mode and within range.

9. SPECIFICATIONS

Feature	Detail
Brand	WANBO
Model Number	Mozart 1 Pro 2025
Display Resolution	1920 x 1080 (Native 1080P)
4K Support	Yes (4K input supported)
Brightness	1200 ANSI Lumens
HDR Support	HDR10

Feature	Detail
Operating System	Google TV
Connectivity	Bluetooth, HDMI, USB, Wi-Fi (2.4G/5G)
Special Features	Auto Focus, Auto Keystone, MEMC Motion Smoothing, Google Assistant, Chromecast Built-in, Atmosphere Wall Mode, PixelPro 5.0 Optical Engine
Audio	Dual 20W Full-range Speakers, 660cc Sound Chamber, DSP Processing
Light Source Life	30,000+ hours
Product Dimensions	6.9 x 8.2 x 8.7 inches
Item Weight	7.2 pounds
Power Voltage	100-240V

10. WARRANTY AND SUPPORT

WANBO provides comprehensive customer support for the Mozart 1 Pro projector:

- **Customer Support:** 24/7 after-sales customer support.
- **Money-Back Guarantee:** 2-YEAR money-back guarantee.
- **Repair Coverage:** 3-YEAR repair coverage.
- **Technical Support:** Lifetime technical support.

For further assistance, please refer to the quick start guide included with your product or contact WANBO customer service. Contact details can typically be found on the official WANBO website or in the product packaging.

Related Documents - Mozart 1 Pro

 <p>Projector Mozart 1 Pro User Manual + Assembly Guide + Remote Control</p>	<p><u>Wanbo Mozart 1 Pro Projector User Manual</u></p> <p>Comprehensive user manual for the Wanbo Mozart 1 Pro Smart Projector, covering safety precautions, installation, operation, and adjustments. Includes information in English, Czech, Slovak, Hungarian, and German.</p>
 <p>X5 User Manual + Assembly Manual Wlanerungsanleitung + Benutzerhandbuch</p>	<p><u>Wanbo X5 Projector User Manual - Setup and Operation Guide</u></p> <p>Comprehensive user manual for the Wanbo X5 projector, covering setup, operation, maintenance, and safety precautions. Learn how to connect devices, adjust settings, and care for your projector.</p>
	<p><u>Wanbo Projector Mozart 1 Introduction Manual</u></p> <p>This introduction manual provides essential information for the Wanbo Projector Mozart 1, covering setup, safety guidelines, features, technical specifications, and connectivity options.</p>
 <p>Portable Projector TT User Manual/Manual de usuario</p>	<p><u>Wanbo TT Portable Projector User Manual</u></p> <p>User manual for the Wanbo TT portable projector by Wanbo, providing setup, operation, specifications, and troubleshooting guides. Available in English and Spanish.</p>
 <p>wanbo T2 Max 1080P Mini LED Projector Instruction Manual User Manual / Manual de usuario</p>	<p><u>Wanbo T2 Max 1080P Mini LED Projector Instruction Manual</u></p> <p>Comprehensive instruction manual for the Wanbo T2 Max 1080P Mini LED Projector, covering setup, operation, troubleshooting, specifications, and warranty information.</p>
 <p>wanbo T2 Max 1080P Mini LED Projector Instruction Manual User Manual / Manual de usuario</p>	<p><u>Wanbo T2 Max 1080P Mini LED Projector Instruction Manual - User Guide</u></p> <p>Comprehensive instruction manual for the Wanbo T2 Max 1080P Mini LED Projector, covering setup, operation, troubleshooting, specifications, and warranty information.</p>

