

Logitech M196

Logitech M196 Bluetooth Wireless Mouse User Manual

Model: M196

INTRODUCTION

This manual provides instructions for setting up, operating, and maintaining your Logitech M196 Bluetooth Wireless Mouse. The M196 is a compact and portable mouse designed for seamless Bluetooth connectivity with laptops, tablets, and other compatible devices.



Image: Top view of the Logitech M196 Bluetooth Wireless Mouse in Graphite color.

WHAT'S IN THE BOX

Upon unboxing your Logitech M196 mouse, verify that all components are present:

- Logitech M196 Wireless Mouse
- 1 AA Battery (pre-installed)
- User Documentation

In the box



Image: The Logitech M196 mouse and a single AA battery, illustrating the contents included in the product packaging.

SETUP

1. Powering On and Battery Check

The Logitech M196 mouse comes with one AA battery pre-installed. To activate the mouse:

1. Locate the ON/OFF switch on the bottom of the mouse.
2. Slide the switch to the 'ON' position.

2. Bluetooth Pairing

The M196 connects wirelessly via Bluetooth, requiring no USB receiver.

1. Ensure the mouse is powered on.

2. On the bottom of the mouse, locate the Bluetooth pairing button (often indicated by a Bluetooth symbol).
3. Press and hold the pairing button for a few seconds until the LED indicator on the mouse begins to blink, signifying it is in pairing mode.
4. On your computer, tablet, or smartphone, navigate to the Bluetooth settings.
5. Search for new devices. The mouse should appear as 'Logitech M196'.
6. Select 'Logitech M196' to complete the pairing process. The LED on the mouse will stop blinking and remain solid for a moment, then turn off, indicating a successful connection.




Image: The Logitech M196 mouse positioned on a wooden desk, highlighting its Bluetooth connectivity feature for easy pairing.



Image: An annotated diagram of the Logitech M196 mouse, pointing out key features such as the ON/OFF switch, long-press pairing mode button, and battery compartment.

OPERATING THE MOUSE

The Logitech M196 mouse offers standard three-button functionality with a scroll wheel for navigation.

- **Left Click:** Primary selection and interaction.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls vertically through documents and web pages. The scroll wheel also functions as a middle click button.

The optical tracking technology provides smooth and accurate cursor control on various surfaces.

Easy navigation, precise control




Image: A hand operating the Logitech M196 mouse on a wooden desk, demonstrating its comfortable design and ease of use for navigation.

MAINTENANCE

Battery Replacement

The Logitech M196 mouse is designed for a 12-month battery life under typical usage conditions. When the mouse performance degrades or it stops responding, it's time to replace the battery.

1. Turn the mouse OFF using the switch on the bottom.
2. Locate the battery compartment cover on the bottom of the mouse.
3. Slide or lift the cover to open the compartment.
4. Remove the old AA battery.
5. Insert a new AA battery, ensuring correct polarity (+/-).
6. Replace the battery compartment cover.
7. Turn the mouse ON.

Quality you can rely on




Image: The Logitech M196 mouse positioned beside a laptop, highlighting its extended 12-month battery life for reliable use.

Cleaning

To maintain optimal performance and hygiene, clean your mouse periodically:

- Use a soft, lint-free cloth lightly dampened with water or an alcohol-based cleaner.
- Avoid harsh chemicals or abrasive materials.
- Gently wipe the exterior of the mouse.
- For the optical sensor, use a dry cotton swab to carefully remove any dust or debris.

TROUBLESHOOTING

Mouse Not Connecting or Responding

- **Check Power:** Ensure the mouse is turned ON.
- **Check Battery:** Replace the AA battery if the mouse is unresponsive.
- **Re-pair Bluetooth:** Go to your device's Bluetooth settings, remove the 'Logitech M196' if listed, and then re-initiate the pairing process as described in the Setup section.
- **Device Bluetooth:** Ensure Bluetooth is enabled on your computer or device.

- **Interference:** Move the mouse closer to your device and away from other wireless devices that might cause interference.

Erratic Cursor Movement

- **Clean Sensor:** Clean the optical sensor on the bottom of the mouse.
- **Surface:** Use the mouse on a clean, non-reflective, and uniform surface. Avoid glass or highly reflective surfaces.
- **Battery Level:** A low battery can sometimes cause erratic behavior. Replace the battery.

SPECIFICATIONS

Model Name	M196
Connectivity Technology	Bluetooth
Movement Detection	Optical
Product Dimensions	3.9 x 2.36 x 0.1 inches (100 x 60 x 38 mm)
Item Weight	2.65 ounces (76 g) with battery
Batteries Required	1 AA battery
Battery Life	Up to 12 months (may vary based on usage)
Special Features	Lightweight, Portable, Wireless, Ambidextrous Design



Image: A technical diagram illustrating the dimensions of the Logitech M196 mouse in both millimeters and inches, along

with its weight.

WARRANTY INFORMATION

Logitech products are manufactured to high quality standards. For detailed warranty information regarding your Logitech M196 Bluetooth Wireless Mouse, please refer to the warranty card included in your product packaging or visit the official Logitech support website.





SUPPORT


For further assistance, technical support, or to access drivers and software, please visit the official Logitech support page:

[Logitech Support Website](#)

© 2025 Logitech. All rights reserved.

Related Documents - M196

	<p>Logitech M535 Bluetooth Mouse: Features, Setup, and Compatibility Guide</p> <p>Discover the Logitech M535 Bluetooth Mouse. This guide covers its features, Bluetooth connection steps, customization with Logitech Options software, and compatibility with Windows, Mac OS, Chrome OS, and Android devices.</p>
	<p>Logitech Marathon Mouse M705: Getting Started Guide & Features</p> <p>Comprehensive guide to setting up and using the Logitech Marathon Mouse M705, including features, troubleshooting, and Unifying receiver setup.</p>
	<p>Logitech LIFT Vertical Ergonomic Mouse User Guide and Setup</p> <p>Comprehensive guide to setting up, connecting, and using the Logitech LIFT Vertical Ergonomic Mouse. Learn about its features like SmartWheel, Easy-Switch, and Logitech Flow.</p>
	<p>Logitech M337 Bluetooth Mouse: Features, Setup, and Compatibility Guide</p> <p>A comprehensive guide to the Logitech M337 Bluetooth Mouse, detailing its features, setup process, gesture controls, power management, and system compatibility for Windows, macOS, Chrome OS, and Android devices.</p>

<div data-bbox="165 107 261 336"><p>MX ERGO S</p><p>Setup Guide</p><p>Guide of Installation</p><p>设置指南</p></div>  <p>logitech</p>
--