



Manuals.plus /

› AMZASA /

› AMZASA AS9027-4AB Plug-in Crystal Chandelier Instruction Manual

AMZASA AS9027-4AB

AMZASA AS9027-4AB Plug-in Crystal Chandelier Instruction Manual

Model: AS9027-4AB | Brand: AMZASA

INTRODUCTION

Thank you for purchasing the AMZASA AS9027-4AB Plug-in Crystal Chandelier. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before installation and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Always disconnect power before installation, cleaning, or maintenance.
- This product is intended for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.
- Use only E12 base bulbs, maximum 40W per bulb (bulbs not included).
- If using a dimmer switch, ensure bulbs are dimmable and compatible with the switch.
- Handle glass crystals with care to prevent breakage.
- Keep packaging materials away from children.
- If you are unsure about any part of the installation, consult a qualified electrician.

PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Chandelier Frame with 4 E12 Sockets
- Glass Crystal Strings (various sizes and shapes, labeled A, B, C, D, E, F)
- Glass Decorative Saucers
- Power Cord with In-line ON/OFF Switch
- Hanging Chain
- Ceiling Hook

- Cable Management Clips
- Mounting Hardware (screws, anchors)



Figure 1: Chandelier Components Overview

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps to assemble and install your AMZASA Plug-in Crystal Chandelier. It is recommended to wear the provided gloves to avoid fingerprints on the crystals. Refer to the assembly video for visual guidance on each step.

Your browser does not support the video tag.

Video: AMZASA Plug-in Crystal Chandelier Assembly Guide. This video demonstrates the complete assembly process from unboxing to final installation.

Step 1: Prepare Components

Carefully unbox all components and lay them out on a clean, soft surface. Identify the different crystal types (A, B, C, D, E, F) as shown in the video.

Step 2: Assemble Crystal Saucers (A Crystals)

Attach the 'A' crystals to the small holes around the edge of the glass decorative saucers. Ensure they are securely fastened.

Step 3: Attach Top Crystal Chains (B Crystals)

Connect the 'B' crystal chains between the top center part of the chandelier frame and the light bulb sockets. There are four 'B' chains for the four arms.

Step 4: Attach Arm Crystal Chains (C Crystals)

Attach the 'C' crystal chains to the arms of the chandelier, connecting them from one arm to the central base. Ensure even distribution.

Step 5: Attach Bottom Center Crystals (E Crystals)

Secure the 'E' crystals to the bottom center of the chandelier frame. These are typically shorter, individual crystal drops.

Step 6: Attach Saucer Crystals (F Crystals)

Attach the 'F' crystals to the bottom of the glass decorative saucers that were assembled in Step 2.

Step 7: Attach Hanging Chain

Connect the provided hanging chain to the top loop of the chandelier. Ensure the connection is secure.

Step 8: Install Ceiling Hook and Hang Chandelier

Screw the ceiling hook into a secure ceiling joist or use appropriate anchors for drywall. Hang the chandelier chain from this hook. Adjust the chain length to achieve the desired hanging height.



Figure 2: Chandelier Hanging and Cable Management

Step 9: Route Power Cord and Attach Remaining Crystals (D Crystals)

Route the power cord along the ceiling to a power outlet using the provided cable management clips. Once the

chandelier is hung, attach the 'D' crystal chains to the arms, connecting them to the central base or other designated points as shown in the video.

Step 10: Install Light Bulbs

Screw 4 E12 base bulbs (max 40W each, not included) into the chandelier sockets. Ensure bulbs are fully seated.

OPERATING INSTRUCTIONS

1. **Power Connection:** Plug the chandelier's power cord into a standard 110V AC wall outlet.
2. **Turning On/Off:** Use the in-line ON/OFF switch located on the power cord to control the light.
3. **Dimmable Functionality:** If you are using dimmable E12 bulbs and have a compatible dimmer switch installed in your wall outlet, the chandelier's brightness can be adjusted. The chandelier itself does not include a dimmer.



Figure 3: In-line ON/OFF Switch

MAINTENANCE

- **Cleaning:** To clean the chandelier, first ensure it is unplugged. Use a soft, dry cloth to gently wipe the metal frame and glass crystals. For stubborn dust or smudges on crystals, a slightly damp cloth with mild glass cleaner can be used, followed by a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Bulb Replacement:** Ensure the chandelier is unplugged and bulbs are cool before attempting to replace them. Unscrew the old bulb and screw in a new E12 base bulb (max 40W).
- **Crystal Care:** Handle crystals with care. If any crystal strings become detached, reattach them using the small metal rings.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chandelier does not light up.	<ol style="list-style-type: none">1. Power cord not plugged in.2. ON/OFF switch is off.3. Faulty bulb(s).4. Power outage or tripped circuit breaker.	<ol style="list-style-type: none">1. Ensure the power cord is securely plugged into a working outlet.2. Flip the ON/OFF switch to the 'ON' position.3. Replace bulb(s) with new E12 bulbs.4. Check your home's circuit breaker and ensure power is restored.
Lights flicker.	<ol style="list-style-type: none">1. Loose bulb connection.2. Incompatible dimmer switch or dimmable bulbs.	<ol style="list-style-type: none">1. Ensure all bulbs are screwed in tightly.2. Verify that both your bulbs and dimmer switch are compatible. If not, replace bulbs or dimmer.
Crystals appear dull or dirty.	Dust or smudges on crystals.	Clean crystals as described in the Maintenance section.
Chandelier hangs unevenly.	Improper installation of ceiling hook or chain.	Re-check the installation of the ceiling hook and ensure the chain is securely and evenly attached.

SPECIFICATIONS

Model Number:	AS9027-4AB
Brand:	AMZASA
Dimensions (L x W x H):	19.9" x 18.1" x 79.7" (Adjustable Height: 59.8" max)
Material:	Glass, Iron, Crystal
Power Source:	AC (Plug-in)
Voltage:	110 Volts
Number of Lights:	4
Max Wattage per Bulb:	40 Watts
Bulb Base:	E12
Special Features:	Adjustable Height, Dimmable (with compatible bulbs/switch)
Installation Type:	Plug-in Chandelier
Item Weight:	6.82 pounds



Figure 4: Product Dimensions

WARRANTY AND CUSTOMER SUPPORT

AMZASA is committed to providing high-quality products and excellent customer service. If you encounter any issues such as color deviation, missing parts, or difficulties with installation, please contact us directly via email. We aim to provide a response within 24 hours. For further assistance, please visit the AMZASA Store on Amazon.