

VATOS VL-BB6801A

VATOS Smart Electronic Shooting Game Set Instruction Manual

Model: VL-BB6801A

INTRODUCTION

Thank you for choosing the VATOS Smart Electronic Shooting Game Set. This manual provides essential information for the safe and proper use of your new game set. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- This product is designed for users aged 10 and up. Adult supervision is recommended for younger users.
- Do not aim the shooting gun at people or animals. While it does not use projectiles, direct aiming can be startling.
- Keep the product away from water and excessive moisture to prevent electrical damage.
- Do not attempt to modify or disassemble the product. This may void the warranty and cause malfunction.
- Ensure proper battery installation and disposal according to local regulations.
- Use only the provided USB charging cable for the shooting gun.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Smart Scoring Base ×1
- Rechargeable Shooting Gun ×1
- Paper Target Ring ×1
- USB Charging Cable ×1
- User Manual ×1

AIM AND SHOOTING!



Strengthening
Concentration



Breathing
Control



Hand-eye
Coordination



Body
Balance



Spatial
Perception



Figure 1: Package Contents

SETUP

1. Smart Scoring Base Battery Installation

1. Locate the battery compartment on the underside of the Smart Scoring Base.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 AA batteries (not included), ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.




Figure 2: Smart Scoring Base Battery Installation

2. Shooting Gun Charging

1. The shooting gun has a built-in lithium battery. Locate the Type-C charging port on the gun.
2. Connect the provided USB charging cable to the gun and a suitable USB power source (e.g., computer, wall adapter).
3. An indicator light will illuminate during charging. It will turn off when the gun is fully charged (approximately 2 hours for a full charge). A full charge provides up to 4 hours of continuous play.



Figure 3: Shooting Gun Charging

3. Power On and Pairing

1. Turn on both the Smart Scoring Base and the Shooting Gun using their respective ON/OFF buttons.
2. The devices will automatically pair using 2.4G auto-pairing technology. A successful connection will be indicated by lights and voice feedback.

4. Target Placement

The paper target can be placed in two ways:

- **On the Smart Base:** Securely attach the paper target ring to the designated slots on the Smart Scoring Base.
- **Wall/Tree Hanging:** The target can also be hung on a wall or tree trunk for flexible outdoor play. The toy gun can be

used independently without the base, automatically recognizing and announcing scores for any targets with assigned values.



Figure 4: Flexible Target Setup

OPERATING INSTRUCTIONS

1. Controls Overview

Familiarize yourself with the controls on the shooting gun and smart base:

2.4GHZ SHOOTING GUN



ON/OFF

Power Button



Mode Button



Player Button



Confirm Button
(Long Press) Back Button



Type-C Charging Port

Indicator Light
(Turns off when fully charged)

Battery Compartment
(Battery included)

Figure 5: Shooting Gun Controls

AI INTELLIGENT SCORING TARGET



Figure 6: Smart Scoring Base Features

2. Selecting Modes and Players

1. Press the **Mode Button** on the shooting gun to cycle through the four available shooting modes: Practice, PK, Challenge, and Time Attack. The Smart Base's Mode Indicator Lights will change color to reflect the selected mode (Blue for Practice, Red for PK, Green for Challenge, White for Time Attack).
2. Press the **Player Button** to select the number of players (up to 4). The Player Indicator Lights on the Smart Base will show the active players.
3. The **Confirm Button** (also the Back Button with a long press) is used to confirm selections or navigate menus.

3. Real-Time Feedback and Scoring

- The Smart Scoring Base features a digital display screen that shows real-time scores.
- Both the Smart Base and the Shooting Gun provide clear voice feedback with every shot, announcing scores and game status.
- The optimal shooting distance for accurate recognition and rapid response is 6.5–13 feet (2–4 meters).

REAL-TIME SCORING TECHNOLOGY

2.4 Ghz Gun And Smart Base Pairing



Figure 7: Real-Time Scoring in Action

4. Shooting Modes Details

- **Practice Mode (Blue Light):** Focus on improving your shooting accuracy. Scores are displayed instantly.
- **PK Mode (Red Light):** A 10-shot shootout competition. Compete against other players to achieve the highest score within 10 shots.
- **Challenge Mode (Green Light):** Complete tactical missions. This mode may involve specific target sequences or conditions to increase difficulty.
- **Time Attack Mode (White Light):** A 5-second showdown. Test your speed and accuracy by hitting as many targets as possible within a short time limit.



Figure 8: Four Shooting Challenge Modes



Figure 9: Multi-Player Gameplay

5. Aiming Technique

The shooting gun features a sight and a notch to assist with aiming. Align the sight with the notch and the aiming point on the target for improved accuracy.

AIM AND SHOOTING!



Strengthening
Concentration



Breathing
Control



Hand-eye
Coordination



Body
Balance



Spatial
Perception



Figure 10: Aiming and Shooting

6. Official Product Videos

Video 1: VATOS Smart Electronic Shooting Game Set Overview. This video demonstrates the various features and gameplay modes of the shooting game set.

Video 2: Rechargeable Smart Electronic Shooting Gun. This video illustrates the charging process and battery installation for the shooting gun and target base.

Video 3: VATOS Smart Electronic Shooting Gun and Target. This video provides a detailed look at the gun and target components and their interaction during gameplay.

MAINTENANCE

- **Cleaning:** Wipe the Smart Scoring Base and Shooting Gun with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

- **Battery Care:** Remove AA batteries from the Smart Scoring Base if the product will not be used for an extended period to prevent leakage. Ensure the shooting gun is fully charged before storage to maintain battery health.
- **Storage:** Store the game set in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Devices not pairing	Low battery, devices too far apart, interference	Ensure both devices are charged/have fresh batteries. Bring devices closer. Restart both devices.
Inaccurate scoring	Incorrect shooting distance, target not properly aligned, environmental factors (e.g., strong light)	Maintain optimal shooting distance (6.5-13 feet). Ensure target is stable and facing the shooter. Adjust lighting conditions if necessary.
No voice feedback	Volume too low, speaker malfunction	Check volume settings on the gun/base (if applicable). Ensure batteries are sufficient.
Shooting gun not charging	Faulty cable, power source issue, damaged charging port	Try a different USB cable and power source. Ensure the cable is securely connected. Contact support if the issue persists.

SPECIFICATIONS

Feature	Detail
Brand	VATOS
Model Number	VL-BB6801A
Material Type	Plastic
Number of Players	Up to 4
Power Source (Base)	3 AA batteries (not included)
Power Source (Gun)	Built-in rechargeable lithium-ion battery
Charging Time (Gun)	Approx. 2 hours
Play Time (Gun)	Up to 4 hours (continuous)
Optimal Shooting Distance	6.5–13 feet (2–4 meters)
Connectivity	2.4G Auto-pairing
Item Dimensions	9 x 1.5 x 6 inches (Gun)
Age Range Description	Kid (Manufacturer Minimum Age: 120 months)

WARRANTY AND SUPPORT

VATOS products are manufactured to high-quality standards. For warranty information, please refer to the packaging or

contact your retailer. If you encounter any issues or require technical assistance, please contact VATOS customer support through the retailer's platform or the official VATOS website. Please have your model number (VL-BB6801A) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question