

Manuals.plus /

› VGR /

› VGR 119 Professional Cordless Hair Clippers User Manual

## VGR YS-V119

# VGR 119 Professional Cordless Hair Clippers User Manual

Model: YS-V119

## 1. INTRODUCTION

Thank you for choosing the VGR 119 Professional Cordless Hair Clippers. This manual provides essential information for the safe and effective use, maintenance, and care of your new hair clippers. Please read these instructions thoroughly before first use and keep them for future reference.

## 2. PRODUCT OVERVIEW

The VGR 119 hair clippers are designed for professional and home use, featuring a powerful BLDC motor and precision ceramic blades for consistent cutting performance.



**Figure 2.1: Clipper Components.** This image shows the VGR 119 hair clipper resting on its charging base, highlighting key components such as the ceramic and DLC coated blade, taper lever, BLDC motor, ON/OFF button, LED display, and USB charging base.

## Key Features:

- **BLDC Motor:** Equipped with an 8000 RPM brushless DC motor for stable, powerful, and quiet operation.
- **Ceramic Blades with DLC Coating:** Ensures durability, low heat generation, and precise cutting, suitable for all hair types and sensitive skin.
- **Adjustable Taper Lever:** Allows for 5-level precision cutting adjustments from 0.8mm to 2mm.
- **Long-Lasting Battery:** 2500mAh lithium battery provides up to 180 minutes of use after a 3.5-hour charge.
- **Dual Charging Modes:** Can be charged via USB cable or the included charging base.
- **LED Display:** Shows real-time battery status.
- **Low Noise Operation:** Operates at less than 70dB.

## Package Contents:

- VGR 119 Professional Cordless Hair Clipper
- 6 Guide Combs (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
- Charging Dock
- USB Charging Cable
- Blade Oil
- Cleaning Brush

## 3. SETUP

### 3.1 Initial Charge

Before first use, fully charge the clipper. Connect the USB charging cable to the clipper or place the clipper in the charging dock. Connect the other end of the USB cable to a suitable USB power adapter (not included). The LED display will indicate charging status. A full charge takes approximately 3.5 hours.



**Figure 3.1: Dual Charging Methods.** The clipper can be charged using the included charging base or directly via the USB cable for portable charging.

### 3.2 Attaching Guide Combs

To attach a guide comb, align the comb with the clipper blade and push it firmly until it clicks into place. To remove, gently pull the comb away from the blade.



**Figure 3.2: Guide Combs.** The kit includes six durable guide combs for various cutting lengths.

## 4. OPERATING INSTRUCTIONS

### 4.1 Turning On/Off

Press the ON/OFF button located on the side of the clipper to turn it on or off.

### 4.2 Adjusting Cutting Length (Taper Lever)

The taper lever on the side of the clipper allows for fine adjustments to the cutting length without a guide comb, ranging from 0.8mm to 2mm. Move the lever up or down to select the desired length.



**Figure 4.1: Taper Lever Adjustment.** The lever provides precise control over cutting length.

### 4.3 Using Guide Combs

For longer and consistent hair lengths, attach one of the six guide combs. The combs are labeled with their respective cutting lengths (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm). Select the appropriate comb for your desired style.

### 4.4 Hair Cutting Tips

- Ensure hair is clean and dry before cutting.
- Start with a longer guide comb and gradually reduce length if desired.
- Cut against the direction of hair growth for an even trim.
- Use smooth, overlapping strokes.

## 5. MAINTENANCE

---

### 5.1 Cleaning the Blades

After each use, turn off the clipper and remove any attached guide comb. Use the included cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, the blades can be carefully detached and rinsed under running water, ensuring the clipper body remains dry. Allow blades to air dry completely before reattaching.

### 5.2 Oiling the Blades

Regular oiling of the blades is crucial for optimal performance and longevity. After cleaning and drying, apply a few drops of the included blade oil to the teeth of the blades. Turn the clipper on for a few seconds to distribute the oil evenly. Wipe off any excess oil.

### 5.3 Storage

Store the clipper in a dry, cool place, away from direct sunlight and moisture. Keep out of reach of children.

## 6. SAFETY INSTRUCTIONS

---

- Do not immerse the clipper body in water.
- Keep the appliance away from water sources.
- Avoid contact with eyes.
- Do not use on infants.
- Always ensure the clipper is turned off before cleaning or maintenance.
- Use only the provided charging cable and dock.
- Do not operate the clipper if it is damaged.

## 7. TROUBLESHOOTING

---

### 7.1 Clipper Not Turning On

- Check if the battery is charged. Recharge the clipper if necessary.
- Ensure the ON/OFF button is fully pressed.

### 7.2 Poor Cutting Performance

- Clean the blades to remove any trapped hair.
- Oil the blades as described in the maintenance section.
- Ensure the blades are properly aligned and not damaged.

### 7.3 Clipper Overheating

- Turn off the clipper and allow it to cool down.
- Ensure blades are clean and oiled to reduce friction.


## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	YS-V119
Motor Type	BLDC Motor
Motor Speed	8000 RPM
Blade Material	Ceramic with DLC Coating
Battery Type	Lithium-ion
Battery Capacity	2500mAh
Charging Time	3.5 hours
Operating Time	Up to 180 minutes
Cutting Length Adjustment	0.8mm - 2mm (taper lever)
Guide Combs Included	1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm
Noise Level	< 70dB
Power Source	Battery Powered
Product Dimensions	10.94 x 9.33 x 2.36 inches
Item Weight	1.04 Kilograms

## 9. WARRANTY AND SUPPORT

VGR products are manufactured with quality and reliability in mind. This product comes with a 1-year warranty from the date of purchase. We also offer 24-hour customer support to assist with any inquiries or issues.



**Figure 9.1: Warranty and Support**

**Information.** Details on product guarantee and customer service availability.

For support, please contact VGR-DIRECT through our official channels. You can find more information and

contact details on our website or social media platforms.



**Figure 9.2: VGR-DIRECT Social Media.**  
Connect with us for updates and support.