

[Manuals.plus](#) /

› [Kisonli](#) /

› Kisonli K5 Stereo RGB Music Speaker User Manual

Kisonli K5

Kisonli K5 Stereo RGB Music Speaker User Manual

Model: K5

INTRODUCTION

Thank you for purchasing the Kisonli K5 Stereo RGB Music Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully before use to ensure optimal performance and safety.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and other liquids. This product is not water-resistant.
- Do not attempt to disassemble or repair the speaker yourself. Contact qualified service personnel.
- Use only the specified charging cable and power adapter.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check the package for the following items:

- Kisonli K5 Stereo RGB Music Speaker
- USB Charging Cable
- AUX Audio Cable
- User Manual

PRODUCT OVERVIEW

The Kisonli K5 speaker features dual drivers for balanced sound, dynamic RGB lighting, and multiple connectivity options. Familiarize yourself with its components:



Image: Top view of the Kisonli K5 speaker, highlighting the control panel with power, volume, mode, and light buttons.



Image: Rear view of the Kisonli K5 speaker, displaying the USB, AUX, and Micro SD card input ports, typically covered by a protective flap.



Image: Side view of the Kisonli K5 speaker, showcasing the active RGB lighting on the end panel, which illuminates in various colors.

SETUP

Charging the Speaker

1. Connect the USB charging cable to the speaker's charging port.
2. Connect the other end of the USB cable to a compatible USB power adapter (5V/1A recommended) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color once fully charged.
4. A full charge typically takes approximately 3-4 hours.

Powering On/Off

- To power on, press and hold the Power button (U) for a few seconds until you hear an audible prompt and the RGB lights activate.
- To power off, press and hold the Power button (U) again for a few seconds.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue light or audible prompt). If not, press the 'M' (Mode) button to switch to Bluetooth mode.
2. Enable Bluetooth on your device (smartphone, tablet, computer).
3. Search for available Bluetooth devices and select "Kisonli K5" from the list.
4. Once paired, the speaker will emit an audible confirmation, and the Bluetooth indicator light will become solid.
5. You can now play audio from your device through the speaker.

AUX Mode

1. Connect one end of the 3.5mm AUX audio cable to the speaker's AUX input port.
2. Connect the other end of the AUX cable to the audio output jack of your device.
3. Press the 'M' (Mode) button on the speaker to switch to AUX mode.
4. Audio will now play through the speaker from your connected device.

USB Playback

1. Insert a USB flash drive (containing MP3 audio files) into the speaker's USB port.
2. The speaker will automatically switch to USB mode and begin playing audio. If not, press the 'M' (Mode) button to select USB mode.

Micro SD Card Playback

1. Insert a Micro SD card (containing MP3 audio files) into the speaker's Micro SD card slot.
2. The speaker will automatically switch to Micro SD mode and begin playing audio. If not, press the 'M' (Mode) button to select Micro SD mode.

Controlling RGB Lights

- Press the Light button (often indicated by a light bulb icon) to cycle through different RGB lighting modes or to turn the lights off.
- The lights are designed to react to the rhythm of the music.

Volume Control

- Use the '+' button to increase volume and the '-' button to decrease volume.
- You can also control the volume from your connected device.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; incorrect mode; device not connected.	Increase volume on speaker and device. Ensure correct mode (Bluetooth, AUX, USB, Micro SD). Reconnect device.
Bluetooth pairing fails.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in Bluetooth pairing mode. Move device closer. Turn off other Bluetooth devices.
USB/Micro SD not playing.	Unsupported file format; card/drive not inserted correctly; corrupted files.	Ensure files are MP3 format. Reinsert card/drive. Try different files or storage device.
RGB lights not working.	Lights turned off; malfunction.	Press the Light button to activate. If still not working, contact support.

SPECIFICATIONS

Feature	Detail
Model Number	K5
Brand	Kisonli
Maximum Speaker Output Power	16 Watts
Connectivity Technology	Bluetooth, USB, Auxiliary (AUX), Micro SD
Audio Output Mode	Stereo
Speaker Type	Portable Bluetooth Speaker
Mounting Type	Tabletop
Material	Plastic
Color	Black and Orange
Water Resistance	No
Control Method	Touch
Speaker Size	16 Centimeters
Product Dimensions (DxWxH)	16D x 29W x 14H cm
Item Weight	1.57 Kilograms
Power Source	Battery Powered
Surround Sound Channel Configuration	2.0

WARRANTY INFORMATION

The product specifications indicate "NO Warranty". Please refer to your point of purchase or retailer for any specific warranty terms or return policies that may apply.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact the retailer or manufacturer's customer support. Keep your purchase receipt for reference.



© 2025 Kisonli. All rights reserved.