

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PERLESMITH](#) /

› [PERLESMITH Universal Swivel TV Stand Base PSTVS35 & PGTVS29 Instruction Manual](#)

PERLESMITH PSTVS35, PGTVS29

PERLESMITH Universal Swivel TV Stand Base

MODELS: PSTVS35 & PGTVS29

Instruction Manual

1. Important Safety Information

Please read these instructions carefully before installation and use. If you do not understand these instructions or have doubts about the safety of the installation, please contact PERLESMITH customer support.

- Ensure the mounting surface can safely support the combined weight of the equipment and all attached hardware.
- Do not exceed the maximum load capacity specified for each model.
- Use only the components provided by the manufacturer. Do not use the product for any purpose not explicitly specified by PERLESMITH.
- Always have two people for assembly and installation to prevent injury or damage.
- Keep small parts away from children.

2. Product Overview and Parts List

This manual covers two models: the **PGTVS29 Monitor Stand** and the **PSTVS35 TV Stand**. While sharing a universal design, they offer distinct features and compatibility.

Before assembly, ensure all parts are present and undamaged. Refer to the packaging for a complete list of included hardware. Common components include:

- Base Plate
- Support Column
- VESA Plate / TV Bracket
- Mounting Hardware (screws, washers, spacers)
- Tools (Allen wrench, etc.)



Image: Components of the PERLESMITH PGTVS29 Monitor Stand, showing the base, column, and VESA mounting plate.



Image: Components of the PERLESMITH PSTVS35 TV Stand, featuring a wider TV bracket for larger screens.

3. Setup and Assembly Instructions

Follow these general steps for assembly. Specific details may vary slightly between models. Always refer to the detailed diagram in your product packaging for precise screw and part identification.

Step 3.1: Assemble the Base and Support Column

1. Attach the support column to the base plate using the provided screws and tools. Ensure it is securely fastened and stable.
2. Route any necessary cables through the column's cable management openings if available.

Step 3.2: Attach VESA Plate / TV Bracket to Your Screen

Identify the correct VESA mounting screws (M4, M6, M8) for your TV or monitor. Use the appropriate washers and spacers if needed to ensure a flush fit and prevent damage to your screen.

- **For PGTVS29 Monitor Stand:** Compatible with VESA patterns 50x50mm, 75x75mm, and 100x100mm.
- **For PSTVS35 TV Stand:** Compatible with a wider range of VESA patterns (refer to product packaging for specific sizes).

1. Carefully place your screen face down on a soft, clean surface.
2. Align the VESA plate or TV bracket with the mounting holes on the back of your screen.
3. Secure the plate/bracket using the correct screws, ensuring they are tightened firmly but do not overtighten.

Step 3.3: Mount the Screen to the Stand

1. With assistance, carefully lift the screen with the attached VESA plate/TV bracket.
2. Hook the VESA plate/TV bracket onto the support column.
3. Secure the screen to the column using the safety screws or locking mechanism provided. Ensure the screen is stable and cannot be accidentally dislodged.

4. Operating Instructions

4.1: PGTVS29 Monitor Stand Operations

- **Height Adjustment:** The PGTVS29 offers 5 ergonomic height settings, with a maximum height of 15.26 inches and a minimum of 9.27 inches. To adjust, loosen the locking mechanism on the column, slide the screen to the desired height, and re-tighten securely.



Image: Illustration of the PGTVS29 Monitor Stand's 5 ergonomic height adjustment positions.

- **Tilt Adjustment:** The monitor can be tilted from -15° to $+10^\circ$. Use the easy tilt knob located on the VESA plate to adjust the viewing angle. Loosen the knob, set the desired tilt, and tighten the knob to secure.



Image: Demonstrates the -15° to $+10^\circ$ tilt range of the PGTVS29 Monitor Stand, highlighting the easy tilt knob.

- **Rotation:** The PGTVS29 allows for a full 360° screen rotation, enabling both landscape and portrait orientations. Gently rotate the screen to your preferred orientation.

34" Screen Rotation




Image: Visual representation of the PGTVS29 Monitor Stand's 360° screen rotation capability.

4.2: PSTVS35 TV Stand Operations

- **Swivel:** The PSTVS35 TV stand features a 70° swivel range (35° left and 35° right). Gently push the TV to the desired viewing angle. The swivel mechanism is designed for smooth movement.

Perfect View From Any Seat



Image: Demonstrates the $\pm 35^\circ$ swivel capability of the PSTVS35 TV Stand for optimal viewing from various positions.

- **Height Adjustment:** The PSTVS35 offers 6 height configurations. To adjust the height, remove the TV from the stand, reposition the TV bracket on the support column to the desired height setting, and re-mount the TV securely.

6 Height Configurations




Image: Illustrates the 6 different height configurations available for the PSTVS35 TV Stand.

5. Maintenance

- Regularly check that all screws and connections are tight and secure. Re-tighten if necessary.
- Clean the stand with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- Ensure cables are neatly managed and not under tension or pinched, which could affect the stand's stability or cable integrity.

6. Troubleshooting

- **Issue: Stand feels unstable.**

Solution: Ensure all screws are tightened. Verify the stand is placed on a flat, level surface. Check that the weight of your screen does not exceed the stand's maximum load capacity.

- **Issue: Difficulty adjusting height/tilt/swivel.**

Solution: For height and tilt, ensure any locking knobs or screws are sufficiently loosened before attempting adjustment. For swivel, ensure no cables are obstructing movement. Do not force adjustments.

- **Issue: Screen does not fit the VESA plate.**

Solution: Double-check your screen's VESA pattern against the stand's compatibility. Ensure you are using the correct screws, washers, and spacers for your screen model.

7. Specifications

PGTVS29 Monitor Stand:

- **Screen Size Compatibility:** 13" - 34"
- **Maximum Load Capacity:** 44 lbs (20 kg)
- **VESA Compatibility:** 50x50mm, 75x75mm, 100x100mm
- **Column Height:** 17.24 inches
- **Height Adjustment:** 5 positions, Min 9.27" - Max 15.26"
- **Tilt Range:** -15° to +10°
- **Rotation:** 360°



Image: Specifications for the PGTVS29 Monitor Stand, including VESA patterns, max load, and screen size range.

PSTVS35 TV Stand:

- **Swivel Range:** ±35° (70° total)

- **Height Adjustment:** 6 configurations
- **Compatibility:** Universal for various TV sizes (refer to product packaging for specific VESA and weight limits)

8. Warranty and Support

PERLESMITH products are designed for durability and performance. For warranty information, technical support, or any questions regarding your product, please contact PERLESMITH customer service directly. Contact details can typically be found on the product packaging or the official PERLESMITH website.

Please have your model number (PSTVS35 or PGTVS29) and purchase information ready when contacting support.

© 2026 PERLESMITH. All rights reserved.