

MXV H26003

MXV Modern Coffee Table (47-inch) with LED Lights - User Manual

Model: H26003 | Brand: MXV

1. INTRODUCTION

Thank you for choosing the MXV Modern Coffee Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new coffee table. Please read these instructions carefully before use and retain them for future reference.

2. PRODUCT FEATURES

- **Adjustable LED Lights:** Features 16 color options and 4 flashing modes, controlled by a remote, to create a customizable ambiance.
- **Spacious 2-Tier Storage:** Double-layer design provides ample space for magazines, books, remote controls, and other living room essentials.
- **Modern Stylish Design:** High-gloss lacquer finish, round corners, and integrated cable management for a sleek and contemporary look.
- **Durable Construction:** Frame made from FSC-certified engineered wood, designed for stability and longevity.
- **Easy Maintenance:** The high-gloss black surface is designed to be less prone to showing stains or scratches, simplifying cleaning.

3. SPECIFICATIONS

Specification	Detail
Model Number	H26003
Product Dimensions (D x W x H)	23.6" x 47.2" x 15.7"
Item Weight	60 Pounds

Maximum Weight Recommendation	132 Pounds
Frame Material	Engineered Wood (FSC-certified)
Color	Black
LED Features	16 Colors, 4 Flashing Modes, Adjustable Brightness

Product Size

Max Capacity: **130 LBS**




Figure 3.1: Product Dimensions and Max Capacity

4. PACKAGE CONTENTS

Before assembly, please ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

- Coffee Table Components
- LED Light Strip
- Remote Control for LED Lights
- Assembly Hardware (screws, dowels, etc.)
- Assembly Guide (this document)

5. SETUP & ASSEMBLY

Assembly is required for this coffee table. It is recommended to have two people for quicker and more efficient assembly. Please follow the detailed steps provided in the included assembly guide. Ensure you have the recommended tools before starting.

Recommended Tools:

- Hammer
- Screwdriver



Figure 5.1: Assembled Coffee Table with Storage

6. OPERATING INSTRUCTIONS

LED Light Operation:

1. **Connect Power:** Plug the LED light power adapter into a standard electrical outlet. Ensure the cable is routed safely using the integrated cable management feature.
2. **Remote Control:** Use the provided remote control to operate the LED lights.
3. **Power On/Off:** Press the 'ON' or 'OFF' button to turn the lights on or off.
4. **Color Selection:** Select from 16 different colors using the color buttons on the remote.
5. **Mode Selection:** Choose from 4 flashing modes (Flash, Strobe, Fade, Smooth) to change the light effect.
6. **Brightness Adjustment:** Adjust the brightness level using the dedicated brightness buttons. There are 4 levels of brightness.

16-Color Adjustable LED Lights




Figure 6.1: LED Light Remote Control and Features



Adjustable Brightness with 4 Levels



Figure 6.2: Adjustable LED Brightness Levels

Your browser does not support the video tag.

Video 6.1: Demonstration of MXV Modern Coffee Table with LED Light features, including color changes and overall design.

7. MAINTENANCE

- **Cleaning:** Wipe the high-gloss surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Dusting:** Regularly dust the table with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining, especially on the LED light components.
- **LED Care:** Ensure the LED light strip and remote control are kept dry. Do not attempt to disassemble the LED components.

8. TROUBLESHOOTING

LED Lights Not Working:

- **Check Power Connection:** Ensure the power adapter is securely plugged into both the table and a working electrical outlet.
- **Remote Battery:** Verify that the remote control battery is not depleted. Replace if necessary.
- **Line of Sight:** Ensure there are no obstructions between the remote control and the LED receiver on the table.
- **Reset:** Unplug the power adapter for 30 seconds, then plug it back in to reset the LED system.

Table Instability:

- **Check Assembly:** Re-check all screws and connections to ensure they are tightened properly according to the assembly guide.
- **Level Surface:** Ensure the table is placed on a flat, level surface.

9. SAFETY INFORMATION

- Do not exceed the maximum weight recommendation of 132 pounds on the table surface.
- Keep small children and pets away from the assembly area during setup.
- Do not stand or sit on the coffee table.
- Keep liquids away from electrical components, including the LED lights and power adapter.
- Ensure all electrical cords are safely tucked away to prevent tripping hazards.
- Dispose of packaging materials responsibly.

10. WARRANTY & SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the purchase documentation or contact MXV customer service directly. Keep your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question