



[Manuals.plus](#) /

› [ESR](#) /

› ESR AirPods Pro 3 Case Instruction Manual

ESR AirPods Pro 3 Case

ESR AirPods Pro 3 Case Instruction Manual

Model: AirPods Pro 3 Case

INTRODUCTION

Thank you for choosing the ESR AirPods Pro 3 Case. This case is designed to provide robust protection and enhanced functionality for your AirPods Pro 3 (2025) charging case. It features MagSafe compatibility for effortless wireless charging, a magnetic lid lock for secure closure, and a hybrid design for comprehensive drop protection. The integrated lanyard offers convenient portability, and precise speaker cutouts ensure clear Find My alerts.



The ESR AirPods Pro 3 Case, designed for protection and convenience.

SETUP INSTRUCTIONS

1. Installing the Case

1. Ensure your AirPods Pro 3 charging case is clean and free of debris.
2. Carefully insert the bottom part of your AirPods Pro 3 charging case into the main body of the ESR case.
3. Align the top lid of the ESR case with the lid of your AirPods Pro 3 charging case and press firmly until it snaps into place. The adhesive strip inside the lid helps secure it.

Added Extras

Comes with a cleaning brush, easy-removal tool, and adhesive strip for lid



Visual guide for installing the case and using the cleaning brush and removal tool.

2. Attaching the Lanyard

The case includes an adjustable braided strap (lanyard) for easy carrying. Thread the loop of the lanyard through the designated attachment point on the side of the case. Secure it by passing the main strap through the loop.



Easy to carry

Carry on your wrist or securely attach to a bag



The adjustable braided strap allows for secure and convenient carrying on your wrist or attached to a bag.

OPERATING INSTRUCTIONS

Magnetic Lid Lock

The ESR case features strong built-in magnets that ensure the lid of your AirPods Pro 3 charging case remains securely closed, preventing accidental openings and protecting your earbuds.

Magnetic Locking Lid

Stronger magnets ensure your lid stays securely closed



Strong magnets keep the lid securely closed.

MagSafe and Wireless Charging

The case is fully compatible with MagSafe chargers and other wireless charging pads. Simply place your cased AirPods Pro 3 onto a compatible wireless charger for convenient and efficient charging. The strong magnets ensure proper alignment for optimal charging performance.

Effortless MagSafe

Fast, easy place-and-go wireless charging



136%↑
Stronger Magnets

Compatible with Apple
Watch charger




*Data based on ESR lab testing of magnetic strength for ESR AirPods Pro 3 case and Apple AirPods Pro 3 when connected to an Apple MagSafe charger

Effortless MagSafe charging with the case on.

Speaker Cutouts and Status Light

The case features precise cutouts at the base to ensure that the Find My app sound alerts are clearly audible. The front of the case also has a cutout for the charging indicator light, allowing you to easily monitor your AirPods' charging status.

User Friendly



Visible status light and clear speaker cutouts for functionality.

Product Overview Video

Your browser does not support the video tag.

This video provides a visual overview of the ESR AirPods Pro 3 Case, demonstrating its features and design.

MAINTENANCE

Cleaning the Case

To maintain the appearance and functionality of your ESR AirPods Pro 3 Case, regularly wipe it with a soft, damp cloth. For hard-to-reach areas or accumulated dust, use the included cleaning brush. Avoid using harsh chemicals

or abrasive materials, as these may damage the case's finish.

Removing the Case

If you need to remove the case for cleaning or other reasons, use the provided easy-removal tool. Insert the tool into the designated slot and gently pry the case open. Do not force the case off, as this may cause damage.

TROUBLESHOOTING

- **Lid not closing securely:** Ensure the AirPods Pro 3 charging case is properly seated within the ESR case and that the adhesive strip on the lid is clean and making full contact. Check for any obstructions or debris.
- **Wireless charging issues:** Verify that your wireless charger is MagSafe compatible and properly functioning. Ensure the ESR case with your AirPods Pro 3 is correctly aligned on the charging pad. Remove any metal objects between the case and the charger.
- **Muffled Find My alerts:** Check that the speaker cutouts at the bottom of the case are clear of any dust or debris.
- **Case feels loose:** Re-install the case, ensuring both top and bottom sections are firmly attached. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	ESR
Color	Black
Compatible Devices	AirPods Pro 3
Form Factor	Case
Shell Type	Case
Additional Features	Heavy Duty Protection
Compatible Headphone Models	Apple AirPods Pro (3rd generation)
Pattern	Solid
Item Dimensions	2.68 x 2.06 x 1.04 inches
Item Weight	30.7 Grams
Enclosure Material	Polycarbonate, Thermoplastic Polyurethane

WARRANTY INFORMATION

The ESR AirPods Pro 3 Case comes with a comprehensive 12-month protection plan. This warranty covers manufacturing defects and ensures your product performs as expected under normal use. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For detailed setup videos, frequently asked questions (FAQs), or personalized assistance, please visit the official

ESR website or contact our customer support team. We offer unlimited support to ensure your satisfaction with our products.

ESR Official Store: [Visit the ESR Store on Amazon](#)