

[Manuals.plus](#) /

> [WIRQO](#) /

> WIRQO Steam Cleaner WIR-068 Instruction Manual

WIRQO WIR-068

WIRQO Steam Cleaner WIR-068 Instruction Manual

Model: WIR-068 | Brand: WIRQO

1. PRODUCT OVERVIEW

The WIRQO Steam Cleaner WIR-068 is a powerful and versatile cleaning solution designed for various surfaces in your home, car, and more. It utilizes superheated steam to effectively remove stubborn stains, grease, and grime without the need for harsh chemicals, ensuring a safe environment for children and pets. Equipped with a 1500W heating element, it heats up in just 5 minutes and provides up to 50 minutes of continuous steam from its 1.5L water tank.



Image: WIRQO Steam Cleaner in action, demonstrating its chemical-free cleaning capabilities with high-temperature steam, strong pressure, and a large water tank for extended use.



Image: The steam cleaner effectively removing grease and grime from an oven, illustrating its powerful cleaning action.

2. WHAT'S IN THE BOX

Your WIRQO Steam Cleaner comes with a comprehensive 24-piece accessory kit to tackle various cleaning tasks:

- Steam Cleaner Main Unit
- Extension Tube x2
- Big Nozzle x1
- Mop Adapter x1
- Ironing Brush x1
- Squeegee x1
- Carpet Glider x1
- Nylon Brush x4
- Brass Brush x2
- Plastic Brush x1
- Floor Towel x1
- Ironing Towel x2
- Cleaning Cloth x2
- Measuring Cup x1
- Funnel x1
- Glove x1
- Storage Bag x1

24-PIECE PROFESSIONAL ACCESSORY KIT



Image: A visual representation of all 24 multi-functional accessories included with the WIRQO Steam Cleaner.

ACCESSORY DETAIL



Image: Close-up details of several accessories, including brushes, mop pads, and extension tubes, demonstrating their specific applications.

Your browser does not support the video tag.

Video: An official WIRQO video showcasing the steam cleaner and its 24-piece attachments for various home cleaning tasks.

3. SETUP INSTRUCTIONS

Follow these steps to set up your WIRQO Steam Cleaner for first use:

1. **Open the safety cap:** Carefully unscrew the safety cap on the main unit.
2. **Fill the tank with water:** Use the provided measuring cup and funnel to fill the 1.5L water tank with clean water. Do not overfill.
3. **Secure the cap:** Screw the safety cap back on tightly.
4. **Press the power switch:** Plug in the steam cleaner and press the power button. The indicator light will turn red.
5. **Wait for heating:** Allow approximately 5 minutes for the unit to heat up. The indicator light will change from red to green when ready.
6. **Attach desired accessory:** Connect the appropriate cleaning attachment (e.g., extension tube, big nozzle, floor brush) for your task.



Image: Visual guide illustrating the step-by-step process of setting up and preparing the steam cleaner for operation.

4. OPERATING INSTRUCTIONS

Once the steam cleaner is ready, you can begin your cleaning tasks:

- **Adjust Steam Output:** The ergonomic handle features an adjustable steam output button. Slide it to control the steam level (Min to Max) according to the surface and cleaning intensity required.
- **Safety Lock:** The handle also includes a child-safe lock to prevent accidental triggering. Engage the lock when not actively steaming or when storing the device.
- **Optimal Cleaning:** For best results, keep the steam nozzle close to the surface to achieve optimal temperature and steam pressure.
- **Initial Water Spray:** A small amount of water may spray out of the nozzle initially. This is normal condensed water. Once expelled, the unit will produce dry, high-temperature steam.
- **Versatile Application:** Use the appropriate attachments for different surfaces. The flexible hose and long power cord provide excellent maneuverability for kitchens, bathrooms, floors, carpets, cars, sofas, mattresses, toilets, windows, curtains, walls, ovens, and clothing.

FEATURES & ADVANTAGES




Image: Illustration of the steam control function, showing adjustable steam output and the child-safe lock on the handle.

STEAM TEMPERATURE DROPS WITH DISTANCE

For Best Results, hold the nozzle near the surface to maximize cleaning power




Image: A visual explanation of how steam temperature decreases with distance, emphasizing the importance of holding the nozzle close for maximum cleaning power.

Your browser does not support the video tag.

Video: A short demonstration of the steam cleaner being used on a floor, highlighting its ease of use and versatility.



Image: The steam cleaner effectively cleaning a floor surface.



Image: The steam cleaner refreshing and cleaning a couch.



Image: The steam cleaner effectively cleaning grout lines.



Image: The steam cleaner cleaning a window surface.



Image: The steam cleaner sanitizing a toilet.




Image: The steam cleaner cleaning surfaces in a kitchen.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your steam cleaner:

- **Empty Water Tank:** After each use, ensure the unit has cooled down completely, then carefully open the safety cap and empty any remaining water from the tank.
- **Clean Attachments:** Wash all reusable cleaning cloths and mop pads. Clean brushes and nozzles with water to remove any residue.
- **Descaling (Periodically):** Depending on water hardness, periodic descaling may be necessary. Consult the full manual for detailed descaling instructions.

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, ideally in the provided storage bag, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **No Steam or Low Steam:**
 - Check if the water tank is sufficiently filled.
 - Ensure the unit has fully heated up (green indicator light).
 - Verify that the steam output button on the handle is not set to 'Min' or locked.
- **Water Spraying from Nozzle:**
 - A small amount of water spray at the beginning of use is normal due to condensation. Continue steaming, and it will soon produce dry, high-temperature steam.
- **Unit Not Powering On:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the power button on the unit is pressed.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	WIRQO
Model Name	WIR-068
Wattage	1500 watts
Tank Volume	1.5 Liters
Heat Time	5 Minutes
Maximum Temperature	302 Degrees Fahrenheit (150°C)
Continuous Steam Time	Up to 50 minutes
Power Source	Corded Electric
Voltage	120 Volts
Item Weight	11.13 pounds (5050 Grams)
Product Dimensions	11.73"D x 10.35"W x 11.65"H

8. WARRANTY AND SUPPORT

The WIRQO Steam Cleaner WIR-068 comes with a **1-year warranty**. If you have any questions, issues, or require support, please contact WIRQO customer service. Refer to the product packaging or the official WIRQO website for contact details.

