

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Karl home](#) /

> [Karl home Hardside 21 Inch Carry On Luggage KHCL0906 Instruction Manual](#)

**Karl home KHCL0906**

# Karl home Hardside 21 Inch Carry On Luggage Instruction Manual

Model: KHCL0906

## INTRODUCTION

Thank you for choosing the Karl home Hardside 21 Inch Carry On Luggage. This manual provides essential information for the proper setup, operation, and maintenance of your new luggage. Please read these instructions carefully before use to ensure optimal performance and longevity of your product.





Image: Front view of the Karl home Hardside 21 Inch Carry On Luggage in black, showcasing its textured hardshell design and spinner wheels.

## PRODUCT FEATURES

---

The Karl home Hardside Carry On Luggage is designed for convenience and durability. Key features include:

- **Durable ABS Material:** Constructed from sturdy ABS material with molded corners and a full liner, offering resistance to scratches, pressure, and water.
- **TSA Combination Lock:** Integrated TSA-approved lock for secure travel.
- **Organized Interior:** Features two large compartments, a mesh zippered compartment, and cross straps for efficient packing.
- **Effortless Mobility:** Equipped with four 360° silent sliding spinner wheels and a retractable handle for smooth maneuverability.
- **Side Handle and Feet:** An additional side handle for easy lifting and four molded side feet for upright storage.

# 100% ABS Material

- 1 Robust ABS Composition
- 2 Strong Stress Test Passed
- 3 Comprehensive protection




Image: Diagram illustrating the robust ABS material composition, highlighting its multi-layered structure for comprehensive protection and stress resistance.

## SETUP INSTRUCTIONS

### Setting the TSA Combination Lock

Your luggage comes with a pre-set combination lock. To set your personal combination:

1. The lock is factory-set to **0-0-0**. Ensure the dials are set to this combination.
2. Locate the reset button (a small, recessed button, usually on the side of the lock). Use a pen or a pointed object to press and hold this button until you hear a click.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. You should hear another click, indicating your new combination is set.
5. Test your new combination by scrambling the dials and then entering your set combination to open the lock.

**Important:** Remember your combination. There is no master key for the user to reset the lock if the combination is

forgotten. Only TSA agents have a universal key for inspection purposes.



## 3-Digit TSA

TSA customs lock,  
ensuring safe  
and smooth travel worldwide

Image: Detailed view of the 3-digit TSA combination lock, showing the dials and the lock mechanism.

## OPERATING INSTRUCTIONS

### Using the Retractable Handle

The luggage features a multi-stage retractable handle for comfortable maneuvering.

1. To extend the handle, press the button located on the top of the handle grip.
2. Pull the handle upwards to your desired height. The handle has multiple locking positions.
3. To retract the handle, press the button again and push the handle downwards until it is fully nested within the luggage.

# ■ Robust and Customizable

3 adjustable levels

Telescoping handle



Image: Illustration of the telescoping handle, demonstrating its three adjustable levels for user comfort.

## Maneuvering with Spinner Wheels

The 360° spinner wheels allow for effortless movement in any direction.

- For upright rolling, push or pull the luggage alongside you.
- For two-wheel pulling, tilt the luggage and pull it behind you.
- The silent wheels are designed for smooth gliding over various surfaces.



**Strong load-bearing capacity**



**Exquisite and elegant appearance**



**Moveing easily**

Image: Close-up view of the 360° silent and sturdy spinner wheels, highlighting their design for smooth movement.

## **Packing Your Luggage**

Utilize the interior compartments for organized packing:

- Place larger items in the main compartments.
- Use the mesh zippered compartment for smaller items, toiletries, or documents.
- Secure your clothing with the elastic cross straps to prevent shifting during transit.

# Every opening and closing is an encounter with craftsmanship.



zippered Compartment



Mesh Pocket



Elastic Cross Strap

Image: Interior view of the luggage, demonstrating the zippered compartment, mesh pocket, and elastic cross straps for organized packing.

## MAINTENANCE AND CARE

### Cleaning the Hardshell Exterior

The ABS hardshell is easy to clean and maintain:

- Wipe the exterior with a soft cloth dampened with mild soap and water.
- Avoid using abrasive cleaners or solvents, as these can damage the surface.
- For stubborn marks, a magic eraser sponge can be used gently.
- Dry thoroughly with a clean, dry cloth.

### Wheel and Handle Care

- Periodically check the wheels for any debris (hair, lint) and remove them to ensure smooth rolling.
- Ensure the retractable handle extends and retracts smoothly. If it becomes stiff, a small amount of silicone spray can be applied to the telescoping rods, avoiding the button mechanism.

## TROUBLESHOOTING

### TSA Lock Issues

- **Lock not opening:** Ensure the dials are precisely aligned with your set combination. If you forgot the combination, unfortunately, there is no user-accessible reset. You may need to contact customer support for assistance or consider a professional locksmith.
- **Difficulty setting combination:** Ensure the reset button is fully pressed and held while setting the new combination. Release it only after the new combination is set.

### Handle Not Extending/Retracting Smoothly

- Check for any obstructions in the handle mechanism.
- Ensure the release button is fully depressed when attempting to extend or retract.
- If the issue persists, apply a small amount of silicone lubricant to the handle rods.

### Wheels Not Rolling Smoothly

- Inspect the wheels for any trapped debris such as hair, string, or dirt. Carefully remove any obstructions.
- Ensure the wheels are not damaged. If a wheel is severely damaged, contact customer support for potential replacement options.

## SPECIFICATIONS

<b>Model Number</b>	KHCL0906
<b>Product Dimensions</b>	13.78 x 10 x 20.47 inches
<b>Item Weight</b>	4.85 pounds
<b>Material</b>	ABS Hardshell
<b>Wheels</b>	4 x 360° Spinner Wheels
<b>Lock Type</b>	TSA Combination Lock
<b>Department</b>	Unisex Adult
<b>Manufacturer</b>	Karl home

# Size Reference



12  
inch



7.87" X 10.63" X 6.3"

16  
inch



14.17" X 11.81" X 8.27"

28  
inch



24.8" X 18.5" X 11.81"

24  
inch



22.44" X 15.75" X 10.24"

20  
inch



18.5" X 13.78" X 8.66"

Image: Size reference chart for Karl home luggage, providing dimensions for various sizes including the 20-inch carry-on.

## WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Karl home customer service. Refer to the product packaging or the official Karl home website for the most current contact details. Please retain your purchase receipt as proof of purchase for any warranty claims.

