

[Manuals.plus](#) /

> [ESR](#) /

> ESR Orbit Hybrid Magnetic Case for AirPods Pro 3 (2025) - User Manual

ESR AirPods Pro 3 Case

ESR Orbit Hybrid Magnetic Case for AirPods Pro 3 (2025) - User Manual

Model: AirPods Pro 3 Case

INTRODUCTION

This manual provides instructions for the ESR Orbit Hybrid Magnetic Case, designed specifically for AirPods Pro 3 (2025). This case offers enhanced protection, MagSafe compatibility, and convenient features to secure and carry your earbuds.

PRODUCT COMPATIBILITY

The ESR Orbit Hybrid Magnetic Case is exclusively compatible with **AirPods Pro 3 (2025)**. It is not designed for AirPods Pro 2 & 1, AirPods 4, or AirPods 3.

Only for AirPods Pro 3



Image: Visual guide illustrating compatibility with AirPods Pro 3 (2025) and incompatibility with other AirPods models.

SETUP AND INSTALLATION

- 1. Insert AirPods Pro 3 Charging Case:** Gently slide your AirPods Pro 3 charging case into the bottom section of the ESR Orbit Hybrid Magnetic Case. Ensure it is seated firmly.
- 2. Attach the Lid:** Place the top cover of the ESR case over the lid of your AirPods Pro 3 charging case. The strong magnets will secure the lid in place.

3. **Attach Lanyard (Optional):** Thread the adjustable braided strap through the designated loop on the side of the case for convenient carrying.

Your browser does not support the video tag.

Video: Demonstrates the installation of AirPods Pro 3 into the ESR Orbit case, showcasing the magnetic lock and overall fit.

OPERATING INSTRUCTIONS

Magnetic Locking Lid

The case features a magnetic locking lid that keeps your AirPods Pro 3 securely enclosed. To open, simply slide the front latch. The strong magnets ensure the lid remains shut, preventing accidental openings and protecting your earbuds from falling out during drops.

Magnetic Locking Lid

Stronger magnets ensure your lid stays securely closed



Image: Close-up of the ESR case demonstrating the magnetic locking lid mechanism.

MagSafe Charging

The ESR Orbit Hybrid Magnetic Case is fully compatible with MagSafe chargers. Strong magnets built into the back of the case ensure a secure and effortless connection to MagSafe charging pads. Simply place the case on a MagSafe charger for wireless charging without needing to remove the case.

Effortless MagSafe

Fast, easy place-and-go wireless charging



136%↑
Stronger Magnets

Compatible with Apple
Watch charger



*Data based on ESR lab testing of magnetic strength for ESR AirPods Pro 3 case and Apple AirPods Pro 3 when connected to an Apple MagSafe charger

Image: AirPods Pro 3 case in ESR cover being charged wirelessly on a MagSafe compatible stand.

Visible Status Light and Speaker Cutouts

The case features a precise cutout for the charging status light, allowing you to easily monitor your AirPods Pro 3's charging status at a glance. Additionally, specially placed speaker cutouts on the base ensure that "Find My" app sound alerts are clearly audible, helping you locate your earbuds.



Easy to carry

Carry on your wrist or securely attach to a bag



Image: Detail view of the ESR case highlighting the visible charging status light and speaker cutouts.

Easy-Carry Strap

Utilize the included braided strap for convenient and secure carrying. The strap can be worn around your wrist or easily attached to a bag or belt buckle, ensuring your AirPods Pro 3 are always within reach.

Powerful Drop Protection

Double the defense

Shock-absorbing core

Ultra-hard shell



Image: Demonstrates the easy-carry strap being used to attach the case to a wrist.

MAINTENANCE

Cleaning the Case

To clean your ESR Orbit Hybrid Magnetic Case, wipe it with a soft, damp cloth. For hard-to-reach areas or accumulated

dust, use the provided cleaning brush. Avoid harsh chemicals or abrasive materials that could damage the case finish.



Image: Illustration of using the cleaning brush to maintain the case.

Removing the Case

Should you need to remove your AirPods Pro 3 from the case, use the easy-removal tool provided. Insert the tool into the designated slot and gently pry the case open. This prevents damage to both your AirPods case and the ESR protective cover.



Image: Demonstration of using the easy-removal tool to safely detach the case.

TROUBLESHOOTING

- **Lid not staying closed:** The magnetic lock is designed to keep the lid secure. In rare instances of extreme impact from a high drop, the lid may open. Ensure the case is properly installed and the magnetic latch is engaged.
- **Wireless charging issues:** Ensure your MagSafe charger is properly connected and functioning. Verify that the AirPods Pro 3 case is correctly aligned on the MagSafe charger. The ESR case is designed for seamless wireless charging.
- **"Find My" alerts are muffled:** Check that the speaker cutouts on the bottom of the case are not obstructed by debris or improper installation.

SPECIFICATIONS

Brand	ESR
Compatible Devices	AirPods Pro 3 (2025)
Form Factor	Case
Shell Type	Case
Additional Features	Heavy Duty Protection, MagSafe Compatible, Lanyard
Material	Polycarbonate, Thermoplastic Polyurethane
Item Dimensions	2.68 x 2.06 x 1.04 inches

Item Weight

30.7 Grams

Snap and Charge

Compatible with all wireless charger types



*MagSafe charger and cables not included.

Image: Diagram illustrating the dual-layer drop protection with shock-absorbing core and ultra-hard shell.

WARRANTY AND SUPPORT

ESR provides a comprehensive 12-month protection plan for this product. For detailed setup videos, FAQs, unlimited support, and personalized assistance, please visit the official ESR support website or contact customer service. For further assistance, please visit: [ESR Support](#)