Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON GM_DINING_TABLE_FOR_6

GAOMON 71 Inch Farmhouse Dining Table User Manual

Model: GM_DINING_TABLE_FOR_6

Introduction

Thank you for choosing the GAOMON 71 Inch Long Farmhouse Dining Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new dining table. Please read these instructions carefully before assembly and retain them for future reference.

Safety Information

- Always assemble the table on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 350 pounds.
- Keep small parts and packaging materials away from children.
- Two adults are recommended for assembly to ensure safety and ease of installation.
- Pay attention to measures to prevent tipping, falling, and moving of the table during and after assembly.

Package Contents

Before beginning assembly, verify that all parts listed in the assembly guide are present and undamaged. The package includes:

- Tabletop components
- Leg components
- Hardware kit (screws, bolts, washers, etc.)
- Assembly Guide
- Installation tools (e.g., Allen wrench)

Note: Chairs are not included with this dining table.

Setup and Assembly

Assembly of the GAOMON Farmhouse Dining Table is designed to be straightforward. Each screw and accessory is labeled with corresponding numbers for easy identification. Please follow the detailed instructions provided in the included Assembly Guide.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the parts list in the Assembly Guide to identify each component and hardware piece.
3. **Attach Legs:** Securely attach the table legs to the tabletop using the provided hardware. Ensure the V-shaped structure of the legs is correctly oriented for stability.
4. **Tighten Fasteners:** Once all components are in place, tighten all screws and bolts firmly. Do not overtighten.
5. **Position Table:** With assistance, carefully flip the table upright and move it to its desired location. The non-slip foot pads will protect your floor.

Tools Recommended: Screw Driver (not included, but typically needed for some fasteners).



Figure 1: Table dimensions and seating capacity. The table measures 70.87" L x 35.4" W x 30" H and can accommodate 6 to 8 people.



Figure 2: Illustration of the table's sturdy and durable construction, highlighting thick legs and a maximum load capacity of 350 lbs.



Figure 3: Visual representation of the easy assembly process, emphasizing detailed instructions and numbered parts.

Your browser does not support the video tag.

Video 1: Official GAOMON video demonstrating the assembly and features of the Farmhouse 71-inch long dining table. This video provides a visual guide to the product.

Operating Instructions

The GAOMON Farmhouse Dining Table is designed for versatile use in various settings. It can comfortably seat 6 to 8 people, making it suitable for family meals, gatherings, or as a functional workspace.

- **Seating Capacity:** The table is designed to accommodate 6 to 8 individuals.
- **Versatile Use:** This table can function as a dining table, kitchen table, meeting table, executive desk, computer desk, gaming desk, or craft desk.
- **Weight Distribution:** Distribute weight evenly across the tabletop to maintain stability and prevent damage.
- **Floor Protection:** The specially designed non-slip foot pads protect your floor from scratches when moving the table.



Figure 4: The dining table arranged for a meal, demonstrating its capacity and aesthetic appeal in a home setting.



Figure 5: An overhead view of the table, showcasing its ample surface area for dining or other activities.

Your browser does not support the video tag.

Video 2: Official GAOMON video showcasing the Farmhouse Dining Table in a home environment, demonstrating its size and suitability for various uses.

Maintenance and Care

Proper care will ensure the longevity and appearance of your GAOMON Farmhouse Dining Table. The tabletop features a wood grain finish that is waterproof and easy to clean.

- **Cleaning:** Wipe the table surface with a damp cloth to remove spills and dust. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining, especially on the wood grain finish.
- **Protection:** Use placemats or coasters to protect the surface from hot items, scratches, and moisture rings.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood

finish.

- **Regular Checks:** Periodically check all fasteners and re-tighten them as needed to maintain stability.



Figure 6: Detail of the table's wood grain finish, illustrating its waterproof and dustproof characteristics for easy cleaning.

Troubleshooting

This section addresses common issues you might encounter with your dining table.

Problem	Possible Cause	Solution
Table feels wobbly or unstable.	Loose fasteners; uneven floor.	Check and tighten all screws and bolts. Ensure the table is on a level surface. Adjust non-slip foot pads if possible.

Problem	Possible Cause	Solution
Scratches or marks on the tabletop.	Sharp objects; lack of protective measures.	Use placemats or tablecloths to protect the surface. For minor scratches, consider wood repair kits (consult manufacturer for recommendations).
Difficulty cleaning spills.	Spill left for too long; incorrect cleaning agent.	Wipe spills immediately with a damp cloth. Avoid harsh chemicals. For stubborn stains, a mild soap solution can be used, followed by drying.

Specifications

Feature	Detail
Brand	GAOMON
Model Name	GM_DINING_TABLE_FOR_6
Product Dimensions (L x W x H)	70.87" x 35.4" x 30"
Item Weight	87 pounds
Maximum Weight Recommendation	350 pounds
Frame Material	Engineered Wood
Top Material Type	Engineered Wood
Color	Black (for this variant)
Shape	Rectangular
Style Name	Farmhouse
Furniture Finish	Rustic
Tabletop Thickness	Approximately 4.9 inches (thickest part)
Seating Capacity	6-8 people
Indoor/Outdoor Usage	Indoor
Included Components	Assembly Guide
UPC	199414290364

Warranty Information

Specific warranty details for the GAOMON 71 Inch Long Farmhouse Dining Table are not provided in the available product data. For information regarding warranty coverage, terms, and conditions, please contact GAOMON customer support directly or refer to the documentation included with your purchase.

Customer Support

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact GAOMON customer support. Refer to the contact information provided in your product packaging or visit the official GAOMON website for support options.

© 2026 GAOMON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGXXYWBT

More documents and user manuals: **https://manuals.plus/**