

HP HP DeskJet 4252e All-in-One Printer

HP DeskJet 4252e Wireless All-in-One Color Inkjet Printer

MODEL: HP DESKJET 4252E ALL-IN-ONE PRINTER

PRODUCT OVERVIEW

The HP DeskJet 4252e All-in-One Printer is designed for home use, offering versatile color printing, scanning, and copying capabilities. It features a 60-sheet paper capacity and an auto document feeder for efficient handling of various tasks. This wireless inkjet printer provides a straightforward and stress-free experience for all your printing needs, from documents to recipes.

Key Features:

- **All-in-One Functionality:** Color print, copy, and scan.
- **Document Handling:** Flatbed scanner and auto document feeder for easy scanning and copying.
- **Paper Capacity:** Equipped with a 60-sheet input tray.
- **Wireless Connectivity:** Reliable Wi-Fi that automatically detects and resolves connection issues.
- **Mobile Printing:** Utilize the HP app to print, scan, copy, or fax directly from your smartphone.
- **Print Speed:** Up to 8 pages per minute (ppm) for black and 5 ppm for color.

SETUP GUIDE

Setting up your HP DeskJet 4252e printer is a simple process, often completed within minutes using the HP app. Follow these general steps for initial setup:

1. **Unpack the Printer:** Carefully remove the printer from its packaging and remove all protective tapes and packing materials.
2. **Connect Power:** Plug the power cord into the printer and then into a wall outlet.
3. **Install Ink Cartridges:** Open the ink cartridge access door and install the provided HP ink cartridges according to the instructions on the printer's display or the HP app.
4. **Load Paper:** Load plain white paper into the input tray.

5. **Install HP Smart App:** Download and install the HP Smart app on your smartphone or computer. This app guides you through the wireless setup and registration process.
6. **Connect to Wi-Fi:** Follow the on-screen instructions in the HP Smart app to connect your printer to your wireless network. The app simplifies the connection process.
7. **Complete Setup:** Once connected, the app will guide you through any remaining steps, such as registering for HP Instant Ink if desired, and performing an alignment page print.



Figure 1: Front view of the HP DeskJet 4252e All-in-One Printer.

OPERATING THE PRINTER

Loading Paper:

The HP DeskJet 4252e features an easy-to-access rear paper input tray. Simply lift the paper input tray cover, adjust the paper guides to fit your paper size, and load the paper with the print side facing up. Ensure the paper is properly aligned to prevent jams.



Figure 2: The HP DeskJet 4252e printer with paper loaded in the input tray, ready for printing.

Scanning Documents:

The printer includes both a flatbed scanner and an auto document feeder (ADF) for scanning. For single pages or delicate items, use the flatbed scanner by lifting the scanner lid and placing the document face down on the glass. For multiple pages, use the ADF by placing the stack of documents face up in the feeder tray. Initiate the scan from the HP Smart app on your device.



Figure 3: Top view of the printer, highlighting the scanner bed and the automatic document feeder.

Control Panel:

The control panel provides intuitive buttons for basic operations and status indicators. These include buttons for canceling jobs, resuming, information, Wi-Fi status, and copy functions. The display shows ink levels and other important alerts.



Figure 4: Close-up view of the printer's control panel, showing various function buttons and the display screen.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your HP DeskJet 4252e printer.

- **Ink Cartridges:** Replace ink cartridges when prompted by the printer or the HP Smart app. Consider enrolling in HP Instant Ink for automatic ink delivery when levels are low.
- **Cleaning:** Periodically clean the exterior of the printer with a soft, damp, lint-free cloth. For the scanner glass, use a glass cleaner applied to the cloth, not directly to the glass.
- **Paper Handling:** Use recommended paper types and store paper in a dry, cool place to prevent curling or sticking.
- **Firmware Updates:** Keep your printer's firmware updated through the HP Smart app to ensure compatibility and access to the latest features.

TROUBLESHOOTING

If you encounter issues with your printer, try the following common troubleshooting steps:

- **Printer Not Responding:** Ensure the printer is powered on and connected to the network. Restart both the printer and your computer/device.
- **Print Quality Issues:** Check ink levels. Run a print head cleaning or alignment utility from the HP Smart

app or printer software.

- **Paper Jams:** Carefully remove any jammed paper from the input tray, output tray, or inside the printer as indicated by the printer's display.
- **Wireless Connection Problems:** Verify your Wi-Fi network is active. Restart your router and printer. Use the HP Smart app's network diagnostic tools.
- **HP Smart App Issues:** Ensure the app is updated to the latest version. Restart the app or reinstall it if problems persist.

For more detailed troubleshooting, refer to the HP support website or the help section within the HP Smart app.

SPECIFICATIONS

Feature	Detail
Brand	HP
Model Name	HP DeskJet 4252e All-in-One Printer
Product Dimensions	13.07 x 16.85 x 7.87 inches
Printing Technology	Inkjet
Connectivity Technology	Wi-Fi
Printer Output	Color
Max Print Speed (Black)	8 ppm
Max Print Speed (Color)	5 ppm
Sheet Size Support	Plain paper, photo paper, brochure paper, envelopes, and other specialty inkjet papers
Included Components	Printer
UPC	724129332827

WARRANTY AND SUPPORT

The HP DeskJet 4252e All-in-One Printer comes with a **90 days limited warranty**. For warranty claims or technical assistance, please contact HP customer support or visit the official HP support website. Ensure you have your product model and serial number ready for faster service.

For additional resources, including drivers, software, and detailed user guides, please visit www.hp.com/support.

