

Electactic 58090RRE0-BLACK

Electactic 3.2 Cu.ft Mini Fridge with Freezer User Manual

Model: 58090RRE0-BLACK

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new mini fridge. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the appliance is properly grounded.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the refrigerator before cleaning or performing maintenance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

2. PRODUCT OVERVIEW

The Electactic 3.2 Cu.ft Mini Fridge with Freezer is a compact and energy-efficient refrigeration solution designed for various small spaces such as offices, dorms, bedrooms, and apartments. It features a reversible door, adjustable thermostat, and low noise operation.



Image: Front view of the Electactic 3.2 Cu.ft Mini Fridge with its door open, showcasing its interior filled with various food items and beverages.

Quiet Operation

Won't disrupt your sleeping or working



43dB



10dB
Breath

30dB
Library

Our
Refrigerator

60dB
Street

Image: A closer look at the main refrigeration compartment, displaying fresh fruits, vegetables, and milk bottles on the glass shelves.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Inspect the refrigerator for any shipping damage. Keep packaging materials out of reach of children.

3.2 Placement

Choose a location with a solid, level floor that can support the refrigerator when fully loaded. Allow at least 4 inches (10 cm) of space between the back and sides of the refrigerator and any adjacent walls to ensure proper air circulation and cooling efficiency. Avoid direct sunlight or heat sources.



Image: Examples of suitable placement for the mini fridge in different environments, including an office, RV, lounge area, and kitchen.

3.3 Leveling the Appliance

The refrigerator has adjustable leveling legs at the front. Turn the legs clockwise to raise the refrigerator or counter-clockwise to lower it. Ensure the refrigerator is level to prevent vibrations and ensure proper door sealing.




Image: Detail of the 360-degree adjustable leveling leg, indicating its function for stabilizing the unit.

3.4 Reversible Door Installation

The door of the refrigerator is reversible, allowing it to open from either the left or right side to suit your space requirements. Refer to the detailed instructions provided in the separate door reversal kit (if included) or contact customer support for guidance on this procedure.



Image: The mini fridge with its door open, illustrating the reversible door feature with arrows showing the ability to change the door swing direction.

3.5 Initial Cleaning and Power Connection

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and mild detergent. After cleaning, allow the refrigerator to stand upright for at least 2-4 hours before plugging it into a grounded 115 Volt AC outlet. This allows the refrigerant to settle.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator features a rotary thermostat button located inside the unit. This allows you to adjust the temperature

settings. The freezer compartment has a temperature range of 30°F to 48°F (-1°C to 8°C). The main fridge compartment offers 7 variable temperature settings to suit your cooling needs. Turn the knob to a higher number for colder temperatures and a lower number for warmer temperatures.



Image: A detailed view of the internal rotary thermostat knob, showing temperature settings from 1 to 7.

4.2 Storage and Organization

The refrigerator includes adjustable glass shelves, allowing you to customize the interior space to accommodate items of various sizes. The door features a large-capacity chamber, ideal for storing frequently used beverage bottles or cans, optimizing internal storage.



Image: An infographic highlighting the main features of the 3.2 Cu.ft Mini Fridge, including the half-width freezer, temperature control, large door chamber, and drip tray.

4.3 Freezer Compartment

The compact freezer compartment is suitable for making ice cubes and keeping certain foods fresh. Please note that the temperature range of the freezer is not suitable for storing ice cream or items requiring deep freezing.



Image: A close-up view of the half-width freezer compartment, designed for ice cubes and small frozen items.

4.4 Low Noise Operation

The refrigerator operates at a low noise level of 38 dB, ensuring minimal disturbance in quiet environments such as bedrooms or offices. This allows for peaceful rest and work without significant noise interference.



Image: An illustration demonstrating the quiet operation of the refrigerator, comparing its 43dB noise level to common ambient sounds.

5. MAINTENANCE

5.1 Defrosting

This refrigerator features manual defrost. Frost will accumulate on the inner walls of the freezer compartment. When the frost layer becomes about 0.2 inches (5 mm) thick, defrost the appliance. To defrost, unplug the refrigerator, remove all food items, and leave the door open. Place the included drip tray beneath the freezer compartment to collect melted water. Do not use sharp objects to remove frost.



Image: A close-up view of the drip tray, which is used to collect water during the manual defrosting process.

5.2 Cleaning

Regularly clean the interior and exterior of the refrigerator. For the interior, use a solution of mild detergent and warm water. Wipe dry thoroughly. For the exterior, use a soft cloth and mild cleaner. Avoid abrasive cleaners or solvents that may damage the surface. Clean the condenser coils at the back of the unit periodically to maintain efficiency.

5.3 Power Outage

In case of a power outage, keep the refrigerator door closed to maintain internal temperature for as long as possible. Avoid opening the door unnecessarily. If the outage is prolonged, consider transferring perishable items to a cooler with ice.

5.4 Moving the Appliance

When moving the refrigerator, secure all loose items inside. Lift the unit by its base, avoiding lifting by the door or handle. After moving, allow the refrigerator to stand upright for at least 2 hours before plugging it back in.

6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate	No power; Plug not fully inserted; Circuit breaker tripped.	Check power supply; Ensure plug is secure; Reset circuit breaker.
Temperature is not cold enough	Temperature setting too high; Door opened too frequently; Excessive food load; Poor ventilation.	Adjust thermostat to a colder setting; Minimize door openings; Reduce food load; Ensure adequate clearance around unit.
Unusual noises	Refrigerator not level; Objects vibrating against unit; Normal operating sounds.	Adjust leveling legs; Ensure nothing is touching the unit; Gurgling or humming sounds are normal.
Water on floor or inside unit	Drain tube clogged; Door not sealed properly; High humidity.	Clear drain tube; Check door gasket for proper seal; This can be normal in humid conditions.

If the problem persists after checking these solutions, please contact customer support.

7. SPECIFICATIONS

Detailed technical specifications for the Electactic 3.2 Cu.ft Mini Fridge:

Feature	Specification
Brand Name	Electactic
Model Info	58090RRE0-BLACK
Item Weight	37.4 pounds
Product Dimensions (D x W x H)	19.29 x 17.52 x 30.71 inches
Capacity	3.2 Cubic Feet
Annual Energy Consumption	219 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	2.91 Cubic Feet
Freezer Capacity	0.29 Cubic Feet
Installation Type	Freestanding
Special Features	Adjustable Shelves, Compact, Low Noise
Color	Black
Voltage	115 Volts
Defrost System	Manual
Door Hinges	Reversible
Shelf Type	Glass
Number of Shelves	2
Included Components	Drip Tray
Number Of Doors	1

8. WARRANTY AND SUPPORT


8.1 Warranty Information

Specific warranty details for your Electactic Mini Fridge are typically provided with your purchase documentation or on the product registration card. Please refer to these materials for information regarding warranty coverage, duration, and terms. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the seller or manufacturer directly. Contact information can usually be found on the product packaging, purchase invoice, or the manufacturer's official website.

Related Documents

	<p>Electactic NCAA-08C/X1E Room Air Conditioner Energy Guide</p> <p>EnergyGuide label for the Electactic NCAA-08C/X1E Room Air Conditioner, detailing estimated yearly energy cost, cost range of similar models, and Combined Energy Efficiency Ratio.</p>
---	---