



Manuals.plus /

› CRAFTSMAN /

› CRAFTSMAN Vertical Storage Shed BMSC2050 Instruction Manual

CRAFTSMAN BMSC2050

CRAFTSMAN Vertical Storage Shed Instruction Manual

Model: BMSC2050

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your CRAFTSMAN Vertical Storage Shed, model BMSC2050. Designed for organizing tools, gardening gear, and other items, this shed offers a customizable interior and durable, weather-resistant construction. Please read all instructions carefully before beginning assembly or use.



Image: The Craftsman Vertical Storage Shed, model BMSC2050, shown installed on a patio, demonstrating its compact vertical design suitable for various outdoor spaces.

SAFETY WARNINGS

Always check the product packaging and instructions for specific safety warnings before assembly and use. Failure to follow safety guidelines may result in injury or damage to the product.

SETUP AND ASSEMBLY

The CRAFTSMAN Vertical Storage Shed is designed for easy assembly with minimal tools. Ensure you have a clear, level surface for installation.

Preparation:

- Unpack all components and verify against the parts list provided in the packaging.
- Ensure the chosen installation site is level and clear of debris.
- Gather necessary tools (e.g., screwdriver, hammer, safety glasses).

Assembly Steps:

1. Follow the step-by-step instructions included in your product packaging for panel and door assembly.
2. Connect the multi-wall resin panels securely to form the shed structure.
3. Attach the doors and ensure they open and close smoothly.
4. Install the roof section, ensuring a tight, weather-resistant seal.







Image: Interior view of the shed, highlighting the multi-wall resin panels and built-in supports for optional shelving, ideal for organizing various tools.

OPERATING INSTRUCTIONS

Storage Capacity:

The tall profile of this shed is specifically designed for storing long-handled tools, ladders, and various garden supplies. The interior can support up to four shelves (not included), allowing for customizable organization. Compatible shelf models include BMSASHELFV1, BMSBSKT2PK, V7572PK, and V724BLD.

Security:

The shed features pad-lockable resin handles for added security. A padlock is not included and must be purchased separately.



Image: A close-up of the shed's resin handles, demonstrating the pad-lockable design for enhanced security of stored items.

MAINTENANCE

The CRAFTSMAN Vertical Storage Shed is constructed from durable, multi-wall resin, making it low maintenance and easy to clean.

- **Cleaning:** Periodically wipe down the exterior with a damp cloth and mild soap to remove dirt and debris. Avoid abrasive cleaners.
- **Weather Protection:** The all-weather construction provides water resistance and UV protection, minimizing the need for extensive weatherproofing.
- **Inspection:** Regularly inspect the shed for any signs of wear or damage, especially after severe weather conditions. Ensure all panels and doors remain securely fastened.

TROUBLESHOOTING

This section addresses common issues you might encounter with your storage shed.

Problem	Possible Cause	Solution
Doors do not close properly.	Uneven ground; panels not aligned correctly.	Ensure the shed is on a perfectly level surface. Recheck panel connections for proper alignment.
Water leakage inside the shed.	Improper roof installation; damaged seals.	Verify the roof is securely attached and sealed. Inspect for any cracks or damage to the resin panels or seals.
Difficulty locking handles.	Misaligned doors; obstruction.	Adjust door alignment. Ensure no debris is obstructing the handles or latch mechanism.

SPECIFICATIONS

Feature	Detail
Brand	CRAFTSMAN
Model Number	BMSC2050
Primary Material	Resin (Multi-wall construction)
Frame Material	Metal
Color	Dovetail Gray
Product Dimensions (D x W x H)	24.75"D x 32.25"W x 72"H
Item Weight	28.35 Kilograms
Door Style	Single Hinged Door
Water Resistance Level	Water Resistant
Required Assembly	Yes
Shelf Support	Built-in support for wood shelf (shelf not included)
Compatible Accessories	BMSASHELFV1, BMSBSKT2PK, V7572PK, & V724BLD
Manufacturer	Suncast
UPC	044365026350

WARRANTY INFORMATION

Specific warranty details for the CRAFTSMAN Vertical Storage Shed are typically provided with the product packaging or can be found on the official CRAFTSMAN website. Please refer to these resources for the most accurate and up-to-date warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your CRAFTSMAN Vertical Storage Shed, please contact CRAFTSMAN customer support. Contact information can usually be found on the product packaging, the official CRAFTSMAN website, or through your retailer.

