



Manuals.plus /

› **BORNOON** /

› BORNOON Shoe Cabinet 4-Drawer Basic White - Instruction Manual

BORNOON 4-Drawer - Basic

BORNOON Shoe Cabinet (4-Drawer, Basic White)

Model: 4-Drawer - Basic White

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BORNOON 4-Drawer Basic White Shoe Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The BORNOON 4-Drawer Basic White Shoe Cabinet in its closed state, showcasing its sleek design.

SAFETY INFORMATION

To ensure safe use of your shoe cabinet, please observe the following precautions:

- **Anti-Tip Device:** Always secure the cabinet to the wall using the provided anti-tip kit to prevent accidental tipping. This is crucial for households with children or pets.
- **Clearance:** Keep the area around the cabinet clear of obstacles to prevent accidents.
- **Load Capacity:** Do not overload the drawers. Distribute weight evenly to maintain the stability of the cabinet.
- **Assembly:** Always follow the assembly instructions carefully to ensure safe and correct installation.



Image: Visual representation of the anti-tip design, showing how to secure the cabinet to a wall for enhanced stability and safety.

PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. Refer to the included assembly instructions for a complete list of components. If any parts are missing or damaged, please contact customer support.

SETUP AND ASSEMBLY

Assembly is required for this shoe cabinet. All parts are labeled for easy identification, and detailed instructions are included in your package. An electric screwdriver may expedite the process. It is recommended to have two people for certain steps to ensure stability during construction.

Key Assembly Features:

- **Adjustable Shelves:** The internal dividers within each flip drawer can be adjusted to accommodate different shoe heights.
- **Removable Panels:** For larger footwear, panels can be removed to create more space within a drawer.
- **Anti-Tip Mechanism:** A wall-mounting anti-tipping kit is provided and must be installed to secure the cabinet.




Image: Detailed view of the cabinet's features, including adjustable and removable shelves, the anti-tip mechanism, and overall dimensions (9.45"D x 47.24"W x 32.28"H).

Assembly Video Guide:

Your browser does not support the video tag.

Video: Detailed assembly instructions for the shoe cabinet (2:08 duration).

Your browser does not support the video tag.

Video: Alternative assembly guide for the shoe cabinet (1:59 duration).

OPERATING INSTRUCTIONS

The BORNOON shoe cabinet features four flip-out drawers designed for easy access and organization.

- **Opening Drawers:** Gently pull the top edge of each drawer outwards to flip it open.
- **Storing Shoes:** Place shoes on the two-tier organizer within each drawer. Adjust or remove panels as needed to fit different shoe types (e.g., sneakers, high heels, ankle boots). The cabinet can store up to 24 pairs of shoes, depending on their size and style.
- **Closing Drawers:** Push the drawer back into the cabinet until it is flush with the cabinet front.



Image: Demonstration of the flip-out drawers in both open and closed positions, highlighting the cabinet's functionality.

Perfect for all kinds of shoes



Image: The shoe cabinet accommodating different types of footwear, from sneakers to high heels, demonstrating its versatile storage.

Product Features Overview:

Your browser does not support the video tag.

Video: A brief overview of the shoe cabinet's features and functionality (0:33 duration).

MAINTENANCE

To maintain the appearance and longevity of your shoe cabinet:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, consider the following:

- **Drawers not closing properly:** Ensure no shoes are obstructing the closing mechanism. Check if the internal panels are correctly seated. Verify that the cabinet is level.
- **Cabinet wobbles:** Confirm that all assembly screws are tightened. Ensure the cabinet is placed on a flat, stable surface. Re-check the anti-tip device installation.
- **Missing or damaged parts:** Refer to the "Warranty & Support" section for assistance.

SPECIFICATIONS

| Feature | Detail |
|--------------------|--|
| Brand | BORNOON |
| Model | 4-Drawer - Basic White |
| Product Dimensions | 9.45"D x 47.24"W x 32.28"H |
| Material | Engineered Wood |
| Mounting Type | Freestanding (with anti-tip wall anchor) |
| Number of Drawers | 4 |
| Storage Capacity | Up to 24 pairs of shoes (depending on type/size) |
| Special Features | Adjustable/Removable Panels, Anti-Tip Safety |

WARRANTY & SUPPORT

BORNOON offers support for your product. We provide free replacements for any missing or damaged parts encountered during shipping or assembly. If you have any questions or issues regarding your shoe cabinet, please contact our customer support team. We are committed to assisting you within 24 hours.

For assistance, please refer to the contact information provided with your purchase documentation or visit the official BORNOON store on Amazon: [BORNOON Store](#)