



Manuals.plus /

› ESR /

› ESR Cyber Series Case for AirPods Pro 3 (2025) - Instruction Manual

ESR AirPods Pro 3 Case

ESR Cyber Series Case for AirPods Pro 3 (2025) - Instruction Manual

Model: AirPods Pro 3 Case

1. PRODUCT OVERVIEW

The ESR Cyber Series Case is designed to provide robust protection and enhanced functionality for your AirPods Pro 3 (2025) charging case. It features a secure FlickLock mechanism, MagSafe compatibility, and comprehensive drop protection.

Key Features:

- **Compatibility:** Specifically designed for AirPods Pro 3 (2025) with USB-C charging. Not compatible with previous AirPods Pro generations or AirPods 4.
- **Secure FlickLock:** Integrated magnets and an internal latch ensure the case lid remains securely closed, preventing accidental opening and loss of earbuds.
- **Effortless One-Handed Access:** A sliding latch mechanism allows for quick and easy opening of the case with a single hand.
- **MagSafe Charging:** Strong magnets enable secure attachment and efficient wireless charging with MagSafe compatible chargers.
- **360° Drop Protection:** Constructed from shock-absorbing polymer with Air Guard corners to protect against drops and impacts.
- **Portable Design:** Includes a carabiner for easy attachment to bags or clothing.
- **User-Friendly Indicators:** Features a visible status light for charging indication and speaker cutouts for clear Find My alerts.

2. SETUP AND INSTALLATION

Follow these steps to properly install your AirPods Pro 3 charging case into the ESR Cyber Series Case.

1. **Prepare the Case:** Ensure your AirPods Pro 3 charging case is clean and free of debris.
2. **Insert Bottom Half:** Carefully place the bottom half of your AirPods Pro 3 charging case into the bottom

section of the ESR Cyber Series Case. Ensure it fits snugly.

3. **Attach Top Half:** Place the top half of the ESR Cyber Series Case over the lid of your AirPods Pro 3 charging case. Press firmly to ensure it is securely attached. An adhesive strip is included for additional lid security if desired.
4. **Verify Fit:** Check that the case is fully enclosed and the FlickLock mechanism operates smoothly.

User Friendly

Visible Status Light
Charging indicator



Speaker Cutouts
Hear Find My alerts loud and clear

Image: Visual guide for installing the AirPods Pro 3 charging case into the ESR Cyber Series Case, showing the separate top and bottom pieces and how they fit together.



Image: The case comes with a cleaning brush, an easy-removal tool, and an adhesive strip for the lid.

3. OPERATING INSTRUCTIONS

3.1 Opening the Case (FlickLock Mechanism)

The ESR Cyber Series Case features a FlickLock mechanism for secure closure and easy access.

- To open, simply slide the latch located on the front of the case. The internal magnets will assist in springing the lid open, providing instant access to your AirPods Pro 3.
- To close, gently push the lid down until the latch clicks into place, securing your AirPods Pro 3.

Drop-Proof FlickLock™

Stronger magnets and internal latch keeps lid securely closed

✓ ESR



✗ Others



Image: The FlickLock mechanism ensures the case lid remains securely closed, preventing accidental opening.

Easy Open With One Hand

20,000+ uses
Durable and long lasting



Magnets
automatically open case

*Data based on ESR lab testing

Image: Demonstrates the easy one-handed opening of the case by sliding the front latch.

3.2 Charging

The ESR Cyber Series Case supports both wired and wireless charging for your AirPods Pro 3.

- **Wired Charging:** Connect a USB-C cable to the charging port at the bottom of the case.
- **MagSafe Wireless Charging:** Align the back of the case with a MagSafe compatible wireless charger. The strong magnets will ensure a secure connection for efficient charging.
- **Charging Indicator:** The visible LED status light on the front of the case will indicate the charging status of your AirPods Pro 3.

Added Extras

Comes with a cleaning brush, easy-removal tool, and adhesive strip for lid



Image: The case securely attaches to a MagSafe charger for wireless charging.



Easy to Carry

Hook anywhere on the go



Image: Close-up view showing the visible charging status light and speaker cutouts for Find My alerts.

3.3 Portability

The included carabiner allows for convenient portability.

- Attach the carabiner to your backpack, belt loop, or other secure points for easy access and to prevent misplacement.

Ultimate Protection

Air Guard corners protection



Image: The case with its carabiner attached to a backpack, demonstrating its portability.

4. MAINTENANCE

To ensure the longevity and optimal performance of your ESR Cyber Series Case, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, or slightly damp cloth to wipe down the exterior of the case. For hard-to-reach areas, utilize the included cleaning brush to remove dust and debris. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Avoid Excessive Force:** While the FlickLock mechanism is durable, avoid applying excessive force

when opening or closing the case to prevent damage.

5. TROUBLESHOOTING

If you encounter any issues with your ESR Cyber Series Case, refer to the following common solutions:

- **Case Not Closing Securely:**
 - Ensure the AirPods Pro 3 charging case is correctly seated within the ESR case.
 - Check for any debris obstructing the FlickLock mechanism or the lid's closure.
 - If an adhesive strip was used, ensure it is properly aligned and still providing adhesion.
- **Wireless Charging Issues:**
 - Verify that your wireless charger is MagSafe compatible and functioning correctly.
 - Ensure the ESR case is properly aligned with the wireless charger's charging coil.
 - Confirm that your AirPods Pro 3 charging case itself supports wireless charging and is not damaged.
- **Difficulty Opening the Case:**
 - Ensure the sliding latch is fully engaged and not obstructed.
 - If the case feels stiff, check for any foreign objects.

6. SPECIFICATIONS

Brand	ESR
Model	AirPods Pro 3 Case
Compatible Devices	AirPods Pro 3 (2025) (USB-C Cable)
Form Factor	Case
Shell Type	Case
Additional Features	Heavy Duty Protection, MagSafe Compatible, FlickLock Mechanism
Material	Polycarbonate, Thermoplastic Polyurethane
Item Dimensions (L x W x H)	2.6 x 2.12 x 1.32 inches
Item Weight	33.7 Grams (1.189 oz)

7. WARRANTY AND SUPPORT

ESR is committed to providing excellent customer service and product support.

- **Warranty:** This product includes a comprehensive 12-month protection plan.
- **Customer Support:** For detailed setup videos, FAQs, or personalized assistance, please visit the official ESR website or contact their customer support team. Unlimited support is available.

8. PRODUCT VIDEOS

Your browser does not support the video tag.

Video: Official product video demonstrating the ESR Cyber Series Case for AirPods Pro 3, highlighting its drop-proof FlickLock, effortless MagSafe charging, and easy-to-carry design. This video is provided by Minghutech-US (Seller).