

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wentronic](#) /

› [Wentronic Y04 Bluetooth Active Noise Cancelling Headphones User Manual](#)

## Wentronic Y04

# Wentronic Y04 Bluetooth Active Noise Cancelling Headphones User Manual

Model: Y04

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Wentronic Y04 Bluetooth Active Noise Cancelling Headphones. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image: The Wentronic Y04 headphones displayed in multiple color options, highlighting the brand and model.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- Wentronic Y04 Bluetooth Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)



Image: A visual representation of the items included in the Wentronic Y04 headphone package, including the headphones, cables, and manual.

## HEADPHONE COMPONENTS

Familiarize yourself with the various parts and controls of your Y04 headphones:



Image: A silver Wentronic Y04 headphone, showcasing its overall design and the location of buttons and ports on the earcups.

- **Power Button:** Used to turn the headphones on or off.
- **Volume Up/Next Track Button:** Press briefly to increase volume, press and hold to skip to the next track.
- **Volume Down/Previous Track Button:** Press briefly to decrease volume, press and hold to go to the previous track.
- **Multi-function Button (MFB):** Play/pause music, answer/end calls.
- **ANC Button:** Activates or deactivates Active Noise Cancellation.
- **USB-C Charging Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection.
- **Microphone:** For voice calls.



Image: A close-up of the headphone headband, illustrating its multi-level adjustment mechanism for a customized fit.



Image: A detailed view of the headphone's earpads, emphasizing their soft, skin-friendly material designed for comfort.

## SETUP

### Charging the Headphones

1. Connect the provided USB-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, blue for fully charged).
4. A full charge typically takes approximately 2-3 hours.

### Powering On/Off

- **To Power On:** Press and hold the Power button for 3 seconds until the LED indicator flashes blue.
- **To Power Off:** Press and hold the Power button for 3 seconds until the LED indicator turns off.

### Bluetooth Pairing

The Y04 headphones utilize Bluetooth 5.3 for stable and efficient wireless connectivity.




Image: Wentronic Y04 headphones placed next to a laptop, symbolizing their wide compatibility with various devices via Bluetooth 5.3.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately. This indicates pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Y04" from the list of found devices.
5. Once connected, the LED indicator on the headphones will flash blue slowly, and you will hear an audible confirmation.
6. The headphones will automatically attempt to reconnect to the last paired device when powered on.

## OPERATING YOUR HEADPHONES

### Music Playback Controls

Action	Button Press
Play/Pause	Short press MFB
Volume Up	Short press Volume Up button
Volume Down	Short press Volume Down button
Next Track	Long press Volume Up button
Previous Track	Long press Volume Down button

### Active Noise Cancellation (ANC)

The Y04 headphones feature Active Noise Cancellation technology to reduce ambient noise.

# Active Noise Cancellation

One-click to activate the noise cancellation mode and immerse yourself in your own world.



Image: A close-up of the headphone earcup, highlighting the dedicated button for activating Active Noise Cancellation, indicated by a blue glow.

- **To Activate ANC:** Press the ANC button once. The ANC indicator light will illuminate.
- **To Deactivate ANC:** Press the ANC button once again. The ANC indicator light will turn off.



Image: A person wearing the Wentronic Y04 headphones, illustrating the immersive experience provided by Active Noise Cancellation.

## Making and Receiving Calls



Image: A person wearing the Wentronic Y04 headphones, suggesting their use for crystal clear calls.

- **Answer Call:** Short press the MFB.
- **End Call:** Short press the MFB during a call.
- **Reject Call:** Long press the MFB when an incoming call rings.
- **Redial Last Number:** Double-press the MFB.

## Wired Mode

Use the included 3.5mm audio cable for a wired connection, especially when the battery is low or for devices without Bluetooth.

- Plug one end of the 3.5mm audio cable into the headphone's audio jack.
- Plug the other end into your audio source's 3.5mm port.
- In wired mode, Bluetooth and ANC functions may be limited or unavailable depending on battery level.

## MAINTENANCE

## Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging port and audio jack free of dust and debris.

## Storage



Image: The Wentronic Y04 headphones folded compactly, demonstrating their space-saving design for travel and storage.

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- The foldable design allows for compact storage and portability.

## Battery Care

# 48

Hrs

More than a whole day



Image: Wentronic Y04 headphones displayed with a prominent '48 Hrs' text, indicating their extended playtime on a single charge.

- Charge the headphones regularly, even if not used frequently, to maintain battery health.
- Avoid fully discharging the battery for extended periods.

## TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following table:

Problem	Possible Solution
Headphones do not power on	Ensure the headphones are charged. Connect to a power source and try again.
Cannot pair with device	Ensure headphones are in pairing mode (flashing red/blue). Turn off and on Bluetooth on your device. Move closer to the device.
No sound	Check volume levels on both headphones and connected device. Ensure headphones are properly paired or the 3.5mm cable is securely connected.

Problem	Possible Solution
ANC not working effectively	Ensure ANC is activated (indicator light on). ANC is most effective for low-frequency, constant noise.
Poor call quality	Ensure the microphone is not obstructed. Move to an area with less background noise. Check device's connection stability.

## PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	Y04
Connectivity Technology	Wireless (Bluetooth 5.3)
Headphones Jack	3.5 mm Jack
Noise Control	Active Noise Cancellation
Form Factor	Over Ear
Material	Plastic
Special Feature	Foldable, Noise Cancellation
Item Weight	1.34 pounds
Manufacturer	Wentronic

## WARRANTY INFORMATION

Wentronic products are designed and manufactured to the highest quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Wentronic website. Keep your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

If you require further assistance or have questions not covered in this manual, please contact Wentronic customer support through the retailer where you purchased the product or visit the official Wentronic website for contact information.

## Related Documents - Y04

	<p><b>Sicherheitsdatenblatt: Echtwachs weiß (Wentronic) - Artikelnummern 74368, 77750-77780</b></p> <p>Umfassendes Sicherheitsdatenblatt für Echtwachs weiß von Wentronic, inklusive Produktidentifikation, Gefahren, Handhabung, Lagerung, Erste-Hilfe-Maßnahmen, Brandbekämpfung, Umweltschutz und Transportinformationen.</p>
	<p><b><a href="#">Wentronic Product News August 2025: Cables, LED Candles &amp; Lighting</a></b></p> <p>Explore the latest product news from Wentronic, featuring high-performance DisplayPort cables and adapters, a variety of LED real wax candles, LED tea lights with timers, and wireless LED Christmas tree candles. Discover innovative lighting solutions for home and professional use.</p>
	<p><b><a href="#">Wentronic Produktpalette 2019: Umfassendes Zubehör für Unterhaltungselektronik</a></b></p> <p>Umfassender Produktkatalog 2019 von Wentronic, dem führenden Distributor für Unterhaltungselektronik-Zubehör. Entdecken Sie Produkte von Marken wie Goobay, Clicktronic, HP und mehr in Kategorien wie TV &amp; SAT, Audio/Video, Mobilgeräte, Computer, Netzwerk, Stromversorgung und mehr.</p>
	<p><b><a href="#">Wentronic Product News July 2025: Cables, Chargers, Hubs, and Mounts</a></b></p> <p>Explore the latest product offerings from Wentronic in July 2025, featuring USB-C cables, HDMI cables, fast chargers, slim USB hubs, speaker mounts, and DC extension cables. This brochure highlights high-quality accessories for various electronic devices.</p>
	<p><b><a href="#">Wentronic Product News: DisplayPort Cables &amp; LED Candles</a></b></p> <p>Explore the latest product news from Wentronic GmbH, featuring high-performance DisplayPort cables and a variety of LED candles, including real wax, tealights, and Christmas tree lights with timer functions.</p>
	<p><b><a href="#">Wentronic Product News July 2025: USB-C Cables, Chargers, Hubs, and More</a></b></p> <p>Explore the latest product releases from Wentronic in July 2025, featuring USB-C cables, high-speed HDMI cables, fast chargers, slim USB hubs, speaker mounts, and DC extension cables. Discover innovative and reliable accessories for all your connectivity needs.</p>