



Manuals.plus /

› BORNOON /

› BORNOON Shoe Cabinet with 4 Flip Drawers User Manual

BORNOON B0FH1VB719

BORNOON Shoe Cabinet with 4 Flip Drawers User Manual

Model: B0FH1VB719

Brand: BORNOON

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Always secure the cabinet to the wall using the provided anti-tip kit to prevent tipping. This is crucial for households with children or pets.
- Do not overload the cabinet as it may cause instability.
- Regularly inspect the cabinet for any signs of wear or damage.
- Follow the manufacturer's instructions for proper maintenance.
- Keep the cabinet away from heat sources and direct sunlight.
- Do not place heavy objects on top of the cabinet.



Image 1: Anti-Tip Safety Feature. Always install the anti-tip device to prevent accidents, especially in homes with children.

2. PACKAGE CONTENTS


Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Side, Back)
- Flip Drawers (4 units)
- Adjustable/Removable Dividers
- Hardware Pack (screws, dowels, cam locks, etc.)
- Anti-Tip Kit
- Assembly Instructions Manual

3. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 1-2 hours for one person. Do not use power tools for assembly, as this may damage the engineered wood material. Hand tools are recommended.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your included manual to identify each piece.
2. **Assemble the Main Frame:** Connect the side panels to the bottom panel using the provided hardware (e.g., dowels and cam locks). Ensure all connections are secure.
3. **Install Back Panels:** Slide or attach the back panels into the designated grooves or using small nails/screws.
4. **Assemble Flip Drawers:** For each of the four flip drawers, assemble the front panel, side panels, and the internal shoe organizer mechanism.
5. **Insert Adjustable Dividers:** Place the adjustable dividers into the slots within each flip drawer. These can be moved or removed based on shoe size and type.
6. **Attach Flip Drawers to Frame:** Securely attach the assembled flip drawers to the main cabinet frame using the hinge mechanisms. Test each drawer to ensure smooth operation.
7. **Install Anti-Tip Device:** Locate a suitable wall stud and securely fasten the anti-tip bracket to the wall. Attach the corresponding bracket to the top rear of the cabinet and connect them with the provided strap or cable. This step is critical for safety.



4. OPERATING INSTRUCTIONS

The BORNOON Shoe Cabinet is designed for convenient and discreet shoe storage.

- **Opening Drawers:** Gently pull the top edge of each flip drawer outwards to open. The drawer will tilt down, revealing the shoe compartments.
- **Storing Shoes:** Place shoes into the compartments. Each drawer features two tiers. For larger shoes like high heels or ankle boots, the internal divider panels can be adjusted or removed to create more space.
- **Closing Drawers:** Push the drawer upwards until it clicks securely into the closed position. Ensure no shoes are obstructing the closing mechanism.
- **Capacity:** The cabinet can store up to 24 pairs of shoes, depending on their size and type.



Image 4: Open Drawers with Shoes. This image demonstrates how shoes are stored within the open flip drawers.



Image 5: Closed Drawers. The cabinet maintains a sleek look when all drawers are closed, keeping shoes out of sight.

5. MAINTENANCE

Proper care will extend the life and appearance of your shoe cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.

- **Inspection:** Periodically check all hardware connections to ensure they remain tight. Retighten if necessary.

6. TROUBLESHOOTING

If you encounter issues, refer to these common solutions:

Problem	Possible Cause	Solution
Drawers do not close properly	Shoes are too large or improperly placed; hardware is loose.	Adjust or remove internal dividers. Ensure shoes are placed flat. Check and tighten all drawer hardware.
Cabinet feels unstable	Anti-tip kit not installed or loose; uneven floor.	Ensure the anti-tip kit is securely anchored to a wall stud. Place shims under the cabinet legs if the floor is uneven. Do not overload.
Missing or damaged parts	Shipping damage or packaging error.	Contact BORNOON customer support for free replacements.

7. SPECIFICATIONS

Feature	Detail
Brand	BORNOON
Model	B0FH1VB719
Color	Brown
Product Dimensions (D x W x H)	9.45"D x 47.24"W x 32.28"H
Material	Engineered Wood
Mounting Type	Freestanding (with anti-tip wall anchor)
Number of Drawers	4 Flip Drawers
Special Features	Anti-Tip Safety, Adjustable/Removable Dividers, Space Saving
Assembly Required	Yes

8. WARRANTY AND SUPPORT

BORNOON is committed to providing quality products and customer satisfaction.

- **Parts Replacement:** We offer free replacements for any missing or damaged parts during shipping.
- **Customer Support:** If you have any questions, concerns, or require assistance with your product, our customer support team is available to assist you within 24 hours.
- **Contact Information:** Please refer to your purchase documentation or the BORNOON brand store on Amazon for the most current contact details.

