

Manuals.plus /

› BOMOVA /

› BOMOVA Heated Electric Throw Blanket (50" x 60") - Ash Gray User Manual

BOMOVA B0FH21LWDJ

BOMOVA Heated Electric Throw Blanket

Model: B0FH21LWDJ

INTRODUCTION

This manual provides essential information for the safe and effective use of your BOMOVA Heated Electric Throw Blanket. Please read all instructions carefully before use and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of burns, electric shock, fire, or injury to persons, this product must be used in accordance with the following instructions:

- Do not use with an infant, child, incapacitated person, or anyone insensitive to heat.
- Do not use on areas of insensitive skin.
- Do not use in conjunction with other heating appliances.
- Never use the blanket folded, bunched, or crumpled. This can cause overheating and potential fire hazards.
- Do not insert pins or other metallic objects into the blanket.
- Do not use if the blanket is wet.
- Always unplug the blanket from the electrical outlet when not in use.
- Inspect the blanket, cord, and controller regularly for any signs of wear or damage. If damaged, do not use and contact customer support.
- Keep the controller away from open windows or moisture.
- This appliance is not intended for medical use in hospitals.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x BOMOVA Heated Electric Throw Blanket (50" x 60")
- 1 x Digital Controller with Power Cord (7.87 ft)

- 1 x User Manual



Image: The heated electric throw blanket, folded, with its digital controller and power cord.

SETUP

1. **Unpack:** Carefully remove the blanket and controller from the packaging.
2. **Inspect:** Check the blanket, power cord, and controller for any visible damage. Do not use if any damage is found.
3. **Position the Blanket:** Lay the heated blanket flat on your bed, sofa, or desired surface. Ensure there are no folds, creases, or bunched areas.
4. **Connect the Controller:** Locate the connector port on the blanket. Firmly plug the controller's connector into the blanket's port until it clicks securely into place.
5. **Plug into Power:** Insert the power plug into a standard 120V AC electrical outlet. Ensure the outlet is easily accessible.



Image: The Ash Gray heated electric throw blanket laid out on a bed, ready for use.

OPERATING INSTRUCTIONS

Your BOMOVA Heated Electric Throw Blanket features an easy-to-use digital controller for personalized comfort.

1. **Power On/Off:** Press the power button () to turn the blanket on or off. The LED display will illuminate when powered on.
2. **Adjust Heating Levels:** Use the temperature control buttons (+ / -) to select your desired heat level from 1 to 10. The temperature range is approximately 83°F to 113°F. The current heat level will be displayed on the LED screen.
3. **Set Auto-Off Timer:** Press the timer button (⌚) to cycle through the available auto-off settings: 1, 2, 4, 6, or 8 hours. The selected time will be indicated on the LED display. If no timer is set, the blanket will automatically shut off after 8 hours for safety.



Image: Digital controller with clear buttons for power, temperature adjustment, and timer settings, featuring an LED display.

Your browser does not support the video tag.

Video: A user demonstrates the operation of the heated blanket's controller, showing how to power it on, adjust heat levels, and set the timer. The blanket's soft texture is also highlighted.

Your browser does not support the video tag.

Video: A user showcases the heated electric blanket, emphasizing its warmth and the ease of use of its controller. The video demonstrates adjusting settings and the blanket's cozy feel.

Your browser does not support the video tag.

Video: A user explains the benefits of the heated blanket, highlighting its soft texture and the functionality of the controller for temperature and timer adjustments.

CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your heated blanket.

1. **Disconnect Power:** Always unplug the power cord from the wall outlet and detach the controller(s) from the blanket before cleaning.

2. **Machine Wash:** Machine wash the blanket in cold water on a delicate or gentle cycle. Do not bleach or iron.
3. **Drying:** Tumble dry on low heat or air dry. Ensure the blanket is completely dry before reconnecting the controller or storing. Do not wring or twist.
4. **Storage:** Store the blanket in a cool, dry place. Avoid folding tightly or placing heavy objects on top, which could damage the internal heating elements.



WORKING AT HOME
never feel cold, and improve working efficiency

Image: A hand gently touches the soft flannel fabric of the blanket, illustrating its texture and suggesting ease of handling for care.

TROUBLESHOOTING

If you encounter issues with your heated blanket, refer to the following common problems and solutions:

- **Blanket Not Heating:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Verify that the controller is firmly connected to the blanket's port.
 - Check if the auto-off timer has expired.
 - Ensure the blanket is laid flat and not folded or bunched.

- **Controller Display Not Working:**

- Confirm the blanket is plugged into a live power source.
- Try unplugging and re-plugging the controller from both the blanket and the wall outlet.

- **Uneven Heating:**

- Ensure the blanket is spread out evenly without any folds or overlaps.
- Allow sufficient time for the blanket to heat up completely.

If the issue persists after attempting these steps, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	B0FH21LWDJ
Dimensions	50"L x 60"W
Material	Flannel (Fleece Fill)
Color	Ash Gray
Heating Levels	10 (83°F-113°F)
Auto-Off Timer	1, 2, 4, 6, 8 hours (default 8 hours)
Power Cord Length	7.87 ft
Product Care	Machine Washable
Item Weight	3.34 pounds

WARRANTY AND SUPPORT

Your BOMOVA Heated Electric Throw Blanket is covered by a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product is free from defects in material and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact BOMOVA customer service through the retailer where the product was purchased or visit the official BOMOVA website for contact information.

Please retain your proof of purchase for warranty validation.