Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JIXINMIYUE JI-301

JIXINMIYUE JI-301 Multifunction Handheld Car Vacuum Cleaner Instruction Manual

Model: JI-301 | Brand: JIXINMIYUE

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your JIXINMIYUE JI-301 Multifunction Handheld Car Vacuum Cleaner. Please read this manual thoroughly before using the product and retain it for future reference.

2. Product Overview

The JIXINMIYUE JI-301 is a versatile 3-in-1 portable mini vacuum cleaner designed for both suction and blowing functions, suitable for cleaning cars, homes, and pet areas. It features a compact design and multiple nozzles for various cleaning tasks.

2.1 Components

- Main Vacuum Unit
- Dust Collecting Bin
- HEPA Filter
- Various Nozzles (e.g., dusting brush, crevice tool)
- USB Charging Cable



Figure 1: JIXINMIYUE JI-301 Handheld Vacuum Cleaner and included accessories.

3. Setup

3.1 Initial Charging

1. Before first use, fully charge the vacuum cleaner.
2. Connect the USB charging cable to the charging port on the vacuum and to a suitable USB power adapter (not included).
3. The charging indicator light will show the charging status. A full charge typically takes 2.5 to 3.5 hours.

3.2 Assembling for Use

1. Ensure the HEPA filter is correctly installed inside the dust collecting bin.
2. Attach the dust collecting bin to the main vacuum unit by rotating it counter-clockwise until it clicks securely into place.
3. Select the appropriate nozzle for your cleaning task and attach it to the suction port for vacuuming or the air outlet

for blowing.

4. Operating Instructions

4.1 Power On/Off and Speed Adjustment

- To power on, press and hold the power switch for a few seconds. The vacuum will start in the standard speed setting.
- To increase to high speed, short press the power switch again.
- To power off, press and hold the power switch.

4.2 Suction Mode

- Attach the desired nozzle (e.g., flat suction nozzle, brush nozzle) to the main suction port of the vacuum.
- Turn on the vacuum and move the nozzle over the area to be cleaned.
- For stubborn dirt, use a higher speed setting.

4.3 Blowing Mode

- Attach the air nozzle to the air outlet of the vacuum.
- Turn on the vacuum. The air will blow from the nozzle, allowing you to clear dust and debris from surfaces.

Your browser does not support the video tag.

Video 1: Demonstration of the JIXINMIYUE JI-301 Cordless Mini Vacuum Cleaner's strong suction and functionality.

Your browser does not support the video tag.

Video 2: Overview of the JIXINMIYUE JI-301 Handheld Vacuum Cleaner's power and compact size.

5. Maintenance

5.1 Emptying the Dust Bin

- Regularly empty the dust collecting bin to maintain optimal suction power.
- Rotate the dust collecting bin counter-clockwise to detach it from the main unit.
- Dispose of collected debris and reattach the bin.

5.2 Cleaning the HEPA Filter

- Remove the HEPA filter from the dust collecting bin.
- Tap the filter gently to remove loose dust. For a more thorough cleaning, rinse the filter under running water.
- Ensure the filter is completely dry before reinserting it into the dust bin and reassembling the vacuum.

5.3 General Cleaning

- Wipe the exterior of the vacuum with a soft, damp cloth.
- Do not use harsh chemicals or abrasive cleaners.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is low or depleted.	Charge the vacuum fully.
Weak suction power.	Dust bin is full; Filter is clogged; Nozzle is blocked.	Empty the dust bin; Clean or replace the HEPA filter; Clear any blockages from the nozzle or suction path.
Short battery life.	Battery not fully charged; Using high power setting continuously.	Ensure full charge before use; Use lower power settings for lighter tasks to conserve battery.

7. Specifications

- **Brand:** JIXINMIYUE
- **Model Name:** JI-301
- **Special Feature:** Low Noise
- **Filter Type:** HEPA (Home)
- **Included Components:** Dusting Brush, various nozzles, USB charging cable
- **Is Cordless?:** Yes (Battery-powered, charges via corded electric)
- **Capacity:** 4.2 Cubic Feet (Dust bin)
- **Color:** Blue
- **Product Dimensions:** 35"L x 25"W x 35"H
- **Battery Life:** Approximately 20 minutes (depending on usage)
- **Manufacturer:** JIXINMIYUE
- **Number of Items:** 1
- **Number of Power Levels:** 2 (Standard, High)
- **Indoor/Outdoor Usage:** Indoor
- **Vacuum Collection Technology:** Air-based Collection
- **Item Weight:** 1.65 pounds
- **Batteries:** 1 12V battery required (included)
- **Surface Recommendation:** Upholstery
- **Power Source:** Corded Electric (for charging)
- **UPC:** 684646932347
- **ASIN:** B0FH24S8ZQ

8. Warranty & Support

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official JIXINMIYUE website. Keep your purchase receipt for warranty claims.
Email Support: SUPPORT@jixinmiyue.com
Manufacturer: Ningbo HengXin Electric Appliance Co
Address: No. 18 Gaoqian Highway, Gao Qiao Village, Huangjiaobu Town, Yuyao City, Zhejiang Province

© 2026 JIXINMIYUE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH24S8ZQ

More documents and user manuals: **https://manuals.plus/**