

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cheerble](#) /

› [Cheerble Elfin E1 Lite Pumpless Cat Water Fountain User Manual](#)

Cheerble Elfin E1 Lite

Cheerble Elfin E1 Lite Pumpless Cat Water Fountain User Manual

Model: Elfin E1 Lite (CDY09)

INTRODUCTION

Thank you for choosing the Cheerble Elfin E1 Lite Pumpless Cat Water Fountain. This automatic pet fountain is designed to provide your pet with a continuous supply of fresh, filtered water, promoting healthier hydration habits. Featuring MagDrive™ Technology, it offers effortless maintenance and enhanced safety by separating electronic components from the water.

Please read this manual thoroughly before setup and operation to ensure proper use and maintenance of your new pet fountain.

Pumpless™ Cat Fountain

Powered by MagDrive™ Technology.
No Pump, No Risks



Image: The Cheerble Elfin E1 Lite Pumpless Cat Water Fountain in use, demonstrating its MagDrive™ technology for a pump-free water flow.

PACKAGE CONTENTS

Before proceeding with the setup, please ensure all components are present and undamaged:

- 1x Cheerble Pet Fountain Elfin E1 Lite
- 1x USB-Type C Charging Cable (*Note: The power adapter is not included. Please use a standard 5V/1A USB power adapter.*)
- 1x User Manual (This document)

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Rinse Parts:** Wash the water tank, drinking tray, and filter tray with clean water. Do not wash the magnetic base or USB cable.
3. **Assemble Filter:** Place the 3-layer filter into the designated filter tray. Ensure it is seated correctly.

4. **Fill Water Tank:** Fill the water tank with clean drinking water. Ensure the water level is above the MIN (minimum) line and does not exceed the MAX (maximum) line. The capacity is 2 liters (67 oz).
5. **Place Drinking Tray:** Position the drinking tray with the assembled filter onto the water tank. Ensure it rests securely.
6. **Connect Power:** Connect the USB-Type C charging cable to the magnetic base and plug the other end into a 5V/1A USB power adapter (not included) and then into a power outlet.
7. **Initial Operation:** The fountain should begin circulating water automatically. Listen for audio feedback confirming proper installation.




Image: The Cheerble Elfin E1 Lite fountain demonstrating its water-electricity separation design for enhanced safety.

OPERATING INSTRUCTIONS

Continuous Fresh Water Supply

The Elfin E1 Lite fountain provides a 24/7 continuous fresh water supply. Water circulates constantly, preventing stagnation and encouraging pets to drink more. This system ensures cleaner, fresher, and oxygen-rich water for your pet.

24/7 Continuous Fresh Water

Non-stop fresh water all day every day



Image: The Cheerble Elfin E1 Lite fountain providing continuous fresh water, day and night.

Whisper-Quiet Operation

Thanks to its unique kitty spout design and MagDrive™ technology, the fountain operates at a whisper-quiet level (below 23dB). This low noise level is ideal for easily startled pets and ensures minimal disturbance in your home, even during the night.

Quietly Watching Over



Image: The Cheerble Elfin E1 Lite fountain operating silently, ensuring a peaceful environment for pets and owners.

Water Level Indicator

The base of the fountain features a light that changes colors to indicate when the water level is low. Refill the tank promptly when the indicator light signals a low water level to ensure continuous operation and prevent potential issues.

MAINTENANCE

Effortless Cleaning

The pumpless design of the Elfin E1 Lite eliminates traditional pump issues like buildup and hard-to-clean blind spots. Most parts of the fountain are detachable and dishwasher-safe, allowing for quick and hygienic cleaning. This ensures your pet always has access to fresh water without the hassle of complex maintenance.

Effortless Maintenance

No pump, no hidden uncleaned risks.
All visible, all washable



Image: Disassembled components of the Cheerble Elfin E1 Lite fountain being cleaned, highlighting its user-friendly maintenance.

Filter Replacement

The fountain features an advanced 3-layer filtration system designed to purify water by removing hair, heavy metals, and odors. For optimal performance and to support your pet's long-term health, it is recommended to change the filter every 2-4 weeks.

Vertical Filtration System

PP Cotton

Blocks pet hair & dust

Coconut-shell Activated Carbon

Remove odor to promote flavor

Ion exchange resin

Adsorbs heavy metal ions

PP Cotton

Blocks pet hair & dust

Image: Detailed view of the Cheerble Elfin E1 Lite's 3-layer vertical filtration system.

Filter Layers:

- **PP Cotton:** Blocks pet hair and dust.
- **Coconut-shell Activated Carbon:** Removes odor to promote flavor.
- **Ion Exchange Resin:** Adsorbs heavy metal ions.

TROUBLESHOOTING

Loud Noise During Operation

If the fountain produces a loud noise, please follow these steps:

1. **Check Water Level:** Ensure the water level in the tank is not too low. Refill the tank with drinking water, making sure the level is above the MIN line and does not exceed the MAX line.
2. **Inspect Impeller:** Unplug the fountain. Carefully check the impeller and its surroundings for any blockages (e.g., pet hair, debris). Clean the impeller thoroughly and ensure it can rotate freely without obstruction.

SPECIFICATIONS

Feature	Detail
Model Name	Elfin E1 Lite
Item Model Number	CDY09
Capacity	2 Liters (67 oz)
Product Dimensions	8.5"L x 7.5"W x 6.9"H
Item Weight	2 pounds
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Pink
Power Input	USB-Type C (5V/1A adapter not included)
Specific Uses	Indoor

WARRANTY INFORMATION

The Cheerble Elfin E1 Lite Pumpless Cat Water Fountain comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.

SUPPORT

For further assistance, technical support, or warranty inquiries, please refer to the official Cheerble website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.