

Manuals.plus /

› PINDOWS /

› PINDOWS Slim Minimalist Quartz Analog Watch User Manual

PINDOWS PDS-652

PINDOWS Slim Minimalist Quartz Analog Watch User Manual

Model: PDS-652

INTRODUCTION

Thank you for choosing the PINDOWS Slim Minimalist Quartz Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Designed for elegance and everyday wear, this watch features a reliable Japanese quartz movement and a comfortable leather strap. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.





Image: Front view of the PINDOWS Slim Minimalist Quartz Analog Watch with a gold-tone case and black leather strap.

SETUP

Setting the Time

Your PINDOWS watch is equipped with a single crown for time adjustment. Follow these steps to set the correct time:

1. Gently pull the crown located on the side of the watch case outwards to the first position. You may feel a slight click.
2. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands until the desired time is displayed.
3. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Image: A close-up view of the watch case highlighting the crown and an arrow indicating to pull it out for time adjustment.

Adjusting the Strap

The black leather strap is designed for comfort and adjustability. To ensure a proper fit:

- Unbuckle the strap and place the watch on your wrist.
- Thread the end of the strap through the buckle and select a hole that provides a snug yet comfortable fit. The watch should not slide freely on your wrist but also not feel too tight.
- Secure the strap by inserting the buckle pin into the chosen hole. Use the two strap loops to secure the excess strap end.



Image: A PINDOWS watch with a black leather strap worn on a wrist, demonstrating a comfortable fit.

OPERATING

Timekeeping

Your PINDOWS watch utilizes a precise Japanese quartz movement to provide accurate timekeeping. Once the time is set, the watch will continuously display the current hour, minute, and second.

Luminous Dial Function

The watch features a full luminous dial, allowing for clear visibility in low-light conditions. To activate the luminosity:

- Expose the watch dial to a bright light source, such as sunlight or strong indoor lighting, for at least 30 minutes.
- The luminous material on the dial will absorb the light energy and glow in the dark, providing temporary illumination. The duration and intensity of the glow depend on the exposure time and intensity of the light source.

FULL LUMINOUS DIAL



FULL LUMINOUS DIAL ENSURES CLEAR VISIBILITY
IN LOW-LIGHT CONDITIONS

Image: The PINDOWS watch dial illuminated with a green glow in a dark environment, demonstrating its luminous feature.



30M WATER RESISTANT

Splash-resistant design, suitable for daily use (e.g., hand washing, rain) - not suitable for swimming/diving.



LUMINOUS DIAL

Expose the watch to a bright light source, such as sunlight or indoor lighting, for at least 30 minutes to fully absorb light.

Image: A split image showing the watch near water with a "30M Water Resistant" label and the luminous dial glowing in the dark with a "Luminous Dial" label.

MAINTENANCE

Water Resistance

This watch is rated for 30 meters (3 ATM) of water resistance. This means it is suitable for daily use and can withstand splashes, rain, and hand washing. It is *not* suitable for swimming, diving, showering, or any activities involving prolonged water immersion or high-pressure water exposure.

- Do not operate the crown while the watch is wet or submerged in water.
- If the watch comes into contact with saltwater, rinse it gently with fresh water and dry it thoroughly with a soft cloth.

Cleaning

To maintain the appearance of your watch:

- Wipe the watch case and crystal with a soft, dry, lint-free cloth.
- For the leather strap, avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture, as these can cause the leather to dry out, crack, or discolor. Clean the strap with a slightly damp cloth and allow it to air dry completely.
- Avoid using chemical cleaners, solvents, or abrasive materials on any part of the watch.

Battery Replacement

The watch is powered by a long-lasting quartz battery. When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained and to prevent damage to the movement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch is not running.	Battery depleted. Crown is pulled out.	Have the battery replaced by a professional. Push the crown back into its normal position.
Time is inaccurate.	Time not set correctly. Exposure to strong magnetic fields. Low battery.	Reset the time as per "Setting the Time" section. Move the watch away from magnetic sources. Replace the battery.
Luminous dial not glowing.	Insufficient light exposure.	Expose the watch to a bright light source for at least 30 minutes.

SPECIFICATIONS

Feature	Detail
Model Number	PDS-652
Movement	Japanese Quartz
Case Material	Gold-Tone (Metal)
Strap Material	Black Leather
Mirror Material	Mineral Glass
Water Resistance	30M (3 ATM) - Splash Resistant
Case Size	32mm
Case Thickness	8mm
Strap/Lug Width	14mm
Weight	27.5g / 0.97oz
Adjustable Strap Accommodates	6.0" (153+2mm) to 8.3" (210+2mm) wrist circumference




Image: A detailed diagram illustrating the dimensions of the PINDOWS watch, including case size (32mm), strap/lug width (14mm), case thickness (8mm), and the adjustable wrist circumference range.

Thinner than the Phone

8MM



3.15 in

Image: A side profile view of the PINDOWS watch, emphasizing its slim 8mm case thickness compared to a phone.



Stainless Steel Back Cover

corrosion-resistant and tightly sealed

Image: The rear view of the PINDOWS watch, displaying the stainless steel back cover which is corrosion-resistant and tightly sealed, along with the model number PDS-652.

WARRANTY AND SUPPORT

PINDOWS watches are manufactured with attention to quality and detail. For specific warranty terms and conditions, please refer to the warranty card or documentation included with your purchase. In most cases, warranty coverage addresses manufacturing defects.

For technical support, service, or warranty claims, please contact PINDOWS customer service through the retailer where the product was purchased or visit the official PINDOWS website for contact information. Please have your model number (PDS-652) and proof of purchase ready when contacting support.

Note: Unauthorized repairs or modifications may void your warranty.