Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FXWONTY FX-HS032

FXWONTY Open Ear Headphones with Mic (Model FX-HS032) User Manual

Model: FX-HS032 | Brand: FXWONTY

Introduction

These FXWONTY Open Ear Headphones with Microphone (Model FX-HS032) are designed to provide high-fidelity audio and clear communication while allowing awareness of your surroundings. Featuring Bluetooth V5.4, a noise-cancelling microphone, IPX5 water resistance, and a lightweight design, these headphones are suitable for various activities including workouts, driving, meetings, and calls.

What's in the Box

- FXWONTY Open Ear Headphones
- USB Charging Cable
- User Manual

Product Overview


The FXWONTY Open Ear Headphones feature an ergonomic design for comfortable, all-day wear. The device includes an adjustable microphone and intuitive touch controls for managing audio and calls.



FXWONTY Open Ear Headphones, Model FX-HS032.



The headphones weigh only 28g, ensuring a lightweight and comfortable fit.



Key features include a 220° rotatable microphone, intelligent touch control, Environmental Noise Cancellation (ENC), 20-hour battery life, and Hi-Fi sound quality.

Setup

Wearing Instructions

Ensure the headphones are worn correctly for optimal sound and microphone performance. The flexible wraparound frame is designed to fit securely without discomfort.




Diagram illustrating how to wear the headphones and use basic controls.

Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Multi-Function Button (MFB) for 2 seconds. The blue and red LEDs will flash alternately, and you will hear a voice prompt say "Pairing".
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "FX-HS032" from the list of found devices to connect. Once connected, the LED indicator will show a steady blue light or flash slowly.

The headphones support multipoint pairing, allowing seamless switching between two connected devices, such as a laptop and a smartphone.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the MFB until the LED indicator lights up.
- **Power Off:** Press and hold the MFB until the LED indicator turns off.

Call Management

- **Answer/End Call:** Single-press the MFB.
- **Reject Call:** Press and hold the MFB for 2 seconds.
- **Mute Microphone:** Use the dedicated one-touch mute button on the headset during a call.

Music Playback

- **Play/Pause:** Single-press the MFB.
- **Next Track:** Double-click the Volume Control Bar.
- **Previous Track:** Triple-tap the Volume Control Bar.

Volume Control

Locate the Volume Control Bar on the headset. Slide it up to increase volume and down to decrease volume.



Illustrates the touch control for volume adjustment.

Charging

The headphones offer an impressive 20 hours of music playtime or 14 hours of talk time on a full charge. A quick 5-minute USB-C charge provides approximately 2 hours of talk time.

- Connect the USB charging cable to the charging port on the headphones and to a compatible USB power source.
- The LED indicator will show charging status (e.g., red for charging, blue for fully charged).
- A full charge typically takes 2 hours.



Visual representation of the 20-hour battery life and charging status.

Maintenance

To ensure the longevity and optimal performance of your FXWONTY Open Ear Headphones, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the headphones with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Water Resistance:** The headphones are IPX5 water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water or expose them to heavy rain. Ensure the charging port cover is securely closed when not charging.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Charge the headphones regularly, even if not in frequent use, to maintain battery health.

Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Solution
Cannot pair with device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn off and on Bluetooth on your device. Clear previous pairings on your device.
No sound or low volume.	Check volume levels on both headphones and connected device. Ensure headphones are properly connected. Try re-pairing.
Microphone not working.	Ensure the microphone is not muted. Check microphone settings on your connected device. Ensure the microphone is positioned correctly.
Short battery life.	Ensure headphones are fully charged. Battery life can vary based on volume level and usage.
Connection drops frequently.	Ensure you are within the 49 ft Bluetooth range. Avoid obstacles between the headphones and your device. Reduce interference from other wireless devices.

Specifications

Feature	Detail
Brand	FXWONTY

Feature	Detail
Model Number	FX-HS032
Color	Black
Ear Placement	On Ear
Form Factor	On Ear
Impedance	32 Ohms
Connectivity Technology	Wireless
Wireless Technology	Bluetooth
Bluetooth Version	5.4
Bluetooth Range	49 Feet
Item Weight	1.2 Ounces (28g)
Noise Control	Active Noise Cancellation (AI Noise Cancellation for Mic)
Frequency Response	20 Hz
Sensitivity	98 dB
Audio Driver Type	Dynamic Driver
Audio Driver Size	16 Millimeters
Additional Features	Lightweight, Microphone Included, Multipoint Pairing, Noise Cancellation, Touch Control
Enclosure Material	Plastic, Silicone
Water Resistance Level	IPX5 (Water Resistant)
Control Type	Touch Control
Battery Average Life	14 Hours (Talk Time), 20 Hours (Music Time)
Battery Charge Time	2 Hours (Full Charge)

Warranty and Support

The FXWONTY Open Ear Headphones (Model FX-HS032) come with an 18-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards.
For technical support, warranty claims, or any questions regarding your product, please refer to the contact information provided on the product packaging or the official FXWONTY website. Please retain your proof of purchase for warranty service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH2S11SJ

More documents and user manuals: **https://manuals.plus/**