

[Manuals.plus](#) /

› [Coral Milano](#) /

› Dustek DUAL Professional Nail Dust Collector 48W - User Manual

Coral Milano Dual

Dustek DUAL Professional Nail Dust Collector 48W

Model: Dual

INTRODUCTION

The Dustek DUAL professional nail dust collector is designed for effective dust removal during manicure and pedicure procedures. It features a powerful dual turbo fan system and adjustable speed settings to ensure a clean working environment.

SAFETY INFORMATION

- Always read the product label, warnings, and instructions before use.
- Ensure the device is connected to a power source with the correct voltage (48 Volt).
- Do not immerse the device in water or other liquids.
- Keep out of reach of children.
- Do not operate the device if it is damaged or malfunctioning.
- Use only original replacement parts and filters.

PACKAGE CONTENTS

- 1 x Dustek DUAL Professional Nail Dust Collector
- 30 x Replacement Filters
- 1 x Power Adapter
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The Dustek DUAL features a robust design with a white and silver finish, an ergonomic leather handle, and an aluminum top grille for efficient dust collection.

DOPPIA VENTOLA

Aspirazione più veloce ed efficiente



Figure 1: The Dustek DUAL unit showcasing its dual turbo fans for powerful and efficient dust aspiration. The fans are visible through the protective grille.

The device is equipped with a modern LCD display for precise control and monitoring of its 10 adjustable speed levels. Its advanced motor technology ensures ultra-quiet operation while maintaining maximum suction power.

MATERIALI PREMIUM

Filtro in metallo, attacco magnetico



Figure 2: View of the Dustek DUAL with its magnetic metal filter removed, highlighting the premium materials and easy access for maintenance.

MOTORE NEW GEN

Ultra silenzioso, massima potenza



Figure 3: A detailed view of the new generation motor, emphasizing its ultra-silent operation and high power output for efficient dust collection.

SETUP

1. Unpack the Dustek DUAL unit and all accessories from the packaging.
2. Place the unit on a stable, flat surface.
3. Ensure the magnetic filter is correctly seated within the unit.
4. Connect the power adapter to the device and then plug it into a suitable electrical outlet.

OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the device. The LCD display will illuminate.
2. **Adjust Speed:** Use the control knob or buttons (as indicated on the LCD) to select one of the 10 available speed

levels. Higher speeds provide stronger suction.

- 3. **Positioning:** Place your hands or the client's hands directly over the aluminum grille where the dust is generated during filing or other nail procedures.
- 4. **Operation:** The dual turbo fans will actively draw in nail dust and debris, trapping it in the filter.
- 5. **Power Off:** After use, press the power button to turn off the device.

MAINTENANCE

Filter Replacement

The Dustek DUAL comes with 30 replacement filters to ensure continuous optimal performance. Filters should be replaced regularly depending on usage frequency and the amount of dust collected.

- 1. Ensure the device is turned off and unplugged from the power source.
- 2. Gently lift the magnetic aluminum grille to access the filter compartment.
- 3. Remove the used filter and dispose of it properly.
- 4. Insert a new filter into the compartment, ensuring it is seated correctly.
- 5. Replace the aluminum grille, ensuring it snaps securely into place.

Cleaning

- Wipe the exterior of the device with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure no liquids enter the device's internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on	No power connection; faulty power adapter	Check if the power adapter is securely plugged into both the device and the wall outlet. Ensure the outlet is functional.
Weak suction power	Filter is clogged; fan obstruction; low speed setting	Replace the filter. Check for any obstructions in the fan area. Increase the speed setting via the LCD display.
Unusual noise during operation	Obstruction in fan; loose component	Turn off and unplug the device. Carefully check for any foreign objects obstructing the fans. If the noise persists, contact customer support.

SPECIFICATIONS

Model Name:	Dual Professional Nail Dust Collector
Brand:	Coral Milano
Power:	48W

Voltage:	48 Volt
Dimensions (LxWxH):	30 x 25 x 5 cm
Weight:	1200 Grams (1.2 kg)
Material:	Metal, Plastic
Color:	White
Speed Levels:	10 Adjustable Levels
Display:	LCD

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Coral Milano customer service through their official website or authorized retailers. Keep your proof of purchase for warranty claims.

For further assistance, you may visit the [Coral Milano brand page](#).

© 2024 Coral Milano. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

