

EWEADN V97

EWEADN V97 Wired RGB Backlit Keyboard User Manual

Model: V97

1. INTRODUCTION

Thank you for choosing the EWEADN V97 Wired RGB Backlit Keyboard. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new keyboard. Please read it carefully to ensure optimal performance and longevity of your device.



Image 1.1: EWEADN V97 Keyboard with highlighted features.

2. PRODUCT OVERVIEW

The EWEADN V97 is a wired computer keyboard designed for various uses, from work to gaming. Key features include:

- **Wired Connection:** Ensures stable and reliable performance with plug-and-play functionality.
- **RGB Backlit:** Features 11 pre-set lighting effects with adjustable brightness and speed.
- **Unique Curved Body:** Ergonomic design with a 7° tilt angle and stepped keycap layout for comfortable typing.
- **Durable PBT Keycaps:** Smooth, delicate, and long-lasting keycaps.

- **Volume & Light 2-in-1 Knob:** Convenient control for media volume and backlight settings.
- **97-Key Compact Layout:** Saves desktop space while retaining essential function keys.
- **Mac/Win Compatibility:** Supports both Windows and Mac operating systems.



Image 2.1: Overview of the EWEADN V97 Keyboard's main features.

3. SETUP

The EWEADN V97 keyboard offers a straightforward plug-and-play setup.

1. Unpack the keyboard from its packaging.
2. Locate an available USB port on your computer (PC, Mac, or Laptop).
3. Plug the USB cable of the keyboard into the USB port.
4. The keyboard will be automatically recognized by your operating system and is ready for use.

4. OPERATING INSTRUCTIONS

4.1. RGB Backlight Control

The V97 keyboard features vibrant RGB backlighting with multiple effects and adjustable settings.

- **Switch Lighting Effect:** Press **Fn + INS** or **Fn + PgDn** to cycle through 11 pre-set lighting effects.
- **Adjust Brightness:** Press **Fn + PgUp** to increase brightness or **Fn + PgDn** to decrease brightness (9 levels).
- **Adjust Speed:** Press **Fn + ==** to increase lighting speed or **Fn + -** to decrease lighting speed.
- **Turn Backlight Off:** If desired, the backlight can be turned off completely.



Image 4.1: RGB Backlight control functions.

4.2. Multimedia Knob Functions

The integrated knob provides quick access to volume and lighting controls.

- **Adjust Volume:** Rotate the knob clockwise to increase volume, counter-clockwise to decrease volume.
- **Mute/Unmute:** Press the knob briefly to mute or unmute audio.
- **Switch Control Mode:** Press **Fn + Knob** for approximately 3 seconds to switch between volume control mode and light control mode.
- **Adjust Light Brightness (in Light Control Mode):** Rotate the knob to adjust the brightness of the backlight.



Image 4.2: Multimedia Knob functions.

4.3. System Compatibility

The EWEADN V97 keyboard is compatible with both Windows and Mac operating systems.

- **Switch to Windows System:** Press and hold **Fn + A**.
- **Switch to Mac System:** Press and hold **Fn + S**.



Image 4.3: System compatibility and switching instructions.

5. MAINTENANCE

To ensure the longevity and cleanliness of your EWEADN V97 keyboard, follow these maintenance tips:

- **Regular Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface regularly.
- **Keycap Cleaning:** The PBT keycaps are removable for easy cleaning. Gently pull keycaps upwards to remove them. Clean with a mild cleaning solution and a soft brush, then ensure they are completely dry before reattaching.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keycaps.
- **Avoid Liquids:** Do not spill liquids on the keyboard. If a spill occurs, immediately unplug the keyboard and allow it to dry completely before reconnecting.



Image 5.1: Removable PBT keycaps for maintenance.

6. TROUBLESHOOTING

If you encounter issues with your EWEADN V97 keyboard, please refer to the following common solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Keyboard is not responding	Ensure the USB cable is securely plugged into both the keyboard and the computer. Try plugging the keyboard into a different USB port. Restart your computer. Test the keyboard on another computer to rule out a system-specific issue.
RGB backlight is not working or stuck	Ensure the backlight is not turned off (refer to Section 4.1). Try cycling through the lighting effects using Fn + INS or Fn + PgDn . Adjust brightness using Fn + PgUp/PgDn .
Multimedia knob not functioning correctly	Ensure the knob is in the correct control mode (volume or light). Press Fn + Knob for 3 seconds to switch modes. Check if the system volume is not muted.
Incorrect key input (e.g., Mac keys on Windows)	Verify that the keyboard is set to the correct operating system mode (refer to Section 4.3). Press Fn + A for Windows or Fn + S for Mac.

If these solutions do not resolve your issue, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	V97
Connectivity	Wired (USB)
Keyboard Layout	97-key
Keycap Material	PBT
Backlighting	RGB (11 effects, adjustable brightness/speed)
Special Features	Multimedia Knob, Ergonomic Curved Body, Dual-System Compatibility
Compatible Devices	PC, Mac, Xbox
Item Weight	2.33 pounds
Package Dimensions	17.63 x 7.68 x 2.05 inches
Color	White (RGB Backlighting)
Manufacturer	EWEADN

8. WARRANTY AND SUPPORT

EWEADN provides comprehensive support for its products.

- **Warranty:** The EWEADN V97 keyboard comes with 24-month brand support.
- **Customer Support:** For any inquiries, troubleshooting assistance, or warranty claims, please contact our expert team via email.

Email Support: eweadnkeyboard@outlook.com



Image 8.1: EWEADN customer support information.