

- [Manuals.plus](#) /
- › [DERCASS](#) /
 - › DERCASS Full Size Wall Bed with Shelves, Wardrobe, and LED Lights - Instruction Manual

DERCASS LP000898A

DERCASS Full Size Wall Bed with Shelves, Wardrobe, and LED Lights - Instruction Manual

Model: LP000898A

- [Introduction](#)
- [Safety Information](#)
- [Package Contents](#)
- [Setup & Assembly](#)
- [Operating](#)
- [Instructions](#)
- [Maintenance](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your DERCASS Full Size Wall Bed with Shelves, Wardrobe, and LED Lights. Please read these instructions carefully before assembly and operation. Retain this manual for future reference.



Figure 1: DERCASS Full Size Wall Bed in an open configuration, displaying the bed, integrated shelves, and wardrobe.

2. SAFETY INFORMATION

Important Safety Instructions:

- Read all instructions before assembling and using the product.
- Ensure all components are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assembly requires two or more adults. Do not attempt to assemble alone.
- Securely anchor the wall bed to a sturdy wall stud using the provided hardware. Failure to do so can result in serious injury or property damage.
- Keep children and pets away from the assembly area.
- Do not exceed the recommended bed weight capacity of 600 lbs.

- Use only a mattress with a maximum thickness of 8-10 inches. Thicker mattresses may prevent proper folding or cause damage.
- Always ensure the support leg is fully extended and locked into place before using the bed.
- Keep hands and fingers clear of moving parts during opening and closing operations.
- Do not allow children to operate the wall bed mechanism unsupervised.
- Disconnect power to LED lights before cleaning or maintenance.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your packages. If any parts are missing or damaged, contact customer support immediately.

- Bed Frame components
- Hardware (screws, bolts, connectors, wall anchoring kit)
- LED Lights and associated wiring
- Shelves components
- Wardrobe components
- Assembly Tools (basic tools may be included, but additional household tools may be required)

Package Details:

- Sub-item 1: N708P210659K - Quantity: 1 - Dimensions: 64.5" x 19.75" x 7.5" - Weight: 131.18 lbs.
- Sub-item 2: N708P210658K - Quantity: 1 - Dimensions: 84.5" x 16.5" x 6" - Weight: 127.87 lbs.

4. SETUP & ASSEMBLY

Assembly of the DERCASS Wall Bed is required. Detailed step-by-step instructions and necessary tools are included within the product packaging. Please follow these instructions carefully to ensure proper and safe assembly.

Key Assembly Considerations:

- **Location:** Choose a suitable location with adequate wall space and clearance for the bed to fully extend.
- **Wall Anchoring:** This unit **must** be securely anchored to a structural wall stud. Identify stud locations before beginning assembly.
- **Team Assembly:** Due to the size and weight of the components, assembly requires at least two adults.
- **Tool Check:** Ensure you have all required tools as specified in the assembly guide.



Figure 2: Front view of the wall bed in an open position, illustrating the bed frame and internal wardrobe structure.



Figure 3: Angled view of the wall bed with the bed unfolded and wardrobe open, providing a clearer view of the bed frame and shelving.

5. OPERATING INSTRUCTIONS

The DERCASS Wall Bed is designed for ease of use with a dual piston metal folding mechanism.

5.1 Opening the Bed

1. Ensure the area in front of the wall bed is clear of obstructions.
2. Gently pull on the handles located on the front panel of the bed unit.
3. As the bed begins to lower, guide it smoothly towards the floor.
4. Once fully extended, ensure the support leg is securely flipped down and locked into its operational position.



Figure 4: Side view illustrating the bed partially lowered, demonstrating the folding mechanism.

5.2 Closing the Bed

1. Remove all bedding and pillows from the bed surface, except for the mattress (if 8-10 inches thick).
2. Lift the support leg and fold it back into its stored position.
3. Grasp the handles and gently lift the bed frame upwards, guiding it back into the cabinet.
4. Ensure the bed is fully retracted and latched securely into the closed position.



Figure 5: Front view of the wall bed in its closed position, resembling a compact cabinet unit.

5.3 Using the LED Lights

The integrated LED lights provide gentle illumination. Locate the power switch, typically on the side or inside the cabinet, to turn the lights on or off.

6. MAINTENANCE

To ensure the longevity and appearance of your DERCASS Wall Bed, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Mechanism:** The dual piston mechanism is designed for durability. Avoid applying excessive force when opening or closing the bed. Do not lubricate the mechanism unless specifically instructed by the manufacturer.
- **LED Lights:** If LED lights malfunction, check connections. Do not attempt to repair electrical components yourself.

Contact customer support.

7. TROUBLESHOOTING

If you encounter issues with your DERCASS Wall Bed, refer to the following common solutions:

Problem	Possible Cause	Solution
Bed does not open/close smoothly.	Obstruction, loose hardware, mattress too thick.	Check for obstructions. Ensure all hardware is tight. Verify mattress thickness is within 8-10 inches.
LED lights not working.	Power connection issue, faulty switch, damaged wiring.	Check power source and connections. Ensure switch is in "on" position. If problem persists, contact support.
Bed feels unstable.	Improper wall anchoring, loose fasteners.	Re-check wall anchoring to ensure it's secured to studs. Tighten all assembly fasteners.

If you cannot resolve the issue using the information above, please contact DERCASS customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	LP000898A
Brand	DERCASS
Size	Full
Color	Grey
Product Dimensions (L x W x H)	82" x 16.1" x 82.6"
Overall Product Weight	235 lbs
Bed Weight Capacity	600 lbs
Recommended Mattress Thickness	8-10 inches
Material	Plywood + MDF
Special Features	Integrated Shelves, Wardrobe, LED Lights, No Box Spring Needed
Assembly Required	Yes
Care Instructions	Wipe with Dry Cloth
UPC	750864675394

SIZE: INCH




Figure 6: Dimensional drawing of the DERCASS Wall Bed, indicating key measurements.

9. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact DERCASS customer support. Refer to your purchase documentation for specific contact details. When contacting support, please have your model number (LP000898A) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FH41DQXM>

More documents and user manuals: <https://manuals.plus/>