## Razee B0FH4L4JW6

# Razee Large Teepee Tent Instruction Manual

**Model: B0FH4L4JW6**

*For safe and proper assembly, use, and maintenance.*

## Introduction

Thank you for choosing the Razee Large Teepee Tent. This manual provides essential information for the assembly, operation, maintenance, and care of your teepee tent. Please read these instructions carefully before use to ensure safety and optimal performance. This teepee is designed for both indoor and outdoor use, offering a spacious and comfortable area for relaxation or play.

## What's in the Box

Upon unpacking, please verify that all components listed below are present:

- 1 x Double Thickness Fabric Cover
- 1 x Set of Foldable Steel Poles
- 2 x Artificial Vines (for decoration)
- 1 x Canvas Carry Bag
- 1 x Detailed Instructions Manual (this document)

## Setup Instructions

Follow these steps to assemble your Razee Teepee Tent:

1. **Unpack Components:** Remove all items from the canvas carry bag.
2. **Assemble Poles:** The steel poles are foldable and consist of multiple sections. Connect the sections of each pole firmly until they form a complete, sturdy pole.
3. **Insert Poles into Fabric Cover:** Carefully slide each assembled pole into the designated sleeves around the perimeter of the fabric cover.
4. **Gather and Secure Poles:** Once all poles are inserted, gather them at the top. Use the provided rope or ties to securely bind the poles together at the apex of the teepee. Ensure the binding is tight

to maintain stability.

5. **Spread the Base:** Gently spread the base of the teepee outwards until the fabric is taut and the teepee stands upright and stable. Adjust the pole positions as needed to achieve the desired shape and stability.
6. **Add Decorations (Optional):** If desired, drape the artificial vines around the top of the teepee for aesthetic enhancement.




Image: The Razee Teepee Tent assembled outdoors, demonstrating its use for events or relaxation. The open front design allows for easy access and ventilation.



Image: A collage showcasing the versatility of the Razee Teepee Tent in various outdoor settings, including parks and beaches, highlighting its suitability for different events.

## Operating Instructions

The Razee Teepee Tent is designed for versatile use, providing a comfortable space for various activities:

- **Play Area:** Ideal for children's play, reading, or quiet time. Its spacious interior can accommodate up to 3 children.
- **Relaxation Space:** Large enough to comfortably fit one adult, making it suitable for meditation, reading, or simply unwinding.
- **Outdoor Events:** Perfect for picnics, beach outings, garden parties, or as a photo prop. The wide-open front design ensures air circulation and easy access.
- **Ventilation:** The open-front design promotes natural airflow, maintaining a comfortable environment inside the tent.




Image: A young girl playing with a doll inside the Razee Teepee Tent indoors, illustrating its use as a comfortable play space.




Image: A teepee tent decorated with string lights and pillows, creating a cozy ambiance for evening use.

## Maintenance

To ensure the longevity and cleanliness of your teepee tent:

- **Fabric Care:** The teepee cover is made of 100% cotton fabric. It can be machine washed. For specific washing instructions, please refer to the care label attached to the fabric. Generally, use a gentle cycle with cold water and mild detergent.
- **Drying:** Air dry the fabric cover to prevent shrinkage and maintain its shape. Avoid using a high-heat dryer.
- **Pole Care:** Wipe the steel poles with a damp cloth if they become dirty. Ensure they are completely dry before storage to prevent rust.
- **Inspection:** Regularly inspect the fabric for any tears or damage, and the poles for any signs of wear or bending. Address any issues promptly to maintain safety and structural integrity.

## Storage

When not in use, proper storage will extend the life of your teepee tent:

- **Disassembly:** Disassemble the teepee by reversing the assembly steps. Untie the poles, remove them from the fabric sleeves, and separate the pole sections.
- **Folding:** Fold the fabric cover neatly.
- **Packing:** Place the folded fabric cover and disassembled poles into the provided canvas carry bag.
- **Location:** Store the packed teepee in a cool, dry place away from direct sunlight and moisture to prevent mildew and material degradation.




Image: The teepee tent folded and stored compactly against a wall, demonstrating its space-saving design when not in use.

## Safety Information

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**
Always supervise children when they are playing in or around the teepee tent. Ensure the teepee is set up on a flat, stable surface. Do not use near open flames or heat sources. Regularly check all connections and components for security and damage.

## Troubleshooting

- **Teepee is unstable:** Ensure all pole sections are fully connected and the poles are tightly bound at the top. Spread the base evenly to maximize stability.
- **Poles bowing or bending:** Verify that the teepee is not overloaded or subjected to excessive force. Ensure the poles are correctly inserted into the fabric sleeves and properly secured at the top.
- **Fabric appears wrinkled:** The cotton fabric may wrinkle during storage. Light steaming or ironing on a low setting can help smooth out wrinkles.

## Specifications

| | |
|---|---|
| **Product Dimensions** | 60 x 50 x 80 inches (approx. 50" x 50" x 85" as per feature bullets) |
| **Item Weight** | 10.93 pounds |
| **Manufacturer Recommended Age** | 3 years and up |
| **Material** | 100% Cotton Fabric, Steel Poles |
| **Design** | 5 Sides, Wide Open Front (without door flaps) |




Image: This diagram provides key measurements of the teepee (50” x 50” x 85”) and indicates its capacity to accommodate up to 3 children or 1 adult.

## Warranty and Support

For warranty information or customer support, please refer to the product packaging or contact Razee customer service directly through their official website or the retailer where the product was purchased. Keep your purchase receipt for any warranty claims.