Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave TH-00357R-TXLQ-K

Bellemave Metal Twin XL Over Queen Bunk Bed Instruction Manual

Model: TH-00357R-TXLQ-K

Important Safety Information

Please read all instructions carefully before assembly and use of this bunk bed. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the recommended weight capacity for each bunk.
- **Guardrails:** Ensure all guardrails are securely installed on the upper bunk.
- **Ladder Safety:** Always use the provided ladder for access to the upper bunk. Do not jump on or off the bed.
- **Assembly:** Assemble the bed frame according to the provided instructions. Ensure all connections are tight and secure before use.
- **Clearance:** Maintain clear space around the bed, free from sharp objects or heavy items.
- **Children:** The upper bunk is not suitable for children under 6 years of age.
- **Mattress Size:** Use only mattresses of the specified size to ensure proper fit and safety.

This product has passed several Children's Product Certificate (CPC) tests, ensuring its safety standards.

Product Overview

The Bellemave Metal Twin XL Over Queen Bunk Bed is designed for space-saving and durability. It features a robust metal frame with anti-rust powder coating, suitable for both adults and children.



Image: Bellemave Metal Twin XL Over Queen Bunk Bed.

Key Features:

- **Space-Saving Design:** Twin XL over Queen configuration maximizes vertical space.
- **Heavy-Duty Metal Frame:** Constructed from strong metal with anti-rust powder coating for long-term durability.
- **Enhanced Stability:** Reinforced thicker legs on the bottom bunk and sturdy screw connections.
- **Safety Features:** Full-length guardrails on the upper bunk and an easy-climb ladder.
- **Noise Reduction:** Plastic stoppers secure slats to prevent shifting and noise.
- **Under-Bed Storage:** Approximately 9.8 inches of clearance under the bottom bunk for storage.
- **No Box Spring Needed:** Slatted bed base eliminates the need for a box spring.

Product Dimensions:

Dimension	Measurement

Overall Length	82.7 inches
Overall Width	63 inches
Overall Height	64.6 inches
Under-bed Clearance	9.8 inches
Upper Bunk Guardrail Height	13 inches




Image: Detailed dimension diagram of the bunk bed.

Setup and Assembly Instructions

Assembly of the Bellemave Metal Twin XL Over Queen Bunk Bed is designed to be straightforward. All necessary tools and hardware are included in the packaging. It is recommended to assemble the bed with at least two adults.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the parts list (not provided in this manual, refer to your product packaging) are present and undamaged.
2. **Identify Parts:** Lay out all parts on a soft, clean surface to prevent scratches. Refer to the assembly diagram (refer

to your product packaging) to identify each component.

3. **Assemble Lower Bunk:** Begin by assembling the frame for the lower (Queen size) bunk. Connect the side rails to the headboard and footboard using the provided hardware. Ensure all connections are finger-tight initially.
4. **Install Lower Slats:** Place the metal slats onto the lower bunk frame. Secure them using the plastic stoppers and any additional fasteners as indicated in the assembly guide.
5. **Assemble Upper Bunk:** Follow similar steps to assemble the frame for the upper (Twin XL size) bunk. Attach the side rails to the headboard and footboard.
6. **Install Upper Slats and Guardrails:** Secure the metal slats for the upper bunk. Install the full-length guardrails around the perimeter of the upper bunk, ensuring they are firmly attached.
7. **Attach Ladder:** Securely attach the easy-climb ladder to the designated points on the bunk bed frame.
8. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Do not overtighten.
9. **Stability Check:** Gently shake the assembled bed to ensure it is stable and all connections are secure.

For a visual guide to assembly, please refer to the official product video:

Your browser does not support the video tag.

Video: Assembly demonstration for a similar Bellemave bunk bed model.

Operating Instructions (Usage)

This bunk bed is designed for sleeping and resting. Adhere to the following guidelines for safe and proper use:

- **Mattress Placement:** Place a Twin XL mattress on the upper bunk and a Queen mattress on the lower bunk. Ensure mattresses fit snugly within the frame.
- **Ladder Use:** Always use the ladder to access the upper bunk. Face the ladder when climbing up or down.
- **No Horseplay:** Prohibit jumping, rough play, or hanging from any part of the bunk bed.
- **Weight Distribution:** Distribute weight evenly on both bunks. Avoid concentrating weight in one area.
- **Lighting:** Ensure adequate lighting near the ladder for safe nighttime use.
- **Under-Bed Storage:** Utilize the space under the bottom bunk for storage of lightweight items. Do not overload this area.

Maintenance

Regular maintenance will help prolong the life and safety of your Bellemave bunk bed.

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as necessary.
- **Slat Inspection:** Inspect the bed slats and plastic stoppers regularly for any signs of wear or damage. Replace any damaged parts immediately.
- **Rust Prevention:** The frame has an anti-rust powder coating. If the coating is scratched, touch up with appropriate paint to prevent rust.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises during use.	Loose connections or shifting slats.	Retighten all hardware. Verify plastic stoppers are correctly installed and securing the slats.
Difficulty assembling parts.	Incorrect orientation or missing hardware.	Refer to the assembly instructions and diagrams. Ensure parts are oriented correctly. Contact customer support if hardware is missing.
Ladder feels loose.	Ladder attachment points are not secure.	Ensure the ladder is properly hooked and bolted to the bed frame. Tighten all ladder fasteners.

Specifications

- **Model:** TH-00357R-TXLQ-K
- **Brand:** Bellemave
- **Material:** Metal
- **Color:** White Ladders
- **Finish:** Painted (White)
- **Style:** Modern, Stacked Bunk Bed
- **Upper Bunk Mattress Compatibility:** Twin XL
- **Lower Bunk Mattress Compatibility:** Queen
- **Product Dimensions (L x W x H):**82.7" x 63" x 64.6"
- **Item Weight:** 47 Pounds
- **Special Features:** No Box Spring Needed, Guardrails, Slats, Noise-reducing plastic stoppers, Under-bed storage.
- **Assembly Required:** Yes

Warranty and Support

For any questions, concerns, or assistance with your Bellemave Metal Twin XL Over Queen Bunk Bed, please contact our customer support team.

- **Email Support:** US-VC@bellemavehome.com
- **Warranty Information:** Please refer to the warranty card included with your product packaging for specific details regarding coverage and duration.

We are committed to providing high-quality products and support.

© 2026 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH4TJWVH

More documents and user manuals: **https://manuals.plus/**