Surtime 6666

Surtime 48IN 6666 Ceiling Fan with RGB Lights User Manual

Model: 6666 | Brand: Surtime

Introduction

Thank you for choosing the Surtime 48IN 6666 Ceiling Fan with RGB Lights. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read it thoroughly before installation and keep it for future reference.

Safety Information

- Always turn off the power at the circuit breaker before installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances.
- Consult a qualified electrician if you are unsure about wiring.
- Mount the fan to a ceiling joist or support structure capable of holding at least 35 lbs (15.9 kg).
- Keep hands and objects clear of the fan blades during operation.
- Do not use the fan in wet or damp locations. This fan is designed for indoor use only.
- Ensure the fan is installed at a height where blades are at least 7 feet (2.13 meters) from the floor.

Package Contents

Please check that all components are present before beginning installation. If any parts are missing or damaged, contact Surtime customer support.

- Ceiling Fan Motor Housing
- Fan Blades (5x)
- Light Kit with RGB LED
- Remote Control
- Mounting Bracket
- Downrod (if applicable)
- Hardware Pack (screws, wire nuts, washers)

- User Manual

Specifications

Brand	Surtime
Model Number	6666
Size	48 inches
Color	Black
Material	Acrylic, Plastic
Power Source	DC Motor
Special Features	RGB LED Light, Dimmable, Reversible Motor, Remote Control, App Control, Smart Memory Function
Mounting Type	Ceiling Mount
Dimensions (L x W x H)	121.9 x 121.9 x 121.9 cm (48 x 48 x 48 inches)
Assembly Required	Yes

Setup and Installation

The Surtime 48IN 6666 ceiling fan features an innovative design for easier blade installation. For detailed step-by-step instructions, please refer to the separate installation guide included in your package. A professional electrician is recommended for installation.

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting location is secure and can support the fan's weight.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling junction box or support beam.
3. **Assemble Fan Motor:** Attach the downrod (if applicable) to the motor housing.
4. **Hang Fan Assembly:** Carefully lift the fan assembly and hang it on the mounting bracket.
5. **Wire Connections:** Connect the electrical wires (live, neutral, ground) according to the wiring diagram in the detailed installation guide. Use wire nuts to secure connections.
6. **Attach Light Kit:** Connect the light kit wiring and secure the light kit to the fan motor housing.
7. **Install Fan Blades:** Attach the fan blades to the motor housing. The innovative design allows for tool-free blade installation.
8. **Secure Canopy:** Raise the canopy to cover the mounting bracket and wiring, securing it in place.
9. **Restore Power:** Turn on power at the circuit breaker.

Note: If you encounter difficulties during installation, please consult the detailed installation videos provided by Surtime or contact customer support.

Operating Instructions

Your Surtime 48IN 6666 Ceiling Fan can be operated using the included remote control or a mobile application.

Remote Control Operation



Image: Remote control for the Surtime 48IN 6666 Ceiling Fan, illustrating buttons for fan speed, light color temperature, timer settings, and fan direction (forward/reverse).

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Use the speed buttons (1-6) to adjust the fan's airflow. There are 6 adjustable wind speeds:
  - 1-2 Gear: Comfortable Wind
  - 3-4 Gear: Natural Wind
  - 5-6 Gear: Strong Wind
- **Light Control:**
  - **On/Off:** Separate light button to turn the light on or off.
  - **Color Temperature (CCT):** Cycle through 3000K (Warm Light), 4500K (Natural Light), and 6000K (White Light).
  - **RGB Colors:** Select from 7 RGB colors and various dynamic modes (static, gradient, strobe).

    - **Brightness:** Adjust the light brightness levels.
- **Reversible Motor:** Use the forward/reverse button to change the fan's direction.
    - **Summer Mode (Downdraft):** Blades rotate counter-clockwise to create a cooling breeze.
    - **Winter Mode (Updraft):** Blades rotate clockwise to circulate warm air near the ceiling.
- **Timer:** Set the fan to turn off automatically after 2 or 4 hours.



Image: Visual representation of the fan's lighting capabilities, including dimmable white light (3000K, 4500K, 6000K) and various RGB color options (Red, Purple, Green, Blue, Colorful).



Image: The reversible motor feature of the Surtime ceiling fan, showing how it creates a downdraft for cooling in summer and an updraft for circulating warm air in winter.



Image: Diagram showing the 6 adjustable fan speeds, categorized into Comfortable Wind (1-2), Natural Wind (3-4), and Strong Wind (5-6) for different scenarios.

Mobile Application Control

Download the Surtime mobile application (refer to the included quick start guide for QR code or app store links) to control your fan from your smartphone. The app offers similar functionalities to the remote control, including:

- Adjusting fan speed (6 levels)
- Controlling light on/off, color temperature, RGB colors, and brightness.
- Setting the fan direction (forward/reverse).
- Programming the timer (2/4 hours).

Smart Memory Function

The fan's intelligent memory function saves your preferred brightness and color settings for the light. If you turn off the lights for at least 10 seconds, the fan will recall your last settings the next time it is powered on. Turning the light on within 10 seconds may result in a change of color temperature.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Fasteners:** Check all screws and fasteners annually to ensure they are securely tightened.
- **Blade Balance:** If the fan wobbles, check that all blades are securely attached and balanced. A balancing kit (not included) may be used if necessary.
- **Light Source:** The LED light source is integrated and generally does not require replacement. If the light fails, contact customer support.

Warning: Always disconnect power at the circuit breaker before performing any cleaning or maintenance.

Troubleshooting

Refer to the table below for common issues and their solutions. If the problem persists, contact Surtime customer support.

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote control battery dead.	Check circuit breaker; Ensure all wires are securely connected; Replace remote control battery.
Light does not work, but fan operates	Loose light kit wiring; Faulty LED driver.	Check light kit connections (with power off); Contact customer support for light kit replacement.
Fan operates, but light does not work	Loose light kit wiring; Faulty LED driver.	Check light kit connections (with power off); Contact customer support for light kit replacement.
No RGB or color change function	App/remote not paired correctly; Software glitch; Product defect.	Ensure remote/app is correctly paired (refer to quick start guide); Restart fan by cycling power; Contact customer support.
Fan wobbles excessively	Loose blades; Unbalanced blades; Loose mounting.	Ensure all blade screws are tight; Use a blade balancing kit; Check mounting bracket security.
Remote control not working	Dead battery; Obstruction; Not paired.	Replace battery; Ensure clear line of sight to receiver; Re-pair remote with fan (refer to quick start guide).

Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact Surtime customer service. You can typically find contact details by visiting the Surtime store page on the product's original purchase platform or by referring to the contact information provided in your product packaging.
Extended warranty options may be available through third-party providers at the time of purchase.

© 2026 Surtime. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question