Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEROZY BUMAITS05

AEROZY Windowless Portable Evaporative Air Cooler

Model: BUMAITS05

Introduction

This manual provides essential information for the safe and efficient operation of your AEROZY Windowless Portable Evaporative Air Cooler, Model BUMAITS05. Please read these instructions carefully before use and retain them for future reference.





Image: The AEROZY BUMAITS05 evaporative air cooler, a tall white tower unit with a digital display, accompanied by its remote control.

Safety Instructions

- Always place the unit on a stable, level surface.
- Do not immerse the unit, power cord, or plug in water or other liquids.
- Unplug the unit from the power outlet when not in use, when moving, or before cleaning.
- Keep the unit away from heat sources and direct sunlight.
- Do not block air inlets or outlets.
- Ensure the water tank is properly secured before operation.
- Keep out of reach of children and pets.

Package Contents

- AEROZY Evaporative Air Cooler (1 unit)
- Instruction Manual (1 unit)
- Ice Boxes (3 units)
- Remote Control (1 unit)

Setup

1. Unpacking and Placement

Carefully remove all packaging materials. This unit features a slim, space-saving design (45.1" H x 8.7" W x 8.9" D) that fits neatly beside furniture or in tight corners. No window or exhaust hose is required for operation.



Image: Visual representation of the unit's handle for portability, the 1-gallon water tank, the tool-free assembly of the base, and the digital display.

2. Tool-Free Assembly

The base of the unit requires simple, tool-free assembly. Align the base with the main body and push firmly until it snaps into place.

3. Filling the Water Tank

The unit features an extra-large 1.06-gallon water tank for extended cooling. To fill, locate the water tank access point, typically at the top or rear of the unit. Pour clean, cool water into the tank, ensuring not to exceed the maximum fill line. The water level is visible at the front of the tower.

Your browser does not support the video tag.

Video: A demonstration of filling the water tank of the AEROZY evaporative air cooler and inserting ice packs for enhanced cooling.

4. Using Ice Packs for Enhanced Cooling

For a stronger cooling effect, place the included ice packs (3 units) into the freezer until completely frozen. Once frozen, place them directly into the water tank along with the water. This boosts evaporative cooling, providing faster relief in hot conditions.



Image: Detailed view of the unit's dimensions (45.1" H, 11.8" W, 11.8" L), the three included ice boxes (5.5" x 3.4" x 1.0"), and the new designed remote control (4.7" x 1.6").

Operating Instructions

1. Power On/Off

Plug the unit into a standard electrical outlet. Press the power button on the control panel or the remote control to turn the unit on or off.

2. Digital Display and Controls

The unit features a digital display on the front, showing the current temperature and selected settings. Control buttons are located on the top panel of the unit and on the remote control for convenient operation from a distance.




Image: Illustrates the remote control functionality, showing options for 3 fan speeds, 4 operating modes (Natural, Normal, Cooling, Sleep), and other features like On/Off, Oscillation, and Timer.

3. Fan Speeds and Modes

Select from 3 fan speeds (low, medium, high) and 4 operating modes: Cool, Eco, Natural, or Sleep. Adjust settings based on your comfort preference and time of day.



Image: The air cooler positioned in a room, highlighting its ability to provide significant cooling volume and coverage.

4. Quiet Operation

The unit is designed for quiet operation, producing approximately 36.9dB, making it suitable for bedrooms and other quiet environments.



Image: The AEROZY air cooler operating quietly in a bedroom setting, highlighting its low noise level of 36.9dB.

5. Oscillation Function

Activate the oscillation function for dynamic, room-wide air distribution. The unit can oscillate up to 60 degrees to cover a larger area.



Image: The air cooler demonstrating its 60-degree oscillation feature, showing air being distributed widely across a room.

6. Timer Function

Set the 12-hour timer to automatically turn off the unit after a specified duration, ideal for overnight use or when leaving the room.



Image: The air cooler with a graphic indicating its 12-hour timer capability, suggesting long-lasting comfort.

Maintenance

1. Cleaning the Water Tank

Regularly clean the water tank to prevent mineral buildup and maintain optimal performance. Unplug the unit, remove the water

tank, and wash it with mild soap and water. Rinse thoroughly before refilling.

2. Cleaning the Exterior

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

3. Air Filter/Cooling Pad Maintenance

Periodically check the honeycomb cooling pad for dust or debris. Refer to the unit's specific design for instructions on how to access and clean or replace the cooling pad if necessary.




Image: An exploded view of the air cooler's internal components, highlighting the Honeycomb Cooling Pad, Powerful Water Pump, and the AeroDrive motor, which contribute to efficient airflow and cooling.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not turn on	No power supply; Power button not pressed.	Ensure the unit is plugged into a working outlet. Press the power button firmly.
Weak airflow or no cooling	Low water level; Dirty cooling pad; Fan speed too low.	Refill the water tank. Clean or replace the cooling pad. Increase the fan speed. Add frozen ice packs.
Water leakage	Water tank not properly seated; Overfilled water tank; Unit not on a level surface.	Ensure the water tank is securely in place. Do not overfill the tank. Place the unit on a flat, stable surface.
Unusual noise	Unit not on a level surface; Obstruction in fan; Water pump noise.	Place the unit on a flat surface. Check for and remove any obstructions. Some water bubbling noise from the pump is normal.

Specifications

Feature	Detail
Brand	AEROZY
Model Name	BUMAITS05
Mounting Type	Freestanding
Special Feature	Portable
Color	White
Controls Type	Remote
Reservoir Capacity	1.06 Gallons
Product Dimensions	45.1"D x 8.7"W x 8.9"H
Item Weight	14.77 pounds
Operation Mode	Automatic
Batteries Required?	Yes (for remote control)

Warranty and Support

Warranty Information

This AEROZY product comes with a 1-Year Warranty. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact AEROZY customer support. Refer to the product packaging or the official AEROZY website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH69XXXV

More documents and user manuals: **https://manuals.plus/**