Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-C3295

XINFUTE RM-C3295 Remote Control User Manual

Model: RM-C3295 | Compatible with JVC 4K Smart Voice TV and RM-C3293

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your XINFUTE RM-C3295 Remote Control. Designed for seamless compatibility with JVC 4K Smart Voice TVs and RM-C3293 models, this remote offers an ergonomic design and voice search capabilities for enhanced user experience.

Please read this manual thoroughly before using the remote control to ensure proper functionality and longevity of the device.



Figure 1: Front view of the RM-C3295 Remote Control.

Product Overview

The RM-C3295 is a dedicated replacement remote control unit, crafted from durable ABS material. It is designed to provide full functionality for compatible JVC 4K Smart Voice TVs, specifically those originally supplied with the RM-C3293 remote control.

Key Features:

- **Ergonomic Design:** Comfortable to hold and use for extended periods.
- **Voice Search Functionality:** Allows for convenient voice commands to control your TV.
- **Infrared Connectivity:** Reliable communication with your television.
- **Direct Access Buttons:** Includes dedicated buttons for popular streaming services like Netflix and YouTube.





Figure 2: Side view of the RM-C3295.



Figure 3: Back view of the RM-C3295.

Setup

Installing Batteries:

The RM-C3295 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Gently slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 4: Battery compartment with batteries installed.

Once batteries are installed, the remote control is ready for use with compatible JVC 4K Smart Voice TVs. No pairing or programming is typically required for this replacement unit.

Operating Instructions

The RM-C3295 remote control functions identically to the original RM-C3293 remote. Point the remote directly at your television's infrared receiver for optimal performance.

Basic Functions:

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel input.
- **Volume Up/Down (+/-):** Adjusts the volume level.

- **Channel Up/Down (∧ / ∨):** Changes TV channels.
- **Mute ( ):** Mutes or unmutes the TV sound.
- **Input/Source ( ):** Selects input sources (HDMI, AV, etc.).
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back (↩):** Returns to the previous screen or menu.
- **Home ( ):** Accesses the TV's home screen or smart hub.

Smart and Voice Functions:

- **Voice Search Button ( ):** Activates the voice search feature. Hold the button and speak your command or search query.
- **Netflix Button:** Direct access to the Netflix application.
- **YouTube Button:** Direct access to the YouTube application.
- **Other App Buttons:** Dedicated buttons for other pre-installed streaming applications (e.g., Prime Video, Google Play).

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, direct sunlight, or moisture. Keep it away from liquids.

Troubleshooting

If you experience issues with your RM-C3295 remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control is not working.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote control range is poor.	Obstruction between remote and TV; low batteries.	Ensure a clear line of sight to the TV's IR receiver. Replace batteries if they are old.
Specific buttons are not responding.	Dirty contacts; remote malfunction.	Clean the remote's surface. If problem persists, consider replacing the remote.
Voice search not working.	Microphone obstruction; TV settings.	Ensure nothing is blocking the microphone. Check your TV's settings for voice control activation.

If the issue persists after trying these solutions, please refer to the Support section.

Specifications

Feature	Detail
Model Number	RM-C3295
Compatible TV Models	JVC 4K Smart Voice TV (originally supplied with RM-C3293)
Brand	XINFUTE
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches (approximate)
Item Weight	2.82 ounces (approximate)
Special Features	Ergonomic design, Voice Search capability

Warranty Information

XINFUTE provides a one-year warranty on all purchases of the RM-C3295 remote control. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

Please retain your proof of purchase for warranty claims. For more details on warranty terms and conditions, please contact customer support.

Customer Support

If you have any questions, require assistance, or are not satisfied with your purchase, please contact XINFUTE customer support. All goods are inspected before shipment. If you are not satisfied with your purchase, you can contact us within 24 hours of receipt.

For support, please visit the XINFUTE Store on Amazon or refer to the contact information provided with your purchase.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH6NG5RT

More documents and user manuals: **https://manuals.plus/**