

[Manuals.plus](#) /

› [Moen](#) /

› Moen Weylon 84790SRN Bathroom Faucet Instruction Manual

Moen 84790SRN

Moen Weylon 84790SRN Bathroom Faucet Instruction Manual

Model: 84790SRN

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Moen Weylon 84790SRN Two-Handle High-Arc Bathroom Faucet. Designed for modern elegance and effortless maintenance, this faucet features a Spot-Resist™ Brushed Nickel finish and is WaterSense Certified for efficient water usage. Please read this manual thoroughly before beginning installation or operation to ensure proper function and longevity of your product.

- **Elegant High-Arc Design:** Offers sleek visual appeal and increased sink room.
- **Dual Lever Handles:** ADA-compliant for smooth control of hot and cold water.
- **Spot-Resist Brushed Nickel Finish:** Resists fingerprints and water spots for a cleaner appearance.
- **WaterSense Certified:** Reduces water usage without compromising performance.
- **4" Centerset Installation:** Designed to fit most 3-hole sinks.
- **Lift-Rod Drain Assembly:** Included for coordinated style and functionality.

SETUP AND INSTALLATION

The Moen Weylon 84790SRN faucet is designed for a 4-inch centerset installation on 3-hole sinks. It includes 1/2-inch IPS connections for standard plumbing. Ensure you have all necessary tools and components before beginning the installation process.



Figure 1: Moen Weylon 84790SRN Two-Handle High-Arc Bathroom Faucet. This image shows the complete faucet assembly, highlighting its brushed nickel finish and dual lever handles.

Pre-Installation Checklist:

1. Verify all parts are present as per the packing list.
2. Ensure your sink has the required 3 holes with a 4-inch centerset configuration.
3. Turn off the main water supply to the bathroom.
4. Clear the area under the sink for easy access.

Installation Steps (General):

- Position the faucet body and handles onto the sink holes.
- Secure the faucet from underneath the sink using the provided mounting hardware.
- Connect the hot and cold water supply lines to the faucet's 1/2-inch IPS connections.
- Install the lift-rod drain assembly according to the separate instructions provided with the drain.
- Once all connections are secure, slowly turn on the water supply and check for leaks.



Figure 2: Product Dimensions. This diagram illustrates the key measurements of the Moen Weylon 84790SRN faucet, showing its 4-inch depth, 8.2-inch width, and 7-inch height.

OPERATING INSTRUCTIONS

The Moen Weylon faucet is designed for intuitive operation with its dual lever handles and high-arc spout.

Water Flow and Temperature Control:

- The left lever controls hot water.
- The right lever controls cold water.
- Adjust both levers simultaneously to achieve your desired water temperature and flow rate.
- The high-arc spout provides ample clearance for various tasks, such as washing hands or filling containers.

This faucet is WaterSense Certified, meaning it meets EPA criteria for water efficiency and performance, with a maximum flow rate of 1.2 Gallons Per Minute (GPM).



Figure 3: Faucet in Use. This image displays the Moen Weylon faucet installed on a bathroom vanity, demonstrating its aesthetic integration and functional design in a typical bathroom environment.

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Moen Weylon faucet, especially its Spot-Resist™ Brushed Nickel finish.

Cleaning the Finish:

- To clean the Spot-Resist™ Brushed Nickel finish, use a soft, damp cloth and mild soap.
- Rinse thoroughly with warm water and dry with a soft cloth to prevent water spots.

- **Do not** use abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish and void the warranty.
- The Spot-Resist™ feature helps minimize fingerprints and water spots, making routine cleaning easier.

Aerator Maintenance:

- Periodically unscrew the aerator from the end of the spout.
- Rinse any debris or mineral buildup from the aerator screen under running water.
- Reattach the aerator securely. This helps maintain optimal water flow.

TROUBLESHOOTING

If you encounter issues with your Moen Weylon faucet, refer to the common troubleshooting tips below. For problems not listed, please contact Moen customer support.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; kinked supply lines.	Clean aerator; fully open shut-off valves; inspect and straighten supply lines.
Leaking from Spout	Worn out O-rings or seals; loose connections.	Tighten connections; replace O-rings/seals (contact Moen support for parts).
Water Temperature Issues	Incorrect hot/cold supply connections; issues with water heater.	Verify supply line connections; check water heater settings.

SPECIFICATIONS

Feature	Detail
Brand	Moen
Model Name	Weylon
Part Number	84790SRN
Mounting Type	Deck Mount
Installation Type	Centerset (4-inch)
Hole Count	3
Finish Type	Brushed
Color	Spot Resist Brushed Nickel
Material	Brass (Faucet Body), Metal (Handles)
Number of Handles	2
Maximum Flow Rate	1.2 Gallons Per Minute (GPM)
Product Dimensions (D x W x H)	4"D x 8.2"W x 7"H
Item Weight	1.95 Pounds

Included Components	Faucet with two handles, Escutcheon plate, Lift-rod drain assembly, 1/2" IPS connections, Valve
Special Features	Spot Resist Finish, Easy Installation, Pop Up Drain
WaterSense Certified	Yes
ADA-Compliant	Yes

WARRANTY AND SUPPORT

Your Moen Weylon 84790SRN faucet is backed by Moen's Limited Lifetime Warranty, ensuring long-term durability and support. This warranty covers defects in material and manufacturing workmanship for the original consumer purchaser. For warranty claims, technical assistance, or to order replacement parts, please contact Moen Incorporated directly. You can find more information and contact details on the official Moen website or by visiting the [Moen Store on Amazon](#).
Note: Always refer to the official Moen warranty documentation for complete terms and conditions.

© 2025 Moen Incorporated. All rights reserved.
For more information, visit www.moen.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FH7LN6BV>

More documents and user manuals: <https://manuals.plus/>