

[manuals.plus](#) /› [Intex](#) /› [Intex 66505EP Beanless Bag Inflatable Lounge Chair User Manual](#)**Intex 66505EP**

Intex Beanless Bag Inflatable Lounge Chair User Manual

MODEL: 66505EP

1. Introduction and Overview

Thank you for choosing the Intex Beanless Bag Inflatable Lounge Chair. This manual provides essential information for the safe and proper setup, operation, and maintenance of your inflatable chair. Please read all instructions carefully before use and retain this manual for future reference.

The Intex Beanless Bag Chair offers a comfortable and versatile seating solution. Its design allows for quick inflation and easy deflation, making it convenient for storage or transport. Constructed from durable vinyl with a soft fabric-like flocked top, it is suitable for both indoor and outdoor use.



Image 1.1: The Intex Beanless Bag Inflatable Lounge Chair in Beige.

2. Safety Information

To ensure safe use and prevent injury or damage, please adhere to the following safety guidelines:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 220 lbs (100 kg). Overloading can cause damage to the chair and potential injury.
- **Sharp Objects:** Keep the chair away from sharp objects, heat sources, and open flames. Punctures or excessive heat can damage the vinyl material.
- **Children:** Children should be supervised at all times when using the inflatable chair.
- **Inflation:** Do not over-inflate the chair. Inflate until firm, but not rigid. Over-inflation can lead to bursting.
- **Placement:** Ensure the chair is placed on a smooth, level surface free of debris. Avoid rough or abrasive surfaces that could cause damage.
- **Repairs:** Do not attempt to repair large tears or punctures yourself. Refer to the troubleshooting section or contact customer support.

3. Package Contents

Verify that all components are present in the package:

- 1 x Intex Beanless Bag Inflatable Lounge Chair (Model 66505EP)

Note: An air pump is not included and must be purchased separately for inflation.

4. Setup Instructions

Follow these steps to set up your Intex Beanless Bag Inflatable Lounge Chair:

1. **Unpack:** Carefully remove the inflatable chair from its packaging.
2. **Inspect:** Unfold the chair and inspect it for any visible damage or punctures. If damage is found, do not proceed with inflation and contact customer support.
3. **Choose Location:** Select a clean, flat, and smooth surface for inflation and use. Ensure there are no sharp objects or debris that could puncture the chair.
4. **Inflate:** Locate the inflation valve(s) on the chair. Use a manual or electric air pump (not included) to inflate the chair. Insert the pump nozzle into the valve and begin inflation. Inflate until the chair is firm to the touch but still has some give. Do not over-inflate.
5. **Seal Valve:** Once inflated, quickly remove the pump nozzle and securely close the inflation valve cap to prevent air leakage.
6. **Check for Leaks:** After inflation, listen for any hissing sounds indicating air leaks. If a leak is suspected, refer to the troubleshooting section.



Image 4.1: Angled view of the inflated chair, illustrating its form.

5. Operating Instructions

Using your Intex Beanless Bag Inflatable Lounge Chair is straightforward:

- **Seating:** Gently sit on the chair, distributing your weight evenly.
- **Movement:** Avoid dragging the chair across rough surfaces when occupied, as this can cause damage. Lift

and move the chair as needed.

- **Weight Limit:** Always ensure the total weight on the chair does not exceed 220 lbs (100 kg).

6. Maintenance

Proper maintenance will extend the life of your inflatable chair:

- **Cleaning:** To clean, wipe the surface with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners, as these can damage the vinyl. Rinse thoroughly and allow to air dry completely before storing.
- **Storage:** When not in use, ensure the chair is clean and completely dry. Open the inflation valve(s) and gently press out all air until the chair is fully deflated. Fold it compactly and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Patching Small Leaks:** If a small puncture occurs, a repair patch kit (often sold separately or included with other Intex products) can be used. Clean the area around the puncture, apply the patch according to the kit's instructions, and allow sufficient drying time before re-inflating.



Image 6.1: Side view of the chair, demonstrating its compact profile when deflated or for storage.

7. Troubleshooting

If you encounter issues with your inflatable chair, refer to the following common problems and solutions:

- **Chair is losing air:**
 - Ensure the inflation valve cap is securely closed.
 - Check for punctures or small holes. Inflate the chair and apply soapy water to the surface; bubbles will indicate a leak. Patch small leaks as described in the Maintenance section.
 - Verify that the chair is not over-inflated, which can stress seams.

- **Chair does not inflate properly:**

- Ensure your air pump is functioning correctly and the nozzle fits snugly into the valve.
- Check for any obstructions in the inflation valve.

If these steps do not resolve the issue, please contact Intex customer support.

8. Specifications

Feature	Detail
Model Number	66505EP
Dimensions (Inflated)	42"D x 41"W x 27"H (107cm D x 104cm W x 69cm H)
Weight Capacity	220 lbs (100 kg)
Material	Durable Vinyl with Flocked Top
Color	Beige
Usage	Indoor / Outdoor
Item Weight	5.41 lbs (2.45 kg)
UPC	078257665051

9. Warranty Information

Specific warranty details for the Intex Beanless Bag Inflatable Lounge Chair are not provided in this manual. For information regarding product warranty, please refer to the documentation included with your purchase or visit the official Intex website.





10. Customer Support

If you have questions, require assistance, or need to report a problem with your Intex Beanless Bag Inflatable Lounge Chair, please contact Intex customer support. Contact information can typically be found on the product packaging or the official Intex website (www.intexcorp.com).

© 2025 Intex Recreation Corp. All rights reserved.

Intex is a registered trademark of Intex Marketing Ltd.

Related Documents - 66505EP

	<p>INTEX Owner's Manual: Built-in Fast-Fill™ Electric Pump Model AP619A</p> <p>Comprehensive owner's manual for the INTEX Built-in Fast-Fill™ Electric Pump Model AP619A, providing essential safety instructions, operating procedures for inflation and deflation, important notes on airbed care, and storage guidelines. Learn how to properly use and maintain your INTEX airbed pump.</p>
	<p>Intex Inflatable Water Toy User Manual & Safety Instructions</p> <p>Comprehensive user manual and safety guide for Intex inflatable water toys, covering warnings, inflation, maintenance, storage, and repair. Read and understand all instructions before use.</p>
	<p>INTEX Quick-Fill Electric Air Pump AP639 Owner's Manual and Instructions</p> <p>Official owner's manual for the INTEX Quick-Fill Electric Air Pump, Model AP639. Provides safety warnings, operating instructions for inflation and deflation, maintenance, and storage guidelines.</p>
	<p>Intex Auto Pool Cleaner Owner's Manual and Setup Guide</p> <p>Comprehensive owner's manual for the Intex Auto Pool Cleaner. Includes setup instructions, parts reference, cleaning guides, troubleshooting tips, and safety information for maintaining your pool cleaner.</p>
	<p>Intex Frame Pool Set Family User Manual - Models 260x160x65cm and Others</p> <p>Comprehensive user manual for Intex Frame Pool Set Family models, including setup instructions, maintenance guidelines, troubleshooting tips, and warranty information for safe and enjoyable pool use.</p>
	<p>Intex Electric Pool Heater HT30221-2 Owner's Manual</p> <p>This owner's manual provides essential safety rules, setup instructions, operating procedures, troubleshooting guide, and warranty information for the Intex HT30221-2 Electric Pool Heater. Learn how to safely install, operate, and maintain your pool heater for optimal performance.</p>