

Futanwei 18mm Watch Bands

Quick Release Watch Band Instruction Manual

Model: 18mm Watch Bands

INTRODUCTION

This manual provides instructions for the Futanwei Quick Release Watch Band. Designed for comfort and durability, this silicone watch band is an ideal replacement or accessory for compatible smartwatches. Its quick-release mechanism allows for easy installation and removal without the need for special tools.

Package Content: 1 x Quick Release Watch Band (18mm)

COMPATIBLE MODELS

This watch band is compatible with the following smartwatch models:

- TOOBUR DR06
- Fitpolo DR06
- KEEPONFIT DR05
- KIBFLE DR03
- YMZ DR03 Smart Watch

Note: This band is NOT compatible with TOOBUR IDW28 Smart Watch or other devices not listed above.

Compatible Model

Specially Designed for TOOBUR DR06 Smart Watch



Image: A smartwatch with a watch band, demonstrating the compatible model. This image helps users visualize the type of smartwatch the band is designed for.

PRODUCT FEATURES

- Material:** Made from high-quality, soft silicone and stainless steel components.
- Comfort:** Lightweight, flexible, and designed without sharp edges for comfortable wear.
- Durability:** Sturdy construction, washable, and resistant to fading.
- Design:** Features a fashionable fine grid pattern, offering an elegant and exquisite appearance.
- Adjustability:** Multiple holes allow for precise length adjustment, fitting wrist sizes from 140mm to 181mm (5.5 inches to 7.1 inches).



Image: A close-up view of the black silicone watch band, highlighting its texture and quick-release pins.






Image: An overhead view of the watch band, displaying the numerous adjustment holes and the tang buckle.

SETUP AND INSTALLATION

The Futanwei Quick Release Watch Band is designed for easy installation and removal without the need for any tools.

1. **Identify the Quick Release Pins:** Locate the small metal pins on the back of each end of the watch band. These are the quick-release spring bars.
2. **Align the Band:** Hold one end of the watch band with the quick-release pin facing the watch lug.
3. **Insert One Side:** Gently push the quick-release pin inwards (towards the band) using your finger.
4. **Position and Release:** Insert one end of the pin into the corresponding hole on the watch lug. Once one side is in, align the other end of the pin with the opposite hole on the watch lug.
5. **Secure the Band:** Release the quick-release pin. It should snap into place, securing the band to the watch. Gently tug on the band to ensure it is firmly attached.
6. **Repeat for Other Side:** Follow the same steps for the other half of the watch band.

To Remove: Simply pull the quick-release pin inwards and gently detach the band from the watch lug.

Easy to Install and Removal

Quick Release Spring Bars




Image: A visual guide demonstrating the quick-release spring bars and how they facilitate easy installation and removal of the watch band.

OPERATING AND USAGE

Once installed, the watch band can be adjusted to fit your wrist comfortably.

1. **Wear the Watch:** Place the smartwatch on your wrist.
2. **Adjust Length:** Thread the longer strap through the buckle on the shorter strap.
3. **Secure the Buckle:** Insert the tang (pin) of the buckle into one of the adjustment holes on the longer strap. Choose a hole that provides a snug, yet comfortable fit.
4. **Use the Keepers:** Slide the excess strap through the two silicone keepers to prevent it from flapping.

The band is designed for daily wear and is suitable for various activities, including outdoor sports like running, fitness, camping, and golf.



Image: A diagram illustrating the adjustable length of the watch band, showing the minimum (5.5 inches) and maximum (8.7 inches) wrist circumference it can accommodate.

MAINTENANCE

To ensure the longevity and appearance of your Futanwei Quick Release Watch Band, follow these simple maintenance guidelines:

- **Cleaning:** The silicone material can be washed repeatedly. Use mild soap and water to clean the band. Rinse thoroughly and dry with a soft cloth.
- **Avoid Harsh Chemicals:** Do not expose the band to strong chemicals or solvents, as these may damage the

silicone or stainless steel components.

- Storage:** When not in use, store the band in a clean, dry place away from direct sunlight and extreme temperatures.
- Inspection:** Periodically inspect the quick-release pins and buckle for any signs of wear or damage.

TROUBLESHOOTING

If you encounter any issues with your watch band, please refer to the following common solutions:

Problem	Possible Cause	Solution
Band does not attach securely to watch.	Quick-release pin not fully engaged; incorrect band width.	Ensure the quick-release pin is fully seated in the watch lug holes. Verify that your watch requires an 18mm band.
Band feels too loose or too tight.	Incorrect adjustment hole selected.	Adjust the tang buckle to a different hole on the strap until a comfortable fit is achieved. The band fits wrists from 140mm to 181mm.
Band appears dirty or discolored.	Accumulation of dirt, sweat, or oils.	Clean the band with mild soap and water, then rinse and dry thoroughly.

If you experience issues not covered here, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	18mm Watch Bands
Material	Silicone
Metal Type	Stainless Steel
Clasp Type	Tang Buckle
Strap Width	18mm
Strap Length (each piece)	92 mm and 121 mm
Wearable Wrist Size	140mm to 181mm (5.5" to 7.1")
Department	Unisex Adult
Manufacturer	Futanwei
ASIN	B0FH94LZB1

WARRANTY AND SUPPORT

Futanwei is committed to providing high-quality products. If you have any issues with your Quick Release Watch Band, please do not hesitate to contact us. We will do our best to solve your problem quickly and efficiently.

For support, please refer to the contact information provided with your purchase or visit the official Futanwei brand page on Amazon.

© 2025 Futanwei. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.