

[Manuals.plus](#) /

> [YASONIC](#) /

> YASONIC 3 Tier Rolling Cart User Manual

## YASONIC YS-K-305

# YASONIC 3 Tier Rolling Cart User Manual

Model: YS-K-305

## INTRODUCTION

Thank you for choosing the YASONIC 3 Tier Rolling Cart. This versatile utility cart is designed to provide efficient and flexible storage solutions for various spaces, including kitchens, offices, craft rooms, and more. Its robust metal construction and smooth-rolling wheels ensure durability and ease of use. This manual provides essential information for safe assembly, operation, and maintenance of your new rolling cart.



Image: The YASONIC 3 Tier Rolling Cart in white, showcasing its three mesh baskets filled with household and office supplies, along with hanging cups and hooks.

## SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using the cart. Keep this manual for future reference.

- Do not exceed the maximum weight limit of 66 lbs (30 kg) for the entire cart. Distribute weight evenly across the shelves.
- Ensure all screws are securely tightened before use to prevent wobbling or collapse.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Use the cart on a flat, stable surface. Engage wheel locks when the cart needs to remain stationary.
- Avoid placing hot items directly on the mesh baskets without proper insulation.
- Do not stand or climb on the cart.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Side Frames (2)
- Mesh Baskets (3)
- Wheels (4, 2 with locking mechanism)
- Hanging Cups (2)
- Hooks (3)
- Screws (12 identical screws)
- Assembly Tools (Wrench, Screwdriver)

## SETUP AND ASSEMBLY

Assembly is designed to be straightforward and can typically be completed within 15 minutes with the provided tools.

1. **Step 1: Install the Frame.** Connect the two side frames (A and B) by aligning the designated slots and pushing them together until they click into place.
2. **Step 2: Insert Baskets.** Gently press each mesh basket inward until its width matches the frame. Slide the baskets into their respective grooves on the side frames.
3. **Step 3: Secure with Screws.** Use the provided screws and tools to secure each basket to the frame. Ensure all 12 screws are tightened for stability.
4. **Step 4: Install Wheels.** Screw the four wheels into the designated holes at the bottom of the frame. Two of the wheels have locking mechanisms; it is recommended to install these on the

same side for easier access.

- Step 5: Attach Accessories.** Hang the two cups and three hooks onto the side of the cart as desired for additional storage.



Image: Visual guide illustrating the four main steps for assembling the rolling cart, from frame installation to attaching wheels.

## OPERATING INSTRUCTIONS

Your YASONIC Rolling Cart is designed for ease of use and mobility.

- **Moving the Cart:** Gently push or pull the cart using the top handles. The 360-degree swivel wheels allow for effortless movement across various floor types, including carpet and hardwood, without scratching surfaces.
- **Locking the Wheels:** To keep the cart stationary, press down on the lever located on the two locking wheels until they click into place. To unlock, lift the lever.
- **Utilizing Storage:** Arrange items within the three spacious mesh baskets. Use the hanging cups for smaller items like pens, brushes, or utensils, and the hooks for towels, bags, or other accessories.

# Effortless Movement with High Loading



Image: A person effortlessly moving the YASONIC 3 Tier Rolling Cart, demonstrating its smooth mobility even when fully loaded.



Image: A detailed view of the cart's 2-inch heavy-duty wheel, highlighting its ball bearing for smooth rolling and wear-resistant urethane material for silent operation on various floors.

## **MAINTENANCE**

To ensure the longevity and appearance of your YASONIC Rolling Cart, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the metal surfaces and mesh baskets with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the high-gloss, scratch-resistant finish.
- **Drying:** Dry the cart thoroughly after cleaning to prevent water spots or rust.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Wheel Care:** Keep the wheels free of debris (hair, lint, etc.) to maintain smooth rolling.

## TROUBLESHOOTING

If you encounter any issues with your YASONIC Rolling Cart, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cart wobbles after assembly.	Screws are not fully tightened.	Ensure all 12 screws securing the baskets to the frame are tightened firmly.
Wheels do not roll smoothly.	Debris caught in wheels; wheel locks engaged.	Clear any debris from the wheels. Ensure wheel locks are disengaged.
Baskets seem loose or misaligned.	Baskets not fully seated in frame grooves.	Press baskets inward firmly to ensure they are fully seated and secured by screws.
Missing parts upon unboxing.	Packaging error.	Contact YASONIC customer service immediately for assistance.

## SPECIFICATIONS

Key technical details for the YASONIC 3 Tier Rolling Cart:

Feature	Detail
Product Dimensions (D x W x H)	15.35" x 11.45" x 29.79"
Material	Metal
Color	White
Number of Shelves	3
Item Weight	8 Pounds
Weight Limit	66 Pounds
Number of Wheels	4
Caster Type	Swivel, Locking
Assembly Required	Yes
Recommended Use	Indoor




Image: Detailed diagram illustrating the height, width, and depth of the YASONIC 3 Tier Rolling Cart, along with the dimensions of the hanging cups and hooks.

## WARRANTY AND SUPPORT

YASONIC is committed to providing high-quality products and excellent customer service. Your YASONIC 3 Tier Rolling Cart comes with a manufacturer's warranty covering defects in materials and workmanship.

For any questions, concerns, or assistance with assembly or product issues, please contact YASONIC customer service. We aim to provide a satisfactory solution within 24 hours.

**Contact Information:** Please refer to the contact details provided on your product packaging or the official YASONIC website for the most up-to-date support information.

