

## TIMU A10

# TIMU Bluetooth Headphones User Manual

Model: A10

## INTRODUCTION

This user manual provides detailed instructions for the operation, maintenance, and troubleshooting of your TIMU Bluetooth Headphones, Model A10. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

## PACKAGE CONTENTS

- TIMU Bluetooth Headphones (Left and Right Earbuds)
- Charging Case
- Charging Cable
- User Manual

## PRODUCT OVERVIEW



Image: TIMU Bluetooth Headphones (Model A10) shown inside their charging case. The case features a digital display indicating battery levels for both the case and individual earbuds. The earbuds are white with a stem design, and one earbud shows a touch control area with

a fingerprint icon.

The TIMU A10 headphones are true wireless in-ear headphones designed for comfort and high-quality audio. They feature Bluetooth 5.4 connectivity for stable connections and are equipped with 4 microphones for clear call quality. The compact charging case provides extended battery life and includes a digital display for convenient battery status monitoring.

Key Features:

- Bluetooth 5.4 for stable and efficient wireless connection.
- In-ear design for comfortable and secure fit.
- Four microphones for enhanced call clarity.
- Digital display on charging case for battery status.
- Intuitive touch controls for easy operation.

SETUP

1. Initial Charging

Before first use, fully charge the headphones and the charging case. Connect the charging cable to the charging port on the case and a USB power source. The digital display on the case will show the charging progress. Ensure both earbuds are placed correctly in the case for them to charge.

2. Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode (indicated by a flashing LED on the earbuds, if applicable, or a specific sound prompt).
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices.
4. Select **"TIMU A10"** from the list of found devices.
5. Once connected, a voice prompt will confirm successful pairing.

*Note: The headphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.*

OPERATING INSTRUCTIONS

Touch Controls

The TIMU A10 headphones feature intuitive touch controls on the outer surface of each earbud. The specific functions are as follows:

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left/Right Earbud)	Activate Voice Assistant (Siri, Google Assistant)

Action	Function
Long Press (2 seconds, Left/Right Earbud)	Reject Call
Long Press (3 seconds, Left Earbud)	Volume Down
Long Press (3 seconds, Right Earbud)	Volume Up

## Power On/Off

- **Power On:** Open the charging case, or long press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long press the touch area on both earbuds for 5 seconds.

## MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.
- **Battery Care:** To preserve battery life, avoid exposing the headphones and case to extreme temperatures. Charge regularly, even if not used frequently.
- **Water Resistance:** These headphones are not specified as water-resistant. Avoid exposure to water or excessive moisture.

## TROUBLESHOOTING

Problem	Possible Solution
Headphones not pairing	<ul style="list-style-type: none"> <li>◦ Ensure headphones are charged.</li> <li>◦ Turn off and on Bluetooth on your device.</li> <li>◦ Forget "TIMU A10" from your device's Bluetooth list and re-pair.</li> <li>◦ Place earbuds back in case, close lid, wait 5 seconds, then open again.</li> </ul>
Only one earbud working	<ul style="list-style-type: none"> <li>◦ Ensure both earbuds are charged.</li> <li>◦ Place both earbuds back into the charging case, close the lid, and then take them out together.</li> <li>◦ Reset the headphones (refer to specific reset instructions if available, otherwise try re-pairing).</li> </ul>
Low volume or poor sound quality	<ul style="list-style-type: none"> <li>◦ Adjust volume on both your device and the headphones.</li> <li>◦ Ensure earbuds are clean and free of debris.</li> <li>◦ Check for proper fit in your ears.</li> <li>◦ Move closer to your connected device to avoid interference.</li> </ul>

Problem	Possible Solution
Charging case not charging	<ul style="list-style-type: none"><li>◦ Check the charging cable and power adapter.</li><li>◦ Ensure the charging port is clean.</li><li>◦ Try a different charging cable or power source.</li></ul>

## SPECIFICATIONS

Feature	Detail
Brand	TIMU
Model	A10
Model Name	X1-WYLEU-1-1BK
Connectivity Technology	Wireless (Bluetooth 5.4)
Headphones Form Factor	True Wireless In-Ear
Microphones	4 Mics
Color	White
Product Dimensions	2.5 x 2 x 2.5 cm; 24 g
Included Components	User Manual, Charging Case, Charging Cable

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official TIMU website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact TIMU customer service through the contact details provided on their official support page.

