

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ariete](#) /

› [Ariete 4178 Dual Scrub Steam Mop Instruction Manual](#)

## Ariete 4178

# Ariete 4178 Dual Scrub Steam Mop Instruction Manual

Model: 4178

[Introduction](#)   [Safety Information](#)   [Setup](#)   [Operating](#)   [Maintenance](#)   [Specifications](#)  
[Troubleshooting](#)   [Support](#)

## 1. INTRODUCTION

Thank you for choosing the Ariete 4178 Dual Scrub Steam Mop. This innovative appliance combines the power of steam with the scrubbing action of rotating pads to provide a deep and hygienic clean for your hard floors. Please read this manual carefully before use to ensure safe operation and optimal performance.

## 2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This includes:

- Do not leave the appliance unattended while plugged in.
- Keep the appliance out of reach of children.
- Use only as described in this manual.
- Do not use on unsealed wooden floors or floors that are sensitive to heat and moisture.
- Always unplug the appliance before filling or emptying the water tank.
- Do not direct steam at people, animals, or electrical appliances.
- Use only distilled or demineralized water to prevent mineral buildup.

## 3. SETUP

### 3.1 Unpacking and Assembly

Carefully remove all components from the packaging. The Ariete 4178 is designed for easy assembly.

### 3.2 Attaching the Microfiber Pads

The appliance comes with 4 high-quality microfiber pads. Attach two pads to the rotating bases on the bottom of the mop head. Ensure they are securely fastened.



Image: The included microfiber pads and measuring cup. The pads attach to the rotating bases on the mop head.

### 3.3 Filling the Water Tank

The Ariete 4178 features a practical 400cc water tank for adequate autonomy. Use the provided measuring cup to fill the tank with distilled or demineralized water. Do not overfill.



Image: A close-up view of the dark blue steam cleaning appliance's clear water tank, showing its design and capacity.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Powering On and Heat-Up

Plug the appliance into a suitable power outlet. The bi-color indicator lights will inform you of the device's status. The steam will be ready for use in just 30 seconds, allowing you to start cleaning and sanitizing immediately.

### 4.2 Selecting Steam Speed

The rotating brushes offer two speeds: 150 rpm for delicate cleaning and 210 rpm for tackling stubborn dirt. Select the appropriate speed for your cleaning needs. The self-propulsion ensures exceptional glide.



### **VAPORE + PANNI ROTANTI**

Grazie ai panni rotanti, Dual Scrub Steam vaporizza e strofina per una doppia efficacia contro lo sporco ostinato.

Image: The Ariete 4178 Dual Scrub Steam Mop actively cleaning a floor, demonstrating the combined action of steam and rotating pads for effective dirt removal.

#### **4.3 Cleaning Surfaces**

The scrubbing effect of the rotating brushes effectively removes stubborn dirt such as dust, grease, footprints, food residues, and more. The ergonomic and functional design, being lightweight and maneuverable with a slender and inclinable body, allows you to easily clean even under low furniture, beds, and sofas.



Image: A visual representation of the Ariete 4178's key features, including the rotating pads reaching up to 210 rpm, steam ready in 30 seconds, and its inclinable body for cleaning under furniture.

It is ideal for cleaning all hard floors, including marble, solid wood, tiles, stone, laminate, and granite.

#### 4.4 Official Product Videos

##### Schenley Steam Mop Demonstration

Your browser does not support the video tag.

Video: A demonstration of the Schenley steam mop, showcasing its features and cleaning capabilities on various surfaces. This video provides a general overview of steam mop functionality.

##### AlfaBot S2 Cordless Electric Mop Overview

Your browser does not support the video tag.

Video: An overview of the AlfaBot S2 Cordless Electric Mop, demonstrating its ease of use, maneuverability, and effectiveness in cleaning different floor types. Note that this is a cordless model, while the Ariete 4178 is corded.

## Shark Steam & Scrub Steam Mop Features

Your browser does not support the video tag.

Video: A short promotional video highlighting the features of the Shark Steam & Scrub Steam Mop, including its rotating pads and steam cleaning capabilities. This provides a visual example of similar technology.

## 5. MAINTENANCE

### 5.1 Cleaning the Microfiber Pads

The included microfiber pads are reusable and washable. After use, detach the pads from the mop head and wash them conveniently in a washing machine. This ensures ecological and long-lasting cleaning.

### 5.2 Emptying and Refilling the Water Tank

After each use, or when the water level is low, unplug the appliance and allow it to cool. Empty any remaining water from the tank and refill as described in the Setup section.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Ariete
Model Name	4178 Dual Steam Scrub
Model Number	4178/00
Color	Blue
Product Dimensions	37 x 17 x 120 cm
Item Weight	4.64 Kilograms
Water Tank Capacity	400 Centiliters
Wattage	1200 watts
Voltage	230 Volt
Special Feature	Motorized Rotating Pads
Recommended Surfaces	Floor, Sink, Tile, Countertop, Bathroom
Included Components	Floor pads, Measuring cup



## DIMENSIONI

L 37 cm x P 17 cm x A 120 cm




Image: The Ariete 4178 Dual Scrub Steam Mop with its dimensions clearly indicated: Length 37 cm, Depth 17 cm, Height 120 cm.

## 7. TROUBLESHOOTING

### 7.1 No Steam Production

- Check if the appliance is properly plugged into a working power outlet.
- Ensure the water tank is filled with water.
- Allow sufficient time (approx. 30 seconds) for the appliance to heat up.

### 7.2 Pads Not Rotating

- Verify that the pads are correctly attached to the rotating bases.
- Check if the selected speed setting is active.
- Ensure there are no obstructions preventing the pads from rotating freely.

### 7.3 Poor Cleaning Performance

- Ensure the microfiber pads are clean. Replace or wash dirty pads.
- Increase the steam speed for more stubborn dirt.
- Pre-vacuum the floor to remove loose debris before steam cleaning.

## 8. WARRANTY AND SUPPORT

---

For warranty information, please refer to the documentation included with your purchase or visit the official Ariete website. For technical support, spare parts, or additional assistance, please contact Ariete customer service through their official channels.

You can visit the Ariete store on Amazon for more products and information:[Ariete Store](#)