

[Manuals.plus](#) /

› [Swarovski](#) /

› Swarovski NL Pure 8x42 Binoculars Instruction Manual

Swarovski NL Pure 8x42

Swarovski NL Pure 8x42 Binoculars Instruction Manual

Model: NL Pure 8x42 | Brand: Swarovski

1. INTRODUCTION

The Swarovski NL Pure 8x42 Binoculars in Burnt Orange are engineered for superior optical performance. Featuring 8x magnification and a 42mm objective lens, these binoculars provide a wide field of view and exceptional detail. Designed for comfort and durability, they are lightweight, ergonomic, waterproof, and fog-proof, making them suitable for various outdoor activities and weather conditions. This manual provides essential information for the proper setup, operation, and maintenance of your binoculars.



Image: Swarovski NL Pure 8x42 Binoculars, Burnt Orange.

2. PRODUCT FEATURES

- **High-Quality Optics:** Provides exceptional clarity and brightness with 8x magnification and a 42mm objective lens.
- **Ergonomic Design:** Lightweight and comfortable for extended use.
- **Durable Construction:** Waterproof and fog-proof for reliable performance in diverse weather conditions.
- **Wide Field of View:** Offers detailed observation, ideal for nature enthusiasts.
- **Distinctive Finish:** Features a stylish burnt orange color.

3. WHAT'S IN THE BOX

Upon unboxing your Swarovski NL Pure 8x42 Binoculars, you should find the following items:

- Swarovski NL Pure 8x42 Binoculars

- Protective Carrying Case
- User Manual / Technical Data Sheet
- Objective Lens Caps
- Ocular Lens Caps
- Comfort Neck Strap
- Strap Adapters
- Cleaning Kit (includes small brush and soap)

Your browser does not support the video tag.

Video: Unboxing the Swarovski NL Pure Binoculars. Note: The binoculars shown in the video are green, while your product is burnt orange. The unboxing process and accessories are identical.

4. SETUP

4.1 Attaching the Neck Strap

1. Locate the neck strap and the two strap adapters.
2. Attach each strap adapter to the designated attachment points on the binocular barrels.
3. Thread the ends of the neck strap through the adapters and secure them according to the strap's design. Ensure the strap is firmly attached before use.

4.2 Adjusting Eyecups

The eyecups can be adjusted to provide optimal eye relief, especially for users wearing eyeglasses.

- **For Eyeglass Wearers:** Rotate or twist the eyecups down to their lowest position.
- **For Non-Eyeglass Wearers:** Rotate or twist the eyecups upwards until you achieve a full field of view without vignetting. The NL Pure models offer multiple click-stop positions for precise adjustment.

4.3 Interpupillary Distance Adjustment

Adjust the distance between the two binocular barrels to match the distance between your pupils. This ensures a single, circular field of view.

1. Hold the binoculars up to your eyes.
2. Grasp each barrel firmly and move them closer together or further apart until you see a single, clear image.

4.4 Diopter Adjustment

Compensate for differences in vision between your left and right eyes.

1. Cover the right objective lens (the front lens) with your hand.
2. Look through the left eyepiece at a distant object and rotate the central focusing wheel until the image is sharp.
3. Now, cover the left objective lens and look through the right eyepiece. Adjust the diopter ring (usually located on the right eyepiece) until the image is sharp.
4. Your binoculars are now set for your individual vision. Use only the central focusing wheel for subsequent focusing.

5. OPERATING

5.1 Focusing

Once the interpupillary distance and diopter are set, use the central focusing wheel to bring objects into sharp focus.

1. Point the binoculars at the desired object.
2. Rotate the central focusing wheel until the image appears clear and sharp.

5.2 Viewing

Hold the binoculars steady and enjoy the wide, detailed view. The ergonomic design is intended to reduce fatigue during prolonged observation.

Your browser does not support the video tag.

Video: A user demonstrating the use of Swarovski NL Pure Binoculars in a snowy outdoor setting.

Your browser does not support the video tag.

Video: A user demonstrating the use of Swarovski NL Pure Binoculars.

6. MAINTENANCE

6.1 Cleaning the Optics

Use the provided cleaning kit for optimal care of your binoculars.

1. Use the small brush to gently remove any loose dust or debris from the lenses and body.
2. For stubborn dirt or smudges, apply a small amount of the provided soap to a clean, soft cloth (not included) and gently wipe the lenses.
3. Wipe dry with a clean, lint-free microfiber cloth. Avoid using harsh chemicals or abrasive materials.

6.2 General Care and Storage

- Always store your binoculars in their protective carrying case when not in use.
- Keep the lens caps on to prevent dust and scratches.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- If the binoculars become wet, dry them thoroughly before storing.

7. TROUBLESHOOTING

If you experience any issues with your Swarovski NL Pure 8x42 Binoculars, please refer to the following common solutions:

- **Blurred Image:** Ensure the interpupillary distance and diopter settings are correctly adjusted for your eyes. Use the central focusing wheel to sharpen the image.
- **Double Image:** Re-adjust the interpupillary distance until a single, clear image is visible.
- **Fogging:** The binoculars are fog-proof. If internal fogging occurs, ensure the lenses are clean and the binoculars have acclimatized to the ambient temperature. If fogging persists, contact customer support.
- **Difficulty Focusing:** Check for any obstructions on the lenses. Ensure the central focusing wheel moves freely.

For persistent issues or complex problems, please contact Swarovski customer support or an authorized dealer for assistance.

8. SPECIFICATIONS

Feature	Specification
Brand	Swarovski

Model Name	NL Pure
Model Number	36015
Magnification	8x
Objective Lens Diameter	42 Millimeters
Color	Burnt Orange
Water Resistance Level	Waterproof
Focus Type	Manual Focus
Item Weight	6 Ounces
UPC	708026360152

9. WARRANTY AND SUPPORT

For detailed information regarding the product warranty, please refer to the official Swarovski website. Swarovski is committed to providing high-quality products and excellent customer service.

If you require technical support, have questions about your product, or need assistance with repairs, please visit the [Swarovski Optik website](#) or contact an authorized Swarovski dealer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

